


HONDA

XBR500

SHOP MANUAL
MANUEL D'ATELIER
WERKSTATT-HANDBUCH

© HONDA MOTOR CO., LTD. 1985

Free use for all XBR owners



HOW TO USE THIS MANUAL

This shop manual describes the technical features and servicing procedures for the XBR500.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition.

Throughout the manual, the following abbreviations are used to identify individual models.

CODE	AREA (TYPE)
ED	Europe
E	U.K.
F	France
*G-I	Germany
H	Netherlands
*G-II	Germany
SW	Switzerland
SD	Sweden

*G-I : Full power type

*G-II: Limited power type

Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 through 3 apply to the whole motorcycle, while sections 4 through 19 describe parts of the motorcycle, grouped according to location.

Find the section you want on this page, then turn to the table of contents on page 1 of that section.

Most sections start with an assembly or system illustration, service information and troubleshooting for the section. The subsequent pages give detailed procedures.

If you don't know the source of the trouble, go to section 20 TROUBLESHOOTING.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION.


HONDA MOTOR CO., LTD.
SERVICE PUBLICATIONS OFFICE

CONTENTS

	GENERAL INFORMATION	1
	LUBRICATION	2
	MAINTENANCE	3
ENGINE	FUEL SYSTEM	4
	ENGINE REMOVAL/INSTALLATION	5
	CYLINDER HEAD/VALVES	6
	CYLINDER/PISTON	7
	CLUTCH/OIL PUMP/KICK STARTER	8
	ALTERNATOR	9
	SHIFT LINKAGE/TRANSMISSION	10
	CRANKSHAFT/BALANCER	11
CHASSIS	FRONT WHEEL/SUSPENSION/STEERING	12
	REAR WHEEL/BRAKE/SUSPENSION	13
	HYDRAULIC BRAKE	14
	REAR FENDER/EXHAUST SYSTEM	15
ELECTRICAL	IGNITION SYSTEM	16
	BATTERY CHARGING SYSTEM	17
	ELECTRICAL STARTER SYSTEM	18
	LIGHTS/SWITCHES/INSTRUMENT	19
	TROUBLESHOOTING	20

Free use for all XBR owners

IMPORTANT SAFETY NOTICE



WARNING Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

CAUTION: Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. It is important to note that this manual contains *some* warnings and cautions against some specific service methods which could cause **PERSONAL INJURY** to service personnel or could damage a vehicle or render it unsafe. Please understand that those warnings could not cover all conceivable ways in which service, whether or not recommended by Honda might be done or of the possible hazardous consequences of each conceivable way, nor could Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized by the service method or tools selected.

AVIS IMPORTANT




ATTENTION Indique un grand risque d'accident corporel grave, voire mortel, si les instructions ne sont pas observées.

PRECAUTION: Indique un risque d'accident corporel ou de détérioration du véhicule si les instructions ne sont pas observées.

NOTE: Fournit des renseignements utiles.

On ne trouvera pas dans ce manuel de description détaillée des procédures en atelier, des principes de sécurité ou des opérations d'entretien. Noter cependant que ce manuel comprend quelques avertissements contre certaines méthodes de révision de la machine qui risquent, si on les applique, d'apporter des **DOMMAGES CORPORELS** au personnel chargé de la révision, d'endommager la machine ou de rendre son utilisation peu sûre. On comprendra, par ailleurs, que ces avertissements ne peuvent couvrir toutes les façons de procéder à une révision, que celle-ci soit recommandée par Honda ou non, ni tous les dangers que l'on encourt à suivre telle ou telle façon étant donné qu'il est impossible pour Honda de ne serait-ce que répertorier toutes les procédures de révision. Avant de procéder à une révision, qu'elle soit ou non recommandée par Honda, il faudra donc s'assurer absolument que ni le personnel ni la machine ne sont soumis à un risque quelconque à cause des méthodes ou des outils utilisés pour la révision.

WICHTIGER SICHERHEITSHINWEIS



WARNUNG Zeigt mögliche persönliche Verletzungs- oder Lebensgefahr an, falls Anweisungen nicht beachtet werden.

VORSICHT: Zeigt mögliche persönliche Verletzungsgefahr oder Beschädigung der Maschine an, falls Anweisungen nicht befolgt werden.

ZUR BEACHTUNG: Gibt wertvolle Informationen.

Ausführliche Beschreibungen allgemeiner Werkstatt-Arbeitsweisen, Sicherheitsregeln und Wartungsverfahren sind nicht eingeschlossen. Es ist wichtig zu beachten, daß dieses Handbuch einige Warnungen und Vorsichtsmaßnahmen für bestimmte Wartungsmethoden enthält, die **PERSÖNLICHE VERLETZUNG** des Werkstattpersonals verursachen, das Fahrzeug beschädigen oder es fahrunsicher machen können. Verständlicherweise können diese Warnungen nicht alle absehbaren Verfahrensweisen der Wartung, ob von Honda empfohlen oder nicht, oder die möglichen gefährlichen Folgen der einzelnen Verfahrensweisen erfassen, ganz abgesehen davon, daß Honda nicht alle solche Verfahrensweisen erforschen kann. Jeder, der bestimmte Wartungsverfahren oder Werkzeuge benutzt, ob von Honda empfohlen oder nicht, muß sich selbst gründlich davon überzeugen, daß durch die gewählten Wartungsmethoden oder Werkzeuge weder die persönliche Sicherheit noch die Sicherheit des Fahrzeugs gefährdet ist.

1. GENERAL INFORMATION

GENERAL SAFETY	1-1	TORQUE VALUES	1-5
SERVICE RULES	1-1	TOOLS	1-7
MODEL IDENTIFICATION	1-2	WIRING DIAGRAM	1-9
SPECIFICATIONS	1-3	CABLE AND HARNESS ROUTING	1-11

GENERAL SAFETY

WARNING

If the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.

WARNING

Gasoline is extremely flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.

WARNING

The battery electrolyte contains sulfuric acid. Protect your eyes, skin and clothing. In case of contact, flush thoroughly with water and call a doctor if electrolyte gets in your eyes.

WARNING

The battery generates hydrogen gas which can be highly explosive. Do not smoke or allow flames or sparks near the battery, especially while charging it.


SERVICE RULES

1. Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that do not meet Honda's design specifications may damage the motorcycle.
2. Use the special tools designed for this product.
3. Use only metric tools when servicing this motorcycle. Metric bolts, nuts, and screws are not interchangeable with English fasteners. The use of incorrect tools and fasteners may damage the motorcycle.
4. Install new gaskets, O-ring, cotter pins, lock plates, etc. when reassembling.
5. When tightening bolts or nuts, begin with larger-diameter or inner bolts first, and tighten to the specified torque diagonally, unless a particular sequence is specified.
6. Clean parts in clean solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
7. After reassembly, check all parts for proper installation and operation.
8. Route all electrical wires as shown on page 1-11, Cable and Harness Routing.


GENERAL INFORMATION

MODEL IDENTIFICATION


ALLGEMEINE SICHERHEITSHINWEISE	1-1	ANZUGSWERKE	1-5
ARBEITSREGELN	1-1	WERKZEUGE	1-7
MODELLKENNUNG	1-2	INHALTSPLAN	1-9
TECHNISCHE DATEN		FAHRZUG- UND KASSELFÜHRUNG	1-11



ARBEITSREGELN




(1) The frame serial number is stamped on the steering head right side.



(2) The engine serial number is stamped on the left side of the lower crankcase.



(3) The carburetor identification number is on the left side of the carburetor.



(4) The color label is attached to the rear fender below the seat.

GENERAL INFORMATION

SPECIFICATIONS

ITEM		SPECIFICATIONS	
DIMENSIONS	Overall length	2,120 mm (83.5 in) < SW: 2,155 mm (84.8 in) >	
	Overall width	685 mm (27.0 in)	
	Overall height	1,055 mm (41.5 in)	
	Wheelbase	1,400 mm (55.1 in)	
	Ground clearance	160 mm (6.3 in)	
	Dry weight	157 kg (346 lb)	
FRAME	Type	Semi double cradle	
	Front suspension, travel	Telescopic	140 mm (5.5 in)
	Rear suspension, travel	Swing arm	100 mm (3.9 in)
		Front	Rear
	Tire size	100/90-18 56S	110/90-18 61S
	Driver only	200 kPa (2.00 kg/cm ² , 28 psi)	200 kPa (2.00 kg/cm ² , 28 psi)
	Driver and one passenger	200 kPa (2.00 kg/cm ² , 28 psi)	250 kPa (2.50 kg/cm ² , 36 psi)
	Front brake, lining swept area	Disc brake, 452 cm ² (70.06 sq in)	
ENGINE	Rear brake, lining swept area	132 cm ² (20.46 sq in)	
	Fuel capacity	19 lit (5.0 US gal, 4.2 Imp gal)	
	Fuel reserve capacity	3.3 lit (0.9 US gal, 0.7 Imp gal)	
	Caster	29° 30'	
	Trail	115 mm (4.5 in)	
	Front fork oil capacity	283 cm ³ (9.6 oz)	
	Type	Air-cooled 4-stroke SOHC	
	Cylinder arrangement	Vertical single	
	Bore x stroke	92.0 x 75.0 mm (3.62 x 2.95 in)	
	Displacement	498 cm ³ (30.4 cu. in)	
CARBURETOR	Compression ratio	8.9 : 1	
	Valve train	4-valve, silent chain driven SOHC	
	Maximum horsepower	31.5 KW (43 BHP)/7,000 min ⁻¹ (rpm)	
	Maximum torque	4.4 kg-m (31.8 ft-lb)/6,000 min ⁻¹ (rpm)	
	Engine oil capacity	2.3 lit (2.4 US qt, 2.0 Imp qt) at engine assembly	
		1.6 lit (1.7 US qt, 1.4 Imp qt) at oil change	
	Lubrication system	Forced pressure and dry sump	
	Air filtration system	Paper element	
	Cylinder compression	1,250 ± 150 kPa (12.5 ± 1.5 kg/cm ² , 172 ± 21 psi)	
	Intake valve	Opens	5° (BTDC)
		Closes	40° (ABDC)
	Exhaust valve	Opens	45° (BBDC)
		Closes	5° (ATDC)
	Valve clearance	Intake	0.10 mm (0.004 in)
		Exhaust	0.12 mm (0.005 in)
	Type	Constant vacuum	
	Identification number	VE10A	
	Main jet	#152	
	Slow jet	#48	
	Pilot screw initial opening	2-1/2	
	Float level	18.5 mm (0.73 in)	
	Idle speed	1,200±100 min ⁻¹ (rpm)	

GENERAL INFORMATION

ITEM		SPECIFICATIONS
DRIVE TRAIN	Clutch type	Wet multi-plate
	Transmission	5-speed constant mesh
	Primary reduction	2.482 (72/29)
	Gear ratio I	2.384 (31/13)
	Gear ratio II	1.555 (28/18)
	Gear ratio III	1.200 (24/20)
	Gear ratio IV	1.000 (23/23)
	Gear ratio V	0.875 (21/24)
	Final reduction	2.400 (36/15) < G-II : 2.571 >
ELECTRICAL	Gearshift pattern	Left foot operated return system (1-N-2-3-4-5)
	Ignition	CDI
	Ignition timing	Initial
		Full advance
	Alternator	170 W/5,000 min ⁻¹ (rpm)
	Battery capacity	12V-12 AH
	Spark plug	Standard: DPR8EA-9 (NGK) or X24EPR-U9 (ND)
		For cold climate (Below 5°C, 41°F):
		*DPR7EA9 (NGK) or *X22EPR-U9 (ND)
		For extended high speed riding:
		DPR9EA-9 (NGK) or X27EPR-U9 (ND)
	Spark plug gap	0.8-0.9 mm (0.031-0.035 in)
	Headlight, Hight/Low	60/55 W
	Brake and taillight	21/5 W
	Turn signal light, Front/Rear	21/21 W
	Speedometer light	3.4 W x 2
	Tachometer light	3 W x 2
	Neutral indicator	3 W
	Turn signal indicator	3 W
	Hight beam indicator	3 W
		* : Except G-I, H types

GENERAL INFORMATION

TORQUE VALUES

ENGINE

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kg-m, ft-lb)	REMARKS
Spark plug	1	12	15-20 (1.5-2.0, 11-15)	
Crankcase drain bolt	1	12	20-30 (2.0-3.0, 15-22)	
Oil filter cover bolt	3	6	8-10 (0.8-1.0, 5-7)	
Valve adjusting screw lock nut	4	7	23-27 (2.3-2.7, 17-20)	
Cylinder head bolt	6	8	28-32 (2.8-3.2, 20-23)	Apply engine oil to the washer
Cam sprocket bolt	2	7	18-22 (1.8-2.2, 13-16)	
Cylinder head cover bolt	1	8	20-26 (2.0-2.6, 15-19)	
	1	6	10-14 (1.0-1.4, 7-10)	
	11	6	8-12 (0.8-1.2, 6-9)	6 mm flange bolt with 8 mm head
Rocker arm shaft	4	14	25-30 (2.5-3.0, 18-22)	
Crankcase cover bolt	19	6	10-14 (1.0-1.4, 7-10)	
Primary drive gear lock nut	1	18	70-80 (7.0-8.0, 51-58)	
Neutral switch	1	10	10-14 (1.0-1.4, 7-10)	
Sub rocker arm shaft IN.	4	14	25-30 (2.5-3.0, 18-22)	
EX.	4	12	20-25 (2.0-2.5, 15-18)	
Cylinder bolt	4	10	40-44 (4.0-4.4, 29-32)	Apply engine oil to the washer
Clutch lock nut	1	18	70-80 (7.0-8.0, 51-58)	
Flywheel bolt	1	12	115-135 (11.5-13.5, 84-98)	Apply molybdenum disulfide grease to the threads
Gear shift drum stopper plate bolt	1	6	10-14 (1.0-1.4, 7-10)	
Shift drum stopper arm bolt	1	8	22-28 (2.2-2.8, 16-20)	
Gearshift return spring pin	1	8	22-26 (2.2-2.6, 16-19)	
Shift fork set bolt	1	7	13-17 (1.3-1.7, 9-12)	
Kick starter stopper plate bolt	2	8	22-28 (2.2-2.8, 16-20)	
Mainshaft bearing plate bolt	1	8	22-28 (2.2-2.8, 16-20)	
Tensioner mounting bolt	1	6	10-14 (1.0-1.4, 7-10)	Apply thread lock agent to the threads
Starter clutch torx bolt	6	8	28-32 (2.8-3.2, 20-23)	
Stator mounting bolt	3	6	8-12 (0.8-1.2, 6-9)	
Crankcase socket bolt	11	6	10-14 (1.0-1.4, 7-10)	

FRAME

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kg-m, ft-lb)	REMARKS
Oil tank drain bolt	1	12	20-30 (2.0-3.0, 14-22)	
Fuel cup	1	-	3-5 (0.3-0.5, 2-4)	
Oil hose mount bolt	2	6	7-11 (0.7-1.1, 5-8)	
mount nut	2	6	8-12 (0.8-1.2, 6-9)	
Side stand pivot bolt	1	10	35-45 (3.5-4.5, 25-33)	
Fuel tank mounting bolt	1	6	8-12 (0.8-1.2, 6-9)	
Engine rear hanger bolt	1	10	80-100 (8.0-10.0, 58-72)	
Hanger and bracket bolt	4	10	35-45 (3.5-4.5, 25-33)	
	6	8	24-30 (2.4-3.0, 17-22)	
Exhaust pipe joint nut	4	8	8-12 (0.8-1.2, 6-9)	
Exhaust pipe clamp bolt	4	8	15-25 (1.5-2.5, 11-18)	
Exhaust muffler mount bolt	2	8	20-30 (2.0-3.0, 15-22)	
Foot peg bracket bolt	4	8	20-30 (2.0-3.0, 15-22)	
Handlebar pinch bolt	2	8	18-25 (1.8-2.5, 13-18)	

GENERAL INFORMATION

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kg-m, ft-lb)	REMARKS
Front axle	1	12	55-65 (5.5-6.5, 40-47)	
Front axle holder nut	4	8	18-25 (1.8-2.5, 13-18)	
Front fork upper pinch bolt	2	7	9-13 (0.9-1.3, 7-9)	
Front fork lower pinch bolt	2	8	30-40 (3.0-4.0, 22-29)	
Front fork cap	2	31	15-30 (1.5-3.0, 11-22)	
Front fork socket bolt	2	8	15-25 (1.5-2.5, 11-18)	Apply thread lock agent to the threads
Steering bearing adjusting nut	1	26	Initial: 30-40 (3.0-4.0, 22-29) Final: 14-16 (1.4-1.6, 10-12)	Apply engine oil to the threads Refer to page 12-21
Steering stem nut	1	24	80-120 (8.0-12.0, 58-87)	
Front brake disc mount bolt	6	8	37-43 (3.7-4.3, 27-31)	Apply thread lock agent to the threads
Brake hose oil bolt	2	10	30-40 (3.0-4.0, 22-29)	
Caliper bleed valve	1	7	4-7 (0.4-0.7, 3-5)	
Caliper pad pin retainer bolt	1	6	8-13 (0.8-1.3, 6-9)	
Caliper bracket bolt	2	10	30-40 (3.0-4.0, 22-29)	
Caliper mount bolt	1	8	20-25 (2.0-2.5, 14-18)	
Caliper pivot bolt	1	12	25-30 (2.5-3.0, 18-22)	
Swing arm pivot bolt	1	14	80-100 (8.0-10.0, 58-72)	
Rear axle nut	1	16	80-100 (8.0-10.0, 58-72)	
Rear shock absorber mount nut/bolt	4	10	40-50 (4.0-5.0, 29-36)	
Chain slider mounting screw	3	5	5-7 (0.5-0.7, 4-5)	
Rear brake arm bolt	1	6	8-12 (0.8-1.2, 6-9)	
Brake pedal bolt	1	8	18-25 (1.8-2.5, 13-18)	
Gear shift pedal bolt	1	6	8-12 (0.8-1.2, 6-9)	
Kick starter arm bolt	1	8	18-25 (1.8-2.5, 13-18)	Apply thread lock agent to the threads
Damper rod lock nut	2	10	30-40 (3.0-4.0, 22-29)	
Driven sprocket nut	5	10	60-70 (6.0-7.0, 43-51)	

Torque specifications listed above are for the most important tightening points. If a specification is not listed, follow the standards below.

STANDARD TORQUE VALUES

TYPE	TORQUE N-m (kg-m, ft-lb)	TYPE	TORQUE N-m (kg-m, ft-lb)
5 mm bolt, nut	4.5-6.0 (0.45-0.6, 3.3-4.3)	5 mm screw	3.5-5 (0.35-0.5, 2.5-3.6)
6 mm bolt, nut	8-12 (0.8-1.2, 6-9)	6 mm screw and	
8 mm bolt, nut	18-25 (1.8-2.5, 13-18)	6 mm flange bolt	7-11 (0.7-1.1, 5-8)
10 mm bolt, nut	30-40 (3.0-4.0, 22-29)	with 8 mm head	
12 mm bolt, nut	50-60 (5.0-6.0, 36-43)	6 mm flange bolt, nut	10-14 (1.0-1.4, 7-10)
		8 mm flange bolt, nut	24-30 (2.4-3.0, 17-22)
		10 mm flange bolt, nut	35-45 (3.5-4.5, 25-33)

GENERAL INFORMATION

TOOLS

SPECIAL

*: These tools are newly designed and have not been used before.

DESCRIPTION	NUMBER	REMARKS	REF. PAGE
Pilot screw wrench	07908-4220201		4-9
Cylinder compression gauge attachment	07908-KK60000		3-16
Snap ring pliers	07914-3230001		14-8
Steering stem socket	07916-3710100		12-19, 21
Crankcase assembly tool	07931-KF00000		11-5
Threaded adaptor	07931-KF00200		11-5
Puller shaft	07931-ME40000		11-5
Assembly collar	07931-KF00100		11-5
Crankshaft puller	07935-KF00001		11-2
Bearing remover set	07936-3710001		13-14
Remover spindle assembly	07936-3710600		13-14
Remover handle	07936-3710100		13-14
Knock pin puller set	07936-MA70000	Decompressor lifter lever dowel pin	6-5
Sliding shaft	07936-MA70100		6-5
Remover weight	07741-0010201		6-5, 13-14
Attachment	07945-3330300	Dall race lower	12-21
Steering stem driver	07946-MB00000		12-21
Attachment	07946-6790200	Left crankcase bearing	11-4
Attachment	07946-3290000	Ball race upper	12-20
Fork seal driver attachment	07947-KA20200		12-16
Ball race remover	07953-3330000	Ball race upper	12-20
Attachment	07953-KM10100	Ball race lower	12-20
Valve guide reamer	07984-5510000		6-12
* Tensioner setting holder	07973-MG30002		6-6, 8, 16
Bearing puller	07931-MK20100	Left crankcase bearing	11-2
Universal bearing puller	07631-0010000		11-2
Attachment	07960-1870100		11-2
Torx bit (T40)	07703-0010100		18-3

COMMON

DESCRIPTION	NUMBER	REMARKS	REF. PAGE
Float level gauge	07401-0010000		4-7
Wrench, 10 x 12 mm	07708-0030200	Valve clearance	3-8
Adjusting wrench A	07708-0030300	Valve clearance	3-8
Lock nut wrench, 30 x 32 mm	07716-0020400		12-19, 12-22
Clutch center holder	07724-0050000	Clutch	8-5, 18
Flywheel holder	07725-0040000		9-3, 4
Rotor puller	07733-0020001		9-3
Valve guide remover, 6.6 mm	07742-0010200		6-11, 6-12
Driver pin, 2.5 mm	07744-0010100	Oil pump	8-10
Attachment, 24 x 26 mm	07746-0010700		8-4
Attachment, 32 x 35 mm	07746-0010100		13-14
Attachment, 37 x 40 mm	07746-0010200		12-9, 13-6
Attachment, 42 x 47 mm	07746-0010300		12-9, 13-6
Attachment, 72 x 75 mm	07746-0010600		11-4
Attachment, 35 mm I.D.	07746-0030400	Crankshaft	11-5
Pilot, 15 mm	07746-0040300		12-9
Pilot, 17 mm	07746-0040400		13-6
Pilot, 20 mm	07746-0040500		8-4, 13-14
Pilot, 35 mm	07746-0040800		11-4
Pilot, 40 mm	07746-0040900		11-4
Fork seal driver	07747-0010100		12-16
Driver	07749-0010000		-
Shock absorber compressor	07959-3290001		13-12
Valve spring compressor	07757-0010000		6-10, 6-15
Gear holder	07724-0010100	Primary drive gear	10-3, 10-12
Bearing remover head, 15 mm	07746-0050400		12-8
Bearing remover shaft	07746-0050100		12-8
Bearing remover head, 17mm	07746-0050500		13-5

VALVE SEAT CUTTERS

DESCRIPTION	NUMBER	REMARKS	REF. PAGE
Valve seat cutter, 35 mm	07780-0010400	45° EX	6-13, 6-14
Valve seat cutter, 40 mm	07780-0010500	45° IN	6-13, 6-14
Valve seat cutter, 35 mm	07780-0012300	32° EX	6-13, 6-14
Valve seat cutter, 38.5 mm	07780-0012400	32° IN	6-13, 6-14
Valve seat cutter, 37.5 mm	07780-0014100	60° IN/EX	6-13, 6-14
Cutter holder, 6.6 mm	07781-0010201		6-13, 6-14

2. LUBRICATION

SERVICE INFORMATION	2-1	ENGINE OIL FILTER	2-3
TROUBLESHOOTING	2-1	OIL FILTER SCREEN	2-4
ENGINE OIL LEVEL CHECK	2-2	OIL STRAINER	2-5
ENGINE OIL CHANGE	2-2	LUBRICATION POINTS	2-7

2

SERVICE INFORMATION

GENERAL


- This section describes inspection and replacement of engine oil and oil filter and cleaning of the oil filter screen and the strainer.
- Oil pump service is described in Section 8.

SPECIFICATIONS

Oil capacity	2.3 liter (1.4 US qt, 2.0 Imp qt) at engine assembly 1.6 liter (1.7 US qt, 1.4 Imp qt) at oil change
Recommended oil:	HONDA 4 stroke oil or equivalent API service classification SE or SF
Oil pump delivery	Pump A 7.5 lit (7.9 US qt, 6.6 Imp qt)/min. at 5,300 min ⁻¹ (rpm) Pump B 10.0 lit (10.6 US qt, 8.8 Imp qt)/min. at 5,300 min ⁻¹ (rpm)

TORQUE VALUES

Crankcase drain bolt	20–30 N·m (2.0–3.0 kg·m, 15–22 ft·lb)
Oil tank drain bolt	20–30 N·m (2.0–3.0 kg·m, 15–22 ft·lb)
Oil filter cover bolt	8–10 N·m (0.8–1.0 kg·m, 5–7 ft·lb)



- (1) Single grade
- (2) Multi grade

TROUBLESHOOTING

Oil level too low

- Normal oil consumption
- External oil leaks
- Worn piston rings

Oil contamination

- Oil not changed often enough
- Faulty head gasket

LUBRICATION

ENGINE OIL LEVEL CHECK

The oil filler cap is in engine oil tank and has a dipstick for measuring the oil level.

To inspect the engine oil level, following the instructions described below:

NOTE

- The oil level cannot be checked accurately immediately after the motorcycle has been stopped.

1. With the motorcycle on its center stand on level ground, start and warm the engine until it runs smoothly. Remove the right side cover.
2. Let the engine idle at $1,200 \pm 100$ min⁻¹ (rpm) for 3 minutes until the engine oil level stabilizes.

NOTE



- Do not allow the engine to run above the idle speed or the engine oil level cannot be checked accurately.

3. Stop the engine and remove the oil filler cap/dipstick immediately, wipe it clean and insert the dipstick without screwing it in. The oil level should be between the upper and lower level marks on the dipstick.
4. If the oil is near the lower level mark, add the recommended oil up to the upper level mark on the dipstick. Do not overfill.

Reinstall the filler cap/dipstick. Check for oil leaks.

CAUTION

- *Running the engine with insufficient oil can cause serious engine damage.*




ENGINE OIL CHANGE

NOTE

- Change the engine oil with the engine warm and the motorcycle on its center stand to assure complete and rapid draining.

1. Start the engine and let it idle for a few minutes.
2. Stop the engine and place an oil drain pan under the engine. Remove the oil filler cap/dipstick and loosen the drain bolt on the oil tank. Install the oil guide, included in the tool kit, on the oil tank as shown. Remove the oil drain bolt to drain the oil from the oil tank.



LUBRICATION

3. Remove the drain bolt on the left crankcase to drain the oil from the crankcase.
4. With the engine stop switch OFF, operate the kick starter several times to drain any oil which may be left in the engine.
5. After the oil has completely drained, make sure the sealing washers on the drain bolts are in good condition.
6. Install the crankcase drain bolt and oil tank drain bolt.

CAUTION

- Oil quantity is about 1.6 liters (1.7 US qt, 1.4 Imp qt) at oil change, and about 1.7 liters (1.8 US qt, 1.5 Imp qt) at filter change.

TORQUE:

Crankcase drain bolt: 20–30 N·m (2.0–3.0 kg·m, 15–22 ft·lb)

Oil tank drain bolt: 20–30 N·m (2.0–3.0 kg·m, 15–22 ft·lb)

7. Pour 1.6 liters (1.7 US qt, 1.4 Imp qt) at oil change, or 1.7 liters (1.8 US qt, 1.5 Imp qt) at oil filter change of the recommended oil into the oil tank up to the upper level mark on the dipstick in two or three steps. Install the oil filler cap/dipstick.
8. Perform the step 1 thru 3 of engine oil level check procedure described in page 2-2.
9. Add recommended oil into the oil tank up to the upper level mark on the dipstick.
10. Reinstall the filler cap/dipstick and right side cover. Check for oil leaks.

CAUTION




- Running the engine with insufficient oil can cause serious engine damage.

ENGINE OIL FILTER

NOTE

- The oil filter should be changed after draining the engine oil.


1. Remove the three bolts securing the cover and the cover.



LUBRICATION


2. Remove and discard the oil filter element.
3. Check that the O-ring on the oil filter cover is in good condition.
Install the spring, a new oil filter element and the oil filter cover, and tighten the bolts.

TORQUE: 8–10 N·m (0.8–1.0 kg·m, 5-7 ft·lb)




OIL FILTER SCREEN (in the right crankcase)


Remove the right crankcase cover (page 8-3), gasket and dowel pins.



Remove the bolt attaching the oil screen to the right crankcase.



Remove the oil screen and clean it.
Install the oil screen and tighten the bolt.
Install the right crankcase cover (page 8-19).
Fill the crankcase with the recommended oil (page 2-1).



OIL STRAINER

REMOVAL

Drain the engine oil (page 2-2).

Remove the rear wheel (page 13-3).

Remove the seat and rear shock absorber upper mounting nuts.

Remove the battery (page 17-2).

Remove the battery holder-to-oil tank mounting bolts.




Remove the oil tank mount bolt from the right side.

Remove the oil tank mount bolt and spacer from the left side.

Disconnect the oil tank breather tube from the oil tank.

Remove rear fender B by removing the bolt.

Disconnect the oil hoses from the oil tank by removing the mounting nuts.




LUBRICATION

Remove the oil tank from the frame




Remove the oil tank mounting bolts and separate the oil tank.
Clean the oil strainer.
Replace the oil strainer if necessary.



INSTALLATION


Install the removed parts in the reverse order of removal.
Install the O-rings and tighten the nuts securely.
Fill the engine oil (page 2-3), start the engine and check for oil leaks.



LUBRICATION

LUBRICATION POINTS

Use general purpose grease where a specification is not given.
Apply oil or grease to sliding surfaces and cables not shown here.



3. MAINTENANCE

3

SERVICE INFORMATION	3-1	BATTERY	3-10
MAINTENANCE SCHEDULE	3-3	BRAKE FLUID	3-10
FUEL LINE	3-4	BRAKE SHOE/PAD WEAR	3-11
FUEL STRAINER SCREEN	3-4	BRAKE SYSTEM	3-12
THROTTLE OPERATION	3-4	BRAKE LIGHT SWITCH	3-13
CARBURETOR CHOKE	3-5	HEADLIGHT AIM	3-13
AIR CLEANER	3-6	CLUTCH SYSTEM	3-13
CRANKCASE BREATHER	3-6	SIDE STAND	3-14
SPARK PLUG	3-7	SUSPENSIONS	3-14
VALVE CLEARANCE	3-7	WHEELS	3-15
DECOMPRESSOR SYSTEM	3-8	STEERING HEAD BEARINGS	3-15
CARBURETOR IDLE SPEED	3-8	NUTS, BOLTS, FASTENERS	3-15
DRIVE CHAIN	3-9	CYLINDER COMPRESSION	3-16

SERVICE INFORMATION

GENERAL

- Brake fluid will damage painted, plastic, and rubber parts. Whenever handling brake fluid, protect the painted, plastic, and rubber parts by covering them with a rag. If fluid does get on these parts, wipe it off with a clean cloth.
- Engine oil level check page 2-2
- Engine oil change page 2-2
- Engine oil filter replacement .. page 2-3
- Oil screen cleaning page 2-4

MAINTENANCE

SPECIFICATIONS

« ENGINE »

Ignition timing Initial $8^{\circ} \pm 2^{\circ}$ BTDC at $1,200 \pm 100 \text{ min}^{-1}$ (rpm) (F mark)
 Full advance $29^{\circ} \pm 2^{\circ}$ BTDC at $5,000 \text{ min}^{-1}$ (rpm)

Spark plug

	NGK	ND
Standard	DPR8EA-9	X24EPR-U9
For cold climate (Below 5°C)	*DPR7EA-9	*X22EPR-U9
For extended high speed driving	DPR9EA-9	X27EPR-U9

* Except G-I, H types

Spark plug gap 0.8–0.9 mm (0.031–0.035 in)
 Valve clearance IN 0.10 mm (0.004 in)
 EX 0.12 mm (0.005 in)
 Idle speed $1,200 \pm 100 \text{ min}^{-1}$ (rpm)
 Cylinder compression $1,250 \pm 150 \text{ kPa}$ ($12.5 \pm 1.5 \text{ kg/cm}^2$, $175 \pm 21 \text{ psi}$)
 Starter decompressor lever free play 1–3 mm (1/16–1/8 in)

« CHASSIS »

Throttle grip free play 2–6 mm (1/8–1/4 in)
 Rear brake free play 20–30 mm (3/4–1-1/4 in)
 Clutch lever free play 10–20 mm (3/8–3/4 in)
 Drive chain slack 15–20 mm (5/8–1 in)

Tires

		Front	Rear
Tire size		100/90-18 56S	110/90-18 61S
Cold tire pressures kPa (kg/cm ² , psi)	Driver only	200 (2.00, 28)	200 (2.00, 28)
	Driver and one passenger	200 (2.00, 28)	250 (2.50, 36)
Tire brand TUBELESS ONLY BRIDGESTONE DUNLOP		G531 K625A	G532 K625

TORQUE VALUES

Rear axle nut 80–100 N·m (8.0–10.0 kg·m, 58–72 ft·lb)
 Fuel cup 3–5 N·m (0.3–0.5 kg·m, 2–4 ft·lb)
 Valve adjusting screw lock nut 23–27 N·m (2.3–2.7 kg·m, 17–20 ft·lb)

TOOLS

SPECIAL

Cylinder compression gauge attachment 07908–KK60000

COMMON

Wrench, 10 x 12 mm 07708–0030200
 Adjusting wrench A 07708–0030300

MAINTENANCE SCHEDULE

Perform the PRE-RIDE INSPECTION in the Owner's Manual at every maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY.

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓	ODOMETER READING [NOTE (3)]								Refer to page
			EVERY	1,000 km (600 mi)	6,000 km (3,750 mi)	12,000 km (7,500 mi)	18,000 km (11,250 mi)	24,000 km (15,000 mi)	30,000 km (18,750 mi)	36,000 km (22,500 mi)	
* FUEL LINE				I	I	I	I	I	I		3-4
* FUEL STRAINER SCREEN				C	C	C	C	C	C		3-4
* THROTTLE OPERATION				I	I	I	I	I	I		3-4
* CARBURETOR CHOKE				I	I	I	I	I	I		3-5
AIR CLEANER	(NOTE 1)					R				R	3-6
CRANKCASE BREATHER	(NOTE 2)			C	C	C	C	C	C		3-6
SPARK PLUG				I	R	I	R	I	R		3-7
* VALVE CLEARANCE				I	I	I	I	I	I		3-7
ENGINE OIL	YEAR R	R	EVERY 3,000 km (1,875 mi) R								2-2
ENGINE OIL FILTER	YEAR R	R	R	R	R	R	R	R	R		2-4
* DECOMPRESS SYSTEM				I	I	I	I	I	I		3-8
* CARBURETOR IDLE SPEED				I	I	I	I	I	I		3-8
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								3-9
BATTERY	MONTH I			I	I	I	I	I	I		3-10
BRAKE FLUID	MONTH I 2 YEARS *R			I	I	*R	I	I	*R		3-11
BRAKE SHOE/PAD WEAR				I	I	I	I	I	I		3-11
BRAKE SYSTEM				I	I	I	I	I	I		3-12
* BRAKE LIGHT SWITCH				I	I	I	I	I	I		3-13
* HEADLIGHT AIM				I	I	I	I	I	I		3-13
CLUTCH SYSTEM				I	I	I	I	I	I		3-13
SIDE STAND				I	I	I	I	I	I		3-14
* SUSPENSION				I	I	I	I	I	I		3-14
* NUT, BOLT, FASTENER				I	I	I	I	I	I		3-15
** WHEEL				I	I	I	I	I	I		3-15
** STEERING HEAD BEARING				I	I	I	I	I	I		3-15

* Should be serviced by an authorized HONDA dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to the official HONDA shop manual.

** In the interest of safety, we recommend these items be serviced ONLY by an authorized HONDA dealer.

- NOTES: (1) Service more frequently when riding in dusty areas.
 (2) Service more frequently when riding in rain or at full throttle.
 (3) For higher odometer reading, repeat at the frequency interval established here.

MAINTENANCE

FUEL LINE

Replace any cracked, damaged or leaking parts.

FUEL STRAINER SCREEN

Turn the fuel valve OFF.

Remove the fuel cup, O-ring and strainer screen, draining the gasoline into a suitable container.

WARNING

- Gasoline is flammable and is explosive under certain conditions.
- Do not smoke or allow flames or sparks near the equipment while draining fuel.



Wash the fuel cup and strainer screen in clean nonflammable or high flash point solvent.

Reinstall the strainer screen, aligning the index marks on the fuel valve body and the strainer screen. Install a new O-ring into the fuel valve body.

Reinstall the fuel cup, making sure the new O-ring is in place. Finger-tighten the cup, then torque it to specification.

TORQUE: 3–5 N·m (0.3–0.5 kg·m, 2–4 ft·lb)


After installing, turn the fuel valve ON and check that there are no fuel leaks.



THROTTLE OPERATION


Check for smooth throttle grip full opening and automatic full closing in all steering positions.

Make sure there is no deterioration, damage, or kinking in the throttle cables. Replace any damaged parts. Make sure that the throttle grip free play is 2–6 mm (1/8–1/4 in) at the throttle grip flange.



Throttle grip free play can be adjusted at either end of the throttle cable.

Minor adjustments are made with the upper throttle cable adjuster.




MAINTENANCE

Major adjustments are made with the lower adjuster.


Adjust free play by loosening the lock nut(s) and turning the adjuster. Tighten the lock nut(s).

Recheck throttle operation. Replace any damaged parts.



CARBURETOR CHOKE

Check that the choke lever moves smoothly. Lubricate the choke cable, if the operation is not smooth.




Loosen the choke valve nut and remove the choke valve from the carburetor.


Pull the choke lever on the handlebar all the way back to fully open position and check for smooth operation of the choke lever.

There should be no free play.

Lubricate the choke cable, if the operation is not smooth.



Check the valve seat on the choke valve for damage. Reinstall the choke valve in the reverse order of removal.




MAINTENANCE

AIR CLEANER


Remove the frame left side cover.
Remove the air cleaner cover screws and the cover.

(1) AIR CLEANER CASE COVER



Pull out the air cleaner element retainer.
Take out and discard the air cleaner element.
Install a new element.
Install the parts in the reverse order of removal.


(1) AIR CLEANER ELEMENT



Remove the plug from the air cleaner case drain tube to empty any deposits.
Install the drain plug.

NOTE

- Service more frequently when ridden in rain or at full throttle or if the deposit level can be seen in the transparent section of the drain tube.




CRANKCASE BREATHER

Remove the plug from the drain tube to empty any deposits.
Install the drain plug.

NOTE

- Service more frequently when ridden in rain or at full throttle or if the deposit level can be seen in the transparent section of the drain tube.



MAINTENANCE

SPARK PLUG

Disconnect the spark plug cap and remove the spark plug.

Visually inspect the spark plug. Discard it if the insulator is cracked or chipped.

Measure the spark plug gap with a wire-type feeler gauge. Adjust the gap by bending the side electrode carefully.

SPARK PLUG GAP: 0.8–0.9 mm (0.031–0.035 in)


RECOMMENDED SPARK PLUG:

DPR8EA-9 (NGK)

X24EPR-U9 (ND)

Make sure the sealing washer is in good condition.

Install the spark plug, tighten it by hand, then use a spark plug wrench for the final tightening.



VALVE CLEARANCE

NOTE

- Inspect and adjust valve clearance while the engine is cold (below 35°C/95°F). Make sure the decompressor valve lifters have some free play during this maintenance.

Remove the seat.



Turn the fuel valve OFF, disconnect the fuel line, and remove the tank.

Remove the crankshaft and timing mark hole caps.

Remove the valve adjuster covers.

Rotate the flywheel counterclockwise to align the "T" mark with the index notch on the left crankcase cover.

Make sure the piston is at TDC (Top Dead Center) on the compression stroke.



Check the clearance of all four valves by inserting a feeler gauge between the adjusting screw and the sub-rocker arm.


NOTE

- When checking the clearance, slide the feeler gauge from the inside out in the arrow direction.

VALVE CLEARANCES:

Intake 0.10 mm (0.004 in)

Exhaust 0.12 mm (0.005 in)



MAINTENANCE

Adjust by loosening the lock nut and turning the adjusting screw until there is a slight drag on the feeler gauge.

Hold the adjusting screw and tighten the lock nut.

TORQUE: 23–27 N·m (2.3–2.7 kg·m, 17–20 ft·lb)


TOOLS

Adjuster wrench A 07708–0030300

Wrench 10 x 12 mm 07708–0030200

Adjust the starter decompressor free play.

Install the removed parts in the reverse order of removal.




DECOMPRESSOR SYSTEM

NOTE

- Always adjust the decompressor cable after adjusting the valve clearance.

Remove the crankshaft and timing hole caps.

Rotate the flywheel counterclockwise to align the "T" mark with the index notch. Make sure that the piston is at TDC (Top Dead Center) on the compression stroke.



Measure kick starter decompressor cable free play at the tip of the decompressor valve lifter lever.

FREE PLAY: 1–3 mm (1/32–1/8 in)

Adjust by loosening the lock nut and turning the adjusting nut.


CAUTION

- Excessive free play causes hard starting. Insufficient free play may cause erratic engine idling and valve damage.

Tighten the lock nut.

Operate the kick starter and check the operation of the decompressor mechanism.

Recheck free play.



CARBURETOR IDLE SPEED

NOTE

- Inspect and adjust idle speed after all other engine adjustments are within specifications.
- The engine must be warm for accurate idle inspection and adjustment. Ten minutes of stop and go riding is sufficient.

Warm up the engine, shift to NEUTRAL, and hold the motorcycle upright. Connect a tachometer. Turn the throttle stop screw to obtain the specified idle speed.

IDLE SPEED: 1,200 ± 100 min⁻¹ (rpm)



MAINTENANCE

DRIVE CHAIN

Turn the ignition switch off, place the motorcycle on its center stand and shift the transmission into neutral.

Move the chain up and down with your fingers and measure the amount of slack. The slack should be adjusted to 15–25 mm (5/8–1 in) and never be allowed to exceed 50 mm (2 in).

DRIVE CHAIN SLACK: 15–25 mm (5/8–1 in)

To adjust the drive chain:

Loosen the rear axle nut.

Loosen the lock nut and turn the adjusting bolt on both the right and left chain adjusters an equal amount of turns to increase or decrease chain slack. Align the chain adjuster index marks with corresponding scale graduations on both sides of the swing arm.

Check the chain wear label when adjusting the chain.

If the red zone on the label aligns with the index mark after the chain has been adjusted to 15–25 mm (5/8–1 in) slack, the chain is excessively worn and must be replaced.

When the drive chain becomes extremely dirty, it should be removed and cleaned prior to lubrication.

Remove the rear wheel (Page 13-3) and the swing arm (Page 13-13).

Remove the drive sprocket cover and drive chain.

Clean the drive chain with kerosene and wipe dry.





CAUTION

- Do not use a steam cleaner, high pressure washers or solvents as these will damage the O-rings.

Lubricate the drive chain with SAE #80 or #90 gear oil.

CAUTION

- Do not use commercial aerosol chain lubricants. They contain solvents which could damage the O-rings.




MAINTENANCE

DRIVE AND DRIVEN SPROCKET:

Inspect the drive and driven sprocket teeth for excessive wear or damage. Replace if necessary.

NOTE

- Never install a new drive chain on worn sprockets or a worn chain on new sprockets.
- Both chain and sprockets must be in good condition, or the new replacement chain or sprockets will wear rapidly.




BATTERY

Remove the seat.

Inspect the battery fluid level.

If the fluid level nears the lower level, remove the battery holder bolt.

(1) BATTERY HOLDER BOLT




Remove the battery caps and add distilled water up to the upper level.

NOTE

- Add only distilled water. Tap water will shorten the service life of the battery.

(1) UPPER LEVEL



(1) LOWER LEVEL

WARNING

- The battery electrolyte contains sulphuric acid. Protect your eyes, skin, and clothing.
- If electrolyte gets in your eyes, flush them thoroughly with water and call a doctor.


BRAKE FLUID

Check the front brake fluid reservoir level.

If the level nears the lower level mark, remove the reservoir cover screws, cover and diaphragm.

(1) LOWER LEVEL

(2) RESERVOIR COVER





MAINTENANCE

Fill the reservoir with the DOT 3 or 4 BRAKE FLUID up to the upper level mark.

CAUTION

- Do not remove the cover until the handlebar had been turned so that the reservoir is level.
- Do not mix different types of fluid; they are not compatible with each other.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.


Refer to section 14 for brake bleeding procedures.
Install the diaphragm and cover, and tighten the screws.



BRAKE SHOE/PAD WEAR

Inspect the pads visually from the direction as indicated by arrow during all regular service intervals to determine the pad wear.


If the pads wear to the wear lines, both pads must be replaced.
Make sure there are no fluid leaks.



Check the brake oil hose and fitting for deterioration or cracks.

CAUTION


- Always replace the brake pads in pairs to assure even disc pressure.



MAINTENANCE

BRAKE SHOE INSPECTION

Replace the brake shoes if the arrow on the brake arm aligns with the reference mark "Δ" on the brake panel when the brake is applied.




BRAKE SYSTEM

BRAKE PEDAL HEIGHT

To adjust:

Loosen the lock nut and adjust the pedal height by turning the stopper bolt. Tighten the lock nut. Adjust the brake pedal free play.




BRAKE PEDAL FREE PLAY

NOTE


- Adjust the brake pedal free play after adjusting the brake pedal height.

Measure the brake pedal free play.

FREE PLAY: 20–30 mm (3/4–1-1/4 in)



If adjustment is necessary, turn the rear brake adjusting nut.



MAINTENANCE

BRAKE LIGHT SWITCH

NOTE

- The front brake light switch does not require adjustment.

Adjust the brake light switch so that the brake light will light when the brake pedal is depressed and the brake begins engagement.

Hold the switch body and turn the adjusting nut as required.

HEADLIGHT AIM

Adjust vertical aim by loosening both headlight case mounting bolts and tilting the headlight as required.

Align the punch marks on the headlight case and bracket.

Adjust horizontal aim by turning the adjusting screw on the headlight rim.

Turn the adjusting screw clockwise to direct the beam toward the left side of the rider.

NOTE

- Adjust the headlight beam as specified by local laws and regulations.

WARNING

- *An improperly adjusted headlight may blind oncoming drivers, or it may fail to light the road for a safe distance.*

CLUTCH SYSTEM

Measure the clutch free play at the lever end.

FREE PLAY: 10–20 mm (3/8–3/4 in)

Measure the brake pedal free play.





FREE PLAY: 20–30 mm (3/4–1 1/4 in)

Minor adjustments are made with the upper adjuster.

Pull the lever cover back, loosen the lock nut and turn the adjuster to obtain the specified free play.

Tighten the lock nut and install the cover.

Check clutch operation.




MAINTENANCE

Major adjustments are made with the lower adjuster.

Turn the upper adjuster in all the way and back out 1 turn.

Loosen the lock nut and turn the adjuster nut to obtain the specified free play.

Tighten the lock nuts and check clutch operation.




SIDE STAND

Check the rubber pad for deterioration or wear. Replace if any wear extends to the wear line as shown.

Check the side stand spring for damage and loss of tension, and the side stand assembly for freedom of movement and bending.

NOTE

- When replacing, use a rubber pad with the mark "above 259 lb only". Spring tension is correct if the measurements fall within 2–3 kg (4.4–6.6 lb) when pulling the side stand lower end with a spring scale.



SUSPENSIONS


FRONT

Check the action of the front forks by compressing them several times.

Check the entire fork assembly for signs of leaks, or damage. Replace any components which are unrepairable. Tighten all nuts and bolts to the specified torque value.

WARNING

- Do not ride a vehicle with faulty suspension. Loose, worn, or damaged suspension parts may affect stability and rider control.**




REAR

Place the vehicle on its center stand to raise the rear wheel.

Move the rear wheel sideways with force to see if the swing arm bushings are worn. Replace if excessively worn. Check the entire suspension assembly, being sure it is securely mounted and not damaged or distorted.

Tighten all nuts and bolts to the specified torque value.




MAINTENANCE

REAR SHOCK ABSORBER


Position I is for light loads and smooth road conditions. Position II to V progressively increase spring tension for a stiffer rear suspension and can be used when the motorcycle is more heavily loaded or operated on rough roads.

Be sure to adjust both shock absorbers to the same position. Adjustment can be made with the hook spanner.



SWING ARM

Pump grease into the swing arm pivot bushing through the grease fitting on the swing arm.



WHEELS

TIRE PRESSURE

NOTE

- Tire pressure should be checked when the tires are COLD.

		Front	Rear
Tire size		100/90-18 56S	110/90-18 61S
Cold tire pressures kPa (kg/cm ² , psi)	Driver only	200 (2.00, 28)	200 (2.00, 28)
	Driver and one passenger	200 (2.00, 28)	250 (2.50, 36)

Check the tires for cuts, imbedded nails, or other sharp objects.

STEERING HEAD BEARINGS


Raise the front wheel off the ground and check that the handlebar rotates freely. Check that the control cables do not interfere with handlebar rotation. If the handlebar moves unevenly, binds, or has vertical movement, adjust the steering head bearings by turning the steering head adjusting nut (page 12-21).

NUTS, BOLTS, FASTENERS


Tighten the bolts, nuts and fasteners at the intervals shown in the Maintenance Schedule (page 3-3).

Check that all chassis nuts and bolts are tightened to their correct torque values (page 1-5 and 6).

Check all cotter pins and safety clips.



(1) STEERING HEAD BEARINGS



MAINTENANCE

CYLINDER COMPRESSION

Warm up the engine.

Stop the engine and remove the spark plug. Remove the fuel tank if necessary.

Insert a compression gauge and push the choke lever in all the way. Turn the engine stop switch OFF.

Open the throttle grip fully. Crank the engine with the electric starter until the gauge stops rising.

Check the gauge reading.

TOOL

Cylinder compression gauge attachment:
07908-KK60000

NOTE

- Be sure compression is not leaking at the gauge connection.

COMPRESSION: $1,250 \pm 150$ kPa (12.5 ± 1.5 kg/cm²,
 172 ± 21 psi)

Low compression can be caused by:

Improper valve adjustment
Valve leakage
Leaking cylinder head gasket
Worn piston rings or cylinder


High compression can be caused by:

Carbon deposits in the combustion chamber or on the piston head.

(1) COMPRESSION GAUGE



FUEL SYSTEM
CIRCUIT D'ALIMENTATION
KRAFTSTOFFSYSTEM



4. FUEL SYSTEM

SERVICE INFORMATION	4-1	CARBURETOR INSTALLATION	4-8
TROUBLESHOOTING	4-2	PILOT SCREW ADJUSTMENT	4-9
CARBURETOR REMOVAL	4-3	FUEL TANK	4-10
CARBURETOR DISASSEMBLY	4-4	AIR CLEANER CASE	4-11
CARBURETOR ASSEMBLY	4-6		

SERVICE INFORMATION

GENERAL

- When disassembling fuel system parts, note the locations of the O-rings. Replace them with new ones on reassembly.
- The carburetor float bowls have a drain screws that can be loosened to drain residual gasoline.

SPECIFICATIONS

Fuel tank capacity	19 lit (5.0 US gal, 4.2 Imp gal)
Reserve capacity	3.3 lit (0.9 US gal, 0.7 Imp gal)
Carburetor	
Type	Constant Vacuum
Identification number	VE10A
Float level	18.5 mm (0.73 in)
Pilot screw opening	2-½ turns out
Main jet	#152
Slow jet	#48
Idle speed	1,200 ± 100 min ⁻¹ (rpm)
Throttle grip free play	2–6 mm (1/8–1/4 in)

TORQUE VALUE

Fuel tank mounting bolt	18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)
-------------------------	---------------------------------------

TOOLS

SPECIAL	
Pilot screw wrench	07908–4220201

COMMON	
Float level gauge	07401–0010000

FUEL SYSTEM

TROUBLESHOOTING

Engine cranks but won't start

- No fuel in tank
- No fuel to carburetor
- Too much fuel getting to cylinder
- No spark at plug (ignition malfunction)
- Air cleaner clogged

Engine idles roughly, stalls, or runs poorly

- Idle speed incorrect
- Ignition malfunction
- Rich mixture
- Lean mixture
- Air cleaner dirty
- Insulator leaks

Lean mixture

- Carburetor fuel jet clogged
- Fuel filler cap vent hole blocked
- Fuel filter clogged
- Fuel line kinked or restricted
- Float valve faulty
- Float level too low
- Intake air leak

Rich mixture

- Starter valve stuck open or damage
- Float valve faulty
- Float level too high
- Carburetor air jet clogged
- Air cleaner dirty

FUEL SYSTEM

CARBURETOR REMOVAL

Remove the seat and fuel tank (page 4-10).
Loosen the drain screw and drain the fuel into a suitable container.

WARNING





Keep gasoline away from frames or sparks. Wipe up spilled gasoline at once.

Loosen the carburetor tube bands.
Disconnect the throttle cables and choke valve from the carburetor.

Remove the three bolts attaching the intake tube to the cylinder head.

Remove the insulator with O-rings and the intake tube.


Pull the carburetor away from the engine through the lift side.




CARBURETOR DISASSEMBLY

VACUUM CHAMBER


Remove the four vacuum chamber cover screws and cover.
Remove the compression spring and diaphragm/vacuum piston.
Inspect the vacuum piston and diaphragm for wear, scratches or other damage.
Make sure the piston moves up and down freely in the chamber.



Push the needle holder in and turn it 60 degrees with a 8 mm socket. Then remove the needle holder, spring and needle from the piston.




Inspect the needle for excessive wear at tip and for bending, or other damage.
Check the diaphragm for torn or deterioration.



AIR CUT-OFF VALVE


Remove the two screws attaching the air cut-off valve cover and the cover.
Remove the spring and diaphragm.




FUEL SYSTEM

FLOAT CHAMBER


Remove the four float chamber screws and the float chamber.




Remove the float pin, float and float valve.



Inspect the float valve for grooves and nicks.




Remove the main jet, slow jet, jet needle holder, needle jet and pilot screw.




FUEL SYSTEM

Blown open all passages with compressed air before installing jets and valve.




CARBURETOR ASSEMBLY



VACUUM CHAMBER

Install the vacuum piston/diaphragm as follows:
 Install the needle onto the piston/diaphragm, and secure with the spring and needle holder.
 Insert the vacuum piston into the carburetor and aligning the tab on the diaphragm with the carburetor groove.
 Install the spring and vacuum chamber cover, aligning its cavity with the tab on the diaphragm, and secure with the screws.





FUEL SYSTEM

FLOAT CHAMBER

Assemble the float chamber components in the reverse order of disassembly.

Install the float with the float valve onto the carburetor.
Inspect the operation of the float valve.




FLOAT LEVEL INSPECTION

Measure the float level with the float tang just contacting the float valve.

SPECIFICATION: 18.5 mm (0.73 in)


TOOL:

Float level gauge 07401-0010000



Install the float chamber and tighten the screws.

(1) FLOAT CHAMBER




FUEL SYSTEM

AIR CUT-OFF VALVE


Check the diaphragm for pin hole or other damage.

Assemble the air cut-off valve in the reverse order of disassembly.



Install the air cut-off valve tube.

Install the carburetor tubes.




CARBURETOR INSTALLATION

Installation is essentially the reverse order of removal.

CAUTION

- When installing the insulator onto the cylinder head, be careful not to damage the O-rings.


Align the tang on the carburetor with the groove on the intake tube.



Install the choke valve into the carburetor securely.

Tighten the choke valve nut.

Install the throttle cables.



NOTE

- Route the throttle and choke cable properly (page 1-11).

Perform the following inspection and adjustments.

- Throttle operation (page 3-4).
- Idle speed (page 3-8).

FUEL SYSTEM

PILOT SCREW ADJUSTMENT

TOOL:

Pilot screw wrench 07908-4220201

NOTE

- The pilot screw is factory pre-set and no adjustment is necessary unless the pilot screw is replaced (page 4-4).

1. Turn the pilot screw clockwise until it seats lightly and back it out to the specification given. This is an initial seating prior to the final pilot screw adjustment.

INITIAL OPENING: 2-½ Turn out


CAUTION:

- Damage to the pilot screw seat will occur if the pilot screw is tightened against the seat.

2. Warm up the engine to operating temperature. Stop and go driving for 10 minutes is sufficient.
3. Attach a tachometer according to the manufacturer's instructions.
4. Adjust the idle speed with the throttle stop screw.

IDLE SPEED: 1,200 ± 100 min⁻¹ (rpm)

5. Turn the pilot screw in or out slowly to obtain the highest engine speed.
6. Repeat the steps 4 and 5.
7. Readjust the idle speed with throttle stop screw.



FUEL SYSTEM

FUEL TANK

WARNING

- Keep gasoline away from flames or sparks. Wipe up spilled gasoline at once.



REMOVAL

Remove the seat and side covers.

Turn the fuel valve OFF.

Place the clean container under the fuel tube and disconnect the fuel tube from the fuel valve.

Remove the fuel tank mounting bolt and fuel tank.



INSTALLATION

Install the fuel tank with the mounting bolt.


TORQUE: 18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)

Connect the fuel tube.

Install the seat and side covers.

NOTE

- After assembling, make sure there are no fuel leaks.
- Do not overtighten the fuel valve screws.



AIR CLEANER CASE

REMOVAL




Remove the following:

- seat, side covers and fuel tank.
- battery and battery holder (page 2-5).
- rear wheel (page 13-3).
- rear shock absorber mounting nuts.
- rear fender

- alternator couplers from the air cleaner case.
- air cleaner case mounting bolts.

- air cleaner element and breather separator mounting bolt.
- oil tank mounting bolt from the right.
- oil tank mounting bolt and the spacer from the left side.


- air cleaner case from the rear.




FUEL SYSTEM

INSTALLATION

Install the air cleaner in the reverse order of removal.



ENGINE REMOVAL/INSTALLATION
DEPOSE/REPOSE DU MOTEUR
AUSBAU/EINBAU DES MOTORS



5. ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION ENGINE REMOVAL

5-1
5-2

ENGINE INSTALLATION

5-4

SERVICE INFORMATION

GENERAL

- A jack or adjustable support is required to maneuver the engine.
- Parts requiring engine removal for servicing:

Cylinder head	Section 6
Cylinder	Section 7
Crankshaft	Section 11
Balancer	Section 11
Transmission	Section 10
Shift linkage	Section 10

SPECIFICATIONS

Engine weight	50 kg (110 lb)
Oil capacity	2.3 lit (2.4 US qt, 2.0 Imp qt) at engine assembly 1.6 lit (1.7 US qt, 1.4 Imp qt) at oil change

TORQUE VALUES

Engine rear hanger bolt: 10 mm	80–100 N·m (8.0–10.0 kg·m, 58–72 ft·lb)
Engine hanger and bracket bolts: 8 mm	24–30 N·m (2.4–3.0 kg·m, 17–22 ft·lb)
10 mm	35–45 N·m (3.5–4.5 kg·m, 25–33 ft·lb)
Exhaust pipe clamp bolt	15–25 N·m (1.5–2.5 kg·m, 11–18 ft·lb)
Exhaust pipe joint nut	8–12 N·m (0.8–1.2 kg·m, 6–9 ft·lb)
Exhaust muffler mount bolt	20–30 N·m (2.0–3.0 kg·m, 15–22 ft·lb)
Rear axle nut	80–100 N·m (8.0–10.0 kg·m, 58–72 ft·lb)

5

ENGINE REMOVAL/INSTALLATION

ENGINE REMOVAL

Remove the seat and disconnect the negative cable at the battery.

Turn the fuel valve OFF and remove the fuel tank (page 4-10).

Remove the exhaust pipe (page 15-2).

Drain the oil from the engine and oil tank (page 2-2).

GENERALITES

- Pour déposer et reposer le moteur, consultez le chapitre 5.
- Pour la maintenance du moteur, il est recommandé d'utiliser des produits de qualité.

- Pièces demandant le démontage du moteur pour l'entretien:

Culasse Chapitre 5

Cylindres Chapitre 7

Vilebrequin Chapitre 11

Arbre à cames Chapitre 11

Disconnect the starter motor cable and engine ground cable.

Disconnect the alternator couplers and wire. Chapitre 10

CARACTERISTIQUES

Poids du moteur 50 kg

Capacité de l'huile 2,5 l (à l'encochure de l'huile)

1,5 l (à l'encochure de l'huile)

COUPLES DE SERRAGE

Bouton de suspension arrière du moteur (Image 6)

10 mm 80 à 100 N·m (6,0 à 10,5 kgf·m)

Bouton de suspension et des supports du moteur (Image 7)

8 mm 24 à 30 N·m (2,4 à 3,0 kgf·m)

10 mm 33 à 45 N·m (3,3 à 4,5 kgf·m)

Ecrou de bécasse de tuyau d'échappement 15 à 25 N·m (1,5 à 2,5 kgf·m)


Ecrou de manchon de tuyau d'échappement 8 à 12 N·m (0,8 à 1,2 kgf·m)

Bouton de montage de vilebrequin 20 à 30 N·m (2,0 à 3,0 kgf·m)

Remove the carburetor (page 4-3).


Disconnect the crankcase breather tube from the crankcase.

(1) BATTERY NEGATIVE CABLE



(1) STARTER MOTOR CABLE

(2) GROUND CABLE



(3) ALTERNATOR COUPLERS AND WIRE

(1) CARBURETOR

(2) CRANKCASE BREATHER TUBE



(1) CLUTCH CABLE CLAMP BOLT


(2) DRIVE SPROCKET COVER




(3) GEARSHIFT PEDAL

ENGINE REMOVAL/INSTALLATION


Loosen the axle nut, drive chain adjuster lock nuts and adjusting bolts to loosen the drive chain.




Remove the drive sprocket bolts and remove the drive sprocket with the drive chain.



Disconnect the oil tank breather tube from the cylinder head. Remove the ignition coil with the spark plug wire. Disconnect the pulse generator wire coupler.



Remove the kick starter pedal. Remove the oil hose clamp from the right crankcase cover. Disconnect the oil hoses from the engine by removing the oil hose attaching bolts.



ENGINE REMOVAL/INSTALLATION

Place a jack or padded block under the engine.
Remove the (1) upper, (2) front and (3) rear brackets.
Remove the (4) front and (5) rear engine hanger bolts.

NOTE

- Note the direction of the engine mounting bolts.

Lower the jack and remove the engine from the left side.

ENGINE INSTALLATION

Install the engine from the left side.
Use a jack or other adjustable support to carefully maneuver the engine into place.

CAUTION

- Use the correct bolt and collars in their proper positions.

Install the bracket, collars, bolts and nuts.

Tighten all bolts to the proper torque specifications.

TORQUE:





Engine rear hanger bolt:

10 mm: 80–100 N·m (8.0–10.0 kg·m, 58–72 ft·lb)

Engine hanger and bracket bolts:

8 mm: 24–30 N·m (2.4–3.0 kg·m, 17–22 ft·lb)

10 mm: 35–45 N·m (3.5–4.5 kg·m, 25–33 ft·lb)



ENGINE REMOVAL/INSTALLATION

Install the drive sprocket as shown.

NOTE

Install the drive sprocket bolts and tighten them.

Install the drive sprocket cover.

Install the gearshift pedal, aligning the punch marks on the gearshift shaft and pedal.




Install the removed parts in the reverse order of removal.

Route the cables and wires properly (page 1-11).


After installing the engine, perform the following inspections and adjustments:

- engine oil level (page 2-2).
- throttle grip free play (page 3-4).
- drive chain free play (page 3-9).
- clutch cable free play (page 3-13).
- rear brake pedal free play (page 3-12).

Check all electrical equipment for proper operation and exhaust pipe for leaking.



CYLINDER HEAD/VALVES
CULASSE/SOUPAPES
ZYLINDERKOPF/VENTILE



6

6. CYLINDER HEAD/VALVES

SERVICE INFORMATION	6-1	VALVE SEAT INSPECTION AND REFACING	6-12
TROUBLESHOOTING	6-3	CYLINDER HEAD ASSEMBLY	6-15
CYLINDER HEAD COVER REMOVAL	6-4	CYLINDER HEAD INSTALLATION	6-16
CYLINDER HEAD COVER DISASSEMBLY	6-5	CAMSHAFT INSTALLATION	6-17
CAMSHAFT REMOVAL	6-6	CYLINDER HEAD COVER ASSEMBLY	6-18
CYLINDER HEAD REMOVAL	6-7	CYLINDER HEAD COVER INSTALLATION	6-19
CYLINDER HEAD DISASSEMBLY	6-8		

SERVICE INFORMATION

GENERAL

- This section covers maintenance of the cylinder head, valves, camshaft and rocker arms. All these operations can be accomplished with the engine installed in the frame.
- Lubricate the camshaft journal and cam lobes with molybdenum disulfide grease for initial lubrication.
- Pour clean engine oil into the oil pockets in the cylinder head to lubricate the cams before installing the cylinder head cover.

SPECIFICATIONS

ITEM			STANDARD	SERVICE LIMIT
Compression			1,250±150 kPa (12.5±1.5 kg/cm ² , 172±21 psi)	—————
Camshaft	Cam lobe height	IN	34.023 mm (1.3395 in)	33.85 mm (1.333 in)
		EX	33.976 mm (1.3376 in)	33.81 mm (1.331 in)
	Runout		—————	0.04 mm (0.002 in)
Sub-rocker arm I.D.		IN	8.000—8.015 mm (0.3150—0.3156 in)	8.05 mm (0.317 in)
		EX	7.000—7.015 mm (0.2756—0.2762 in)	7.05 mm (0.278 in)
Sub-rocker arm shaft O.D.		IN	7.972—7.987 mm (0.3139—0.3144 in)	7.92 mm (0.312 in)
		EX	6.972—6.987 mm (0.2745—0.2751 in)	6.92 mm (0.272 in)
Sub-rocker arm-to-shaft clearance			0.013—0.043 mm (0.0005—0.0017 in)	0.08 mm (0.003 in)
Rocker arm I.D.			11.50—11.518 mm (0.4528—0.4535 in)	11.55 mm (0.455 in)
Rocker arm shaft O.D.			11.466—11.484mm(0.4514—0.4521 in)	11.41 mm (0.449 in)
Rocker arm shaft-to-arm clearance			0.016—0.052 mm (0.0006—0.0020 in)	0.14 mm (0.006 in)
Valve spring	Free length	Inner	34.08 mm (1.342 in)	33.1 mm (1.30 in)
		Outer	38.14 mm (1.502 in)	37.1 mm (1.46 in)
	Preload/length	Inner	6.75±0.54 kg/28 mm (14.9±1.2 lb/1.10 in)	—————
		Outer	15.4±1.2 kg/31.5 mm (34.0±2.6 lb/1.24 in)	—————

ITEM			STANDARD	SERVICE LIMIT
Valve	Stem O.D.	IN	6.575–6.590 mm (0.2589–0.2594 in)	6.56 mm (0.258 in)
		EX	6.560–6.575 mm (0.2583–0.2589 in)	6.55 mm (0.258 in)
	Guide I.D.	IN	6.600–6.615 mm (0.2598–0.2604 in)	6.63 mm (0.261 in)
		EX	6.600–6.615 mm (0.2598–0.2604 in)	6.63 mm (0.261 in)
	Stem-to-guide clearance	IN	0.010–0.040 mm (0.0004–0.0016 in)	0.065 mm (0.0026 in)
		EX	0.025–0.055 mm (0.0010–0.0022 in)	0.080 mm (0.0031 in)
Cylinder head	Warpage			0.10 mm (0.004 in)
	Valve seat width	IN/EX	1.1–1.2 mm (0.04–0.05 in)	1.8 mm (0.07 in)

TORQUE VALUES

Cylinder head bolt		28–32 N·m (2.8–3.2 kg-m, 20–23 ft-lb)
Cam sprocket bolt		18–22 N·m (1.8–2.2 kg-m, 13–16 ft-lb)
Cylinder head cover		
6 mm flange bolt		8–12 N·m (0.8–1.2 kg-m, 6–9 ft-lb)
with 8 mm head		
Rocker arm shaft		25–30 N·m (2.5–3.0 kg-m, 18–22 ft-lb)
Sub-rocker arm shaft IN		25–30 N·m (3.0–2.0 kg-m, 18–22 ft-lb)
Sub-rocker arm shaft EX		20–25 N·m (2.0–2.5 kg-m, 15–18 ft-lb)
Valve adjuster lock nut		23–27 N·m (2.3–2.7 kg-m, 17–20 ft-lb)
Engine upper bracket bolt	8 mm	24–30 N·m (2.4–3.0 kg-m, 17–22 ft-lb)
	10 mm	35–45 N·m (3.5–4.5 kg-m, 25–33 ft-lb)

TOOLS

SPECIAL

Valve guide reamer	07984–551000
Tensioner setting holder	07973–MG30002
Knock pin puller set	07936–MA70000
Sliding shaft	07936–MA70100
Remover weight	07741–0010201

COMMON

Valve guide remover, 6.6 mm	07742–0010200
Valve spring compressor	07757–0010000

Valve seat cutter		
Valve seat cutter	35 mm	07780–0010400
Valve seat cutter	40 mm	07780–0010500
Valve seat cutter	35 mm	07780–0012300
Valve seat cutter	38.5 mm	00780–0012400
Valve seat cutter	37.5 mm	00780–0014100
Cutter holder	6.6 mm	00781–0010201

TROUBLESHOOTING

Engine top-end problems are usually performance-related and can usually be diagnosed by a compression test. Engine noises can usually be traced to the top-end with a sounding rod or stethoscope.

Low compression

- Valve
 - Incorrect valve adjustment
 - Burned or bend valves
 - Incorrect valve timing
 - Broken valve spring
- Cylinder head
 - Leaking or damaged head gasket
 - Warped or cracked cylinder head

High compression

- Excessive carbon build-up on piston crown or combustion chamber

Excessive noise

- Incorrect valve adjustment
- Sticking valve or broken valve spring
- Damaged or worn rocker arm or camshaft
- Loose or worn cam chain
- Worn or damaged cam chain tensioner
- Worn cam sprocket teeth

Poor idling

- Compression too low
- Decompressor out of adjustment

Kick starting difficult

- Decompressor out of adjustment

Schwingscheiben A.D.		EINLASS	8,02-8,015 mm	30,2 mm
Spiel zwischen Schwingscheibe und Achse		000000-0000	7,42-7,41 mm	30,2 mm
Klopfstange I.D.		000000-0000	7,42-7,41 mm	30,2 mm
Klopfstange A.D.		000000-0000	7,42-7,41 mm	30,2 mm
Spiel zwischen K. ehebel und Achse		000000-0000	7,42-7,41 mm	30,2 mm
Ventiltrieb	Einlass	Interieur	34,26 mm	32,1 mm
		Außen	34,14 mm	32,1 mm
	Ventiltrieb/Länge	Interieur	37,65-37,64 mm	37,1 mm
		Außen	37,65-37,64 mm	37,1 mm

CYLINDER HEAD COVER REMOVAL

NOTE

- Position the camshaft so that the cam lobes face down by aligning the T mark on the flywheel with the index notch on the left crankcase cover.

Remove the fuel tank (page 4-10).

Remove the decompressor holder attaching bolts and disconnect the cable from the valve lifter lever.

Disconnect the oil tank breather tube at cylinder head.





Remove the ignition coil with spark plug wires.

Remove the oil pipe bolt, sealing washers from the cylinder head.

Remove the engine upper brackets by removing the 8 mm bolts and 10 mm bolt.

Remove the cylinder head cover bolts and cover.

Remove the dowel pins and head cover gasket.



CYLINDER HEAD COVER DISASSEMBLY

Remove the dowel pin using the special tools.

TOOLS:

Knock pin puller set	07936-MA70000
Sliding shaft	07936-MA70100
Remover weight	07741-0010201


Pull out the valve lifter lever and remove the spring and spring guide plate.

Loosen the sub-rocker arm shafts and rocker arm shafts.

Remove the sub-rocker arm shafts, sealing washers, wave washers and sub-rocker arms.


Remove the rocker arm shafts, copper washers and rocker arms.

(1) DOWEL PIN




(1) VALVE LIFTER LEVER


(2) SPRING GUIDE PLATE



(1) SUB-ROCKER ARM SHAFTS



(1) SUB-ROCKER ARMS/WAVE WASHERS



CYLINDER HEAD/VALVES

SUB-ROCKER ARM AND SHAFT INSPECTION

Inspect the sub-rocker arms and shafts for wear or damage.

Measure the sub-rocker arm I.D.

SERVICE LIMIT: IN 8.05 mm (0.317 in)
EX 7.05 mm (0.228 in)

Measure the sub-rocker arm shaft O.D.

SERVICE LIMIT: IN 7.92 mm (0.312 in)
EX 6.92 mm (0.272 in)

Calculate the sub-rocker arm-to-shaft clearance.

SERVICE LIMIT: 0.08 mm (0.003 in)

ROCKER ARM AND SHAFT INSPECTION

Inspect the rocker arms for damage or wear.

NOTE

- If any rocker arm require servicing or replacement, inspect the cam lobes for scoring, chipping or flat spots.

Measure the I.D. of each rocker arm.

SERVICE LIMIT: 11.55 mm (0.455 in)

Inspect the rocker arm shafts for wear or damage.
Measure the O.D.

SERVICE LIMIT: 11.41 mm (0.449 in)

Calculate the rocker arm-to-shaft clearance.

SERVICE LIMIT: 0.14 mm (0.006 in)

CAMSHAFT REMOVAL

Turn the crankshaft and remove the cam sprocket bolts.

CAUTION





- *Be careful not to drop the bolts into the crankcase.*

Set up the tensioner setting holder on the tensioner lifter to loosen the cam chain as shown.

TOOL:


Tensioner setting holder 07973-MG30002

Pull the cam sprocket off the camshaft flange shoulder and remove the cam chain from the cam sprocket.
Remove the camshaft and sprocket.




CYLINDER HEAD/VALVES

Remove the camshaft ball bearings from the camshaft.



CAMSHAFT BEARING INSPECTION

Check each camshaft bearing for play or damage.
Replace a bearing with a new one if it is noisy or has excessive play.



Check each cam lobe for wear or damage.
Measure the cam lobe height.


SERVICE LIMIT: IN 33.85 mm (1.333 in)
EX 33.81 mm (1.331 in)

CAMSHAFT REMOVAL

CYLINDER HEAD REMOVAL


Remove the following.

- cylinder head cover (page 6-4).
- camshaft (page 6-6).
- carburetor (page 4-3).
- exhaust pipe (page 15-2).



CYLINDER HEAD/VALVES

Remove the oil pipe bracket bolt, oil pipe bolt and sealing washers at the right crankcase cover (page 8-3).
Remove the oil pipe from the engine.
Remove the two cylinder head nuts.



Remove the six cylinder head bolts.


NOTE

- Loosen the bolts in a crisscross pattern in two or more steps.


Remove the cylinder head.

CAUTION

- Be careful not to damage the cylinder head mating surfaces.



Remove the cylinder head gasket and dowel pins.




CYLINDER HEAD DISASSEMBLY

Remove the dowel pin and tensioner setting holder.


TOOL:

Tensioner setting holder 07973—MG30002




CYLINDER HEAD/VALVES


Pull out the tensioner shaft by turning it clockwise and remove the tensioner lifter.




Remove the spring from the tensioner lifter.



Insert the tensioner shaft into the tensioner lifter and inspect the tensioner lifter by turning the shaft. The tensioner shaft should turn clockwise freely and should not turn counterclockwise.



Check the tensioner lifter and tensioner shaft for excessive or abnormal wear or damage.



CYLINDER HEAD/VALVES

Remove the tensioner lifter (page 6-8).
Remove the valve spring cotters, retainers, springs, and valves with a valve spring compressor.

TOOL:

Valve spring compressor 07757-0010000

CAUTION



- To prevent loss of tension, do not compress the valve springs more than necessary to remove the cotters.

NOTE

- Mark all parts to ensure that they are reassembled in their original locations.

Remove the spring seats and valve stem seals.


Remove the carbon deposits from the combustion chamber.
Carefully clean any gasket material from the cylinder head.



CYLINDER HEAD INSPECTION

Check the spark plug hole and valve areas for cracks.
Check the cylinder head diagonally two ways for warpage with a straight edge and a feeler gauge.


SERVICE LIMIT: 0.1 mm (0.004 in)



VALVE SPRING INSPECTION

Measure the free length of the inner and outer valve springs.

SERVICE LIMIT: INNER: 33.1 mm (1.30 in)
OUTER: 37.1 mm (1.46 in)



CYLINDER HEAD/VALVES

VALVE/VALVE GUIDE INSPECTION

Inspect each valve for trueness, burning, scratches or abnormal stem wear.

Check the valve movement in the guide. Measure and record each valve stem O.D.

SERVICE LIMIT: IN 6.56 mm (0.258 in)
EX 6.55 mm (0.258 in)

Measure and record each valve guide I.D. using a ball gauge or inside micrometer.

NOTE

- Ream the guides to remove the carbon buildup before checking the valve guide I.D.

SERVICE LIMIT: IN 6.63 mm (0.261 in)
EX 6.63 mm (0.261 in)

Calculate the stem-to-guide clearance.

VALVE STEM-TO-GUIDE CLEARANCE

SERVICE LIMITS: IN 0.065 mm (0.0026 in)
EX 0.080 mm (0.0031 in)

NOTE

- If the stem-to-guide clearance exceeds the service limit, determine if a new guide with standard dimensions would bring the clearance within tolerance. If so, replace guides as necessary and ream to fit.

If stem-to-guide clearance still exceeds the service limit when new guides are installed, replace the valves.

NOTE

- Reface valve seats whenever new valve guides are installed.

VALVE GUIDE REPLACEMENT




Support the cylinder head and drive out the guide from the combustion chamber side.

CAUTION

- Do not damage the cylinder head during guide removal.

TOOL:

Valve guide remover 07742-0010200



CYLINDER HEAD/VALVES


Apply molybdenum disulfide grease to the I.D. of a new valve guide.

Install the new valve guide from the top of the head, then check that it wasn't damaged during installation.

TOOL:

Valve guide remover/driver 07742-0010200

(1) VALVE GUIDE REMOVER/DRIVER (2) O-RING




Ream the new valve guides after installation.

TOOL:

Valve guide reamer 07984-551000

(1) VALVE GUIDE REAMER



NOTE

- Use cutting oil on the reamer during this operation. Rotate the reamer while inserting and removing it.


Reface the valve seats.

Clean the cylinder head thoroughly to remove any metal particles.

VALVE SEAT INSPECTION AND REFACING

Clean all intake and exhaust valves thoroughly to remove carbon deposits.

Apply a light coating of Prussian Blue to each valve face. Lap each valve and seat using a rubber hose or other hand-lapping tool.



CAUTION

Valves cannot be ground. If the valve face is burned or badly worn or it contacts the seat unevenly, replace the valve.

Inspect the width of each valve seat.


STANDARD: 1.1–1.2 mm (0.04–0.05 in)

SERVICE LIMIT: 1.8 mm (0.07 in)

If the seat is too wide, too narrow, or has low spots, the seat must be refinished for good sealing.

NOTE

- Follow the refacer manufacturer's operating instructions.






CYLINDER HEAD/VALVES

VALVE SEAT CUTTERS

(1) IN: 07780-0012400
EX: 07780-0012300

(2) IN: 07780-0010500
EX: 07780-0010400

(3) IN: 07780-0014100
EX: 07780-0014100



VALVE SEAT GRINDING

using a 45 degree cutter, remove any roughness or irregularities from the seat.


NOTE

- Reface the seat with a 45 degree cutter when the valve guide is replace.


TOOL:

Cutter holder 6.6 mm 07781-0010201


(1) VALVE SEAT CUTTER



Using a 32 degree cutter, remove 1/4 of the existing valve seat material.



Use a 60 degree cutter and remove the bottom 1/4 of the old seat.




CYLINDER HEAD/VALVES

Use a 45 degree finish cutter and cut the seat to the proper width.

NOTE


- Make sure that all pitting and irregularities are removed. Refinish if necessary.




NOTE

- The location of the valve seat in relation to the valve face is very important for good sealing and maximum valve service.


Apply a thin coating of Prussian Blue to the the valve seat. Press the valve through the valve guide and onto the seat to make a clear pattern. Remove to inspect the valve. If the contact area is too high on the valve, the seat must be lowered using a 32 degree flat cutter. Refinish the seat to the correct width using a 45 degree finish cutter.



If the contact area is too low on the valve, the seat must be raised using a 60 degree inner cutter. Refinish the seat to correct width, using a 45 degree finish cutter.



After cutting the seat, apply lapping compound to the valve face, and lap the valve using light pressure. After lapping, wash all residual compound off the cylinder head, valve, and valve guide.



CYLINDER HEAD/VALVES


CYLINDER HEAD ASSEMBLY

Lubricate each valve stem with oil, then insert the valves into the valve guides.

Install new valve stem seal.

Install the valve spring seat, springs and retainers.

The springs tightly wound coils should face in toward the combustion chamber.




Compress the valve springs using the valve spring compressor, then install the valve cotters.

CAUTION

- To prevent loss of tension, do not compress the valve spring more than necessary.

TOOL:


Valve spring compressor 07757-0010000



Tap the valve stems gently with a plastic hammer to firmly seat the cotters.


CAUTION

- Support the cylinder head above the working bench surface to prevent possible valve damage.



Insert the tensioner shaft into the tensioner lifter and inspect the tensioner lifter by turning the shaft.


The tensioner shaft should turn clockwise freely and should not turn counterclockwise.



CYLINDER HEAD/VALVES

Install the spring on the tensioner lifter as shown.

(1) TENSIONER LIFTER




Install the tensioner lifter on the cylinder head.

Apply engine oil to a new O-ring and install it in the groove of the tensioner shaft.

Insert the tensioner shaft into the tensioner lifter through the cylinder head.

(1) TENSIONER LIFTER

(2) O-RING




(3) TENSIONER SHAFT

Set up the special tool on the tensioner lifter, and align the hole in the tensioner shaft with the hole in the cylinder head while turning the tensioner shaft clockwise and insert the dowel pin.

TOOL:

Tensioner setting holder 07973—MG30002

(1) DOWEL PIN




(2) TENSIONER SHAFT

CYLINDER HEAD INSTALLATION

Clean any gasket material from the cylinder surface.
Install the dowel pins and a new gasket.

(1) GASKET

(2) DOWEL PINS



CYLINDER HEAD/VALVES

Install the cylinder head.

Install the dowel pins onto the cylinder head.

Apply engine oil to the cylinder head bolts and washer, and tighten the cylinder head bolts in a crisscross pattern in two or more steps.



TORQUE: 28–32 N·m (2.8–3.2 kg·m, 20–23 ft·lb)

Tighten the cylinder head nuts.

Install the oil pipe, bracket bolt, oil bolt and sealing washers.


Install the following:

- carburetor (page 4-3).
- exhaust pipe (page 15-2).



CAMSHAFT INSTALLATION


Apply engine oil to the camshaft bearings and install them onto the camshaft; the seal bearing goes on the sprocket side with the seal facing out.



Place the cam sprocket inside the cam chain with its dished face facing the right side.

Install the camshaft through the sprocket and cam chain.


Turn the crankshaft and align the T mark on the flywheel with the index notch on the left crankcase cover.



CYLINDER HEAD/VALVES

Align the timing marks on the cam sprocket with the upper surface of the cylinder head and install the cam chain over the sprocket without rotating the sprocket.

Position the cam sprocket onto the shoulder of the camshaft.




Install the sprocket bolt and tighten it.
Turn the crankshaft and install the other sprocket bolt.

NOTE

Align the T mark with the index notch and make sure that the timing marks on the sprocket align with the upper surface of the cylinder head.


Tighten the sprocket bolts to the specified torque.

TORQUE: 18–22 N·m (1.8–2.2 kg·m, 13–16 ft·lb)




CYLINDER HEAD COVER ASSEMBLY

Install the rocker arms on the cover.
Install sub-rocker arms "A", "B" and "KE5", and the wave washers.



Apply engine oil to the rocker arm shafts and install the rocker arm shafts and copper washers.

Apply engine oil to the sub-rocker arm shafts and install the sub-rocker arm shafts and sealing washers.



CYLINDER HEAD/VALVES

Tighten the rocker arm shafts to the specified torque.

TORQUE: 25–30 N·m (2.5–3.0 kg·m, 18–22 ft·lb)

Tighten the sub-rocker arm shafts to the specified torque.

**TORQUE: IN 25–30 N·m (2.5–3.0 kg·m, 18–22 ft·lb)
EX 20–25 N·m (2.0–2.5 kg·m, 15–18 ft·lb)**

Apply grease to the lifter lever dowel pin to prevent it from falling into the crankcase when installing the cylinder head cover.


Align the cut-out of the lever shaft with the hole in the cylinder head cover and insert the dowel pin.

Install the spring and spring guide as shown.


CYLINDER HEAD COVER INSTALLATION

Clean the cylinder head mating surface of the cylinder head cover.


- (1) SUB-ROCKER ARM SHAFTS/INTAKE
(2) RUB-ROCKER ARM SHAFT/EXHAUST




- (3) ROCKER ARM SHAFTS



- (1) SPRING GUIDE




- (2) SPRING




CYLINDER HEAD/VALVES

Pour clean engine oil into the oil pockets in the cylinder head so that the cam lobes are completely submerged.



Install a new cylinder head cover gasket and dowel pins.

Position the camshaft so that both cam lobes face down by rotating the crankshaft.



Loosen all the valve adjusting screws and install the cylinder head cover.

Tighten the cylinder head cover bolts to the specified torque.


TORQUE:

8 mm bolt:	20–26 N·m (2.0–2.6 kg-m, 15–19 ft-lb)
6 mm bolt:	10–14 N·m (1.0–1.4 kg-m, 7–10 ft-lb)
6 mm flange bolt with 8mm head:	8–12 N·m (0.8–1.2 kg-m, 6–9 ft-lb)

NOTE

- Tighten the head cover bolts in a crisscross pattern in two or more steps.


Adjust the valve clearance (page 3-7).



Install the engine upper brackets and tighten the bolts to the specified torque.

TORQUE:


8 mm bolts	24–30 N·m (2.4–3.0 kg-m, 17–22 ft-lb)
10 mm bolt	35–45 N·m (3.5–4.5 kg-m, 25–33 ft-lb)



CYLINDER HEAD/VALVES

Install the following parts:

- ignition coil.
- oil tank breather tube.
- oil pipe bolt and sealing washers to the cylinder head.
- kick starter decompressor cable and holder.



This new cylinder head retaining nut is used to secure the head to the block. It is a new design and is not used on the old head.

Do not use the old head retaining nut. It is a different design and will not fit the new head. The new head retaining nut is used to secure the head to the block.

(1) Dichtung
(2) Passbolzen

Loosen all the valve adjusting screws and install the new head cover.

Tighten the cylinder head to the block with the new head retaining nut. It is a new design and is not used on the old head. The new head retaining nut is used to secure the head to the block.

TORQUE

8 mm bolt	10-12 ft-lb (1.3-1.6 kgm)
8 mm flange	10-12 ft-lb (1.3-1.6 kgm)
8 mm bolt with	10-12 ft-lb (1.3-1.6 kgm)
8 mm head	10-12 ft-lb (1.3-1.6 kgm)

NOTE

Do not use the old head retaining nut. It is a different design and will not fit the new head. The new head retaining nut is used to secure the head to the block.

FOR BEACHING

Do not use the old head retaining nut. It is a different design and will not fit the new head. The new head retaining nut is used to secure the head to the block.


Do not use the old head retaining nut. It is a different design and will not fit the new head. The new head retaining nut is used to secure the head to the block.

SAFETY

Do not use the old head retaining nut. It is a different design and will not fit the new head. The new head retaining nut is used to secure the head to the block.

(1) 8-mm SCHRAUBE
(2) 10-mm SCHRAUBE

CYLINDER/PISTON
CYLINDRE/PISTON
ZYLINDER/KOLBEN



7. CYLINDER/PISTON

SERVICE INFORMATION	7-1	PISTON REMOVAL	7-4
TROUBLESHOOTING	7-2	PISTON INSTALLATION	7-8
CYLINDER REMOVAL	7-3	CYLINDER INSTALLATION	7-8

SERVICE INFORMATION

GENERAL

- Cylinder and piston maintenance and inspection can be accomplished without removing the engine from the frame.

SPECIFICATIONS

ITEM		STANDARD	SERVICE LIMIT
Cylinder	I.D.	92.000–92.010 mm (3.6200–3.6224 in)	92.12 mm (3.627 in)
	Taper	—	0.05 mm (0.002 in)
	Out of round	—	0.05 mm (0.002 in)
	Warpage across top	—	0.10 mm (0.004 in)
Piston, piston ring, piston pin	Piston O.D. at skirt	91.955–91.980 mm (3.6203–3.6213 in)	91.85 mm (3.616 in)
	Piston pin bore	24.002–24.008 mm (0.9450–0.9452 in)	24.08 mm (0.948 in)
	Piston pin-to-piston clearance	0.007–0.019 mm (0.0003–0.0007 in)	0.08 mm (0.003 in)
	Piston ring end gap	Top	0.20 –0.40 mm (0.0079–0.0157 in)
		Second	0.40 –0.55 mm (0.0157–0.0217 in)
		Oil (side rail)	0.20 –0.90 mm (0.008 –0.035 in)
	Piston ring-to-groove clearance	Top	0.015–0.045 mm (0.0006–0.0018 in)
		Second	0.015–0.045 mm (0.0006–0.0018 in)
	Cylinder-to-piston clearance	0.020–0.055 mm (0.0008–0.0022 in)	0.10 mm (0.004 in)
	Piston pin O.D.	23.989–23.995 mm (0.9444–0.9447 in)	23.95 mm (0.943 in)
Connecting rod small end I.D.		24.020–24.041 mm (0.9457–0.9465 in)	22.041 mm (0.8678 in)

TORQUE VALUES

Cylinder bolt 40–44 N·m (4.0–4.4 kg-m, 29–32 ft-lb)

CYLINDER/PISTON

TROUBLESHOOTING

Low compression

- Worn cylinder or piston rings

Excessive smoke

- Worn cylinder, piston, or piston rings
- Improper installation of piston rings
- Scored or scratched piston or cylinder wall

Overheating

- Excessive carbon build-up on piston crown or combustion chamber

Knocking or abnormal noise

- Worn piston and cylinder
- Excessive carbon build-up piston crown or combustion chamber

Worn piston and cylinder		Excessive carbon build-up piston crown or combustion chamber	
mm	in	mm	in
min 80.0	3.150	min 80.0	3.150
min 85.0	3.346	min 85.0	3.346
min 90.0	3.543	min 90.0	3.543
min 95.0	3.740	min 95.0	3.740
min 100.0	3.937	min 100.0	3.937
min 105.0	4.134	min 105.0	4.134
min 110.0	4.331	min 110.0	4.331
min 115.0	4.528	min 115.0	4.528
min 120.0	4.725	min 120.0	4.725
min 125.0	4.922	min 125.0	4.922
min 130.0	5.119	min 130.0	5.119
min 135.0	5.316	min 135.0	5.316
min 140.0	5.513	min 140.0	5.513
min 145.0	5.710	min 145.0	5.710
min 150.0	5.907	min 150.0	5.907
min 155.0	6.104	min 155.0	6.104
min 160.0	6.301	min 160.0	6.301
min 165.0	6.498	min 165.0	6.498
min 170.0	6.695	min 170.0	6.695
min 175.0	6.892	min 175.0	6.892
min 180.0	7.089	min 180.0	7.089
min 185.0	7.286	min 185.0	7.286
min 190.0	7.483	min 190.0	7.483
min 195.0	7.680	min 195.0	7.680
min 200.0	7.877	min 200.0	7.877
min 205.0	8.074	min 205.0	8.074
min 210.0	8.271	min 210.0	8.271
min 215.0	8.468	min 215.0	8.468
min 220.0	8.665	min 220.0	8.665
min 225.0	8.862	min 225.0	8.862
min 230.0	9.059	min 230.0	9.059
min 235.0	9.256	min 235.0	9.256
min 240.0	9.453	min 240.0	9.453
min 245.0	9.650	min 245.0	9.650
min 250.0	9.847	min 250.0	9.847
min 255.0	10.044	min 255.0	10.044
min 260.0	10.241	min 260.0	10.241
min 265.0	10.438	min 265.0	10.438
min 270.0	10.635	min 270.0	10.635
min 275.0	10.832	min 275.0	10.832
min 280.0	11.029	min 280.0	11.029
min 285.0	11.226	min 285.0	11.226
min 290.0	11.423	min 290.0	11.423
min 295.0	11.620	min 295.0	11.620
min 300.0	11.817	min 300.0	11.817
min 305.0	12.014	min 305.0	12.014
min 310.0	12.211	min 310.0	12.211
min 315.0	12.408	min 315.0	12.408
min 320.0	12.605	min 320.0	12.605
min 325.0	12.802	min 325.0	12.802
min 330.0	13.000	min 330.0	13.000
min 335.0	13.197	min 335.0	13.197
min 340.0	13.394	min 340.0	13.394
min 345.0	13.591	min 345.0	13.591
min 350.0	13.788	min 350.0	13.788
min 355.0	13.985	min 355.0	13.985
min 360.0	14.182	min 360.0	14.182
min 365.0	14.380	min 365.0	14.380
min 370.0	14.577	min 370.0	14.577
min 375.0	14.774	min 375.0	14.774
min 380.0	14.971	min 380.0	14.971
min 385.0	15.168	min 385.0	15.168
min 390.0	15.365	min 390.0	15.365
min 395.0	15.562	min 395.0	15.562
min 400.0	15.760	min 400.0	15.760
min 405.0	15.957	min 405.0	15.957
min 410.0	16.154	min 410.0	16.154
min 415.0	16.351	min 415.0	16.351
min 420.0	16.548	min 420.0	16.548
min 425.0	16.745	min 425.0	16.745
min 430.0	16.942	min 430.0	16.942
min 435.0	17.140	min 435.0	17.140
min 440.0	17.337	min 440.0	17.337
min 445.0	17.534	min 445.0	17.534
min 450.0	17.731	min 450.0	17.731
min 455.0	17.928	min 455.0	17.928
min 460.0	18.125	min 460.0	18.125
min 465.0	18.322	min 465.0	18.322
min 470.0	18.520	min 470.0	18.520
min 475.0	18.717	min 475.0	18.717
min 480.0	18.914	min 480.0	18.914
min 485.0	19.111	min 485.0	19.111
min 490.0	19.308	min 490.0	19.308
min 495.0	19.505	min 495.0	19.505
min 500.0	19.702	min 500.0	19.702
min 505.0	19.900	min 505.0	19.900
min 510.0	20.097	min 510.0	20.097
min 515.0	20.294	min 515.0	20.294
min 520.0	20.491	min 520.0	20.491
min 525.0	20.688	min 525.0	20.688
min 530.0	20.885	min 530.0	20.885
min 535.0	21.082	min 535.0	21.082
min 540.0	21.280	min 540.0	21.280
min 545.0	21.477	min 545.0	21.477
min 550.0	21.674	min 550.0	21.674
min 555.0	21.871	min 555.0	21.871
min 560.0	22.068	min 560.0	22.068
min 565.0	22.265	min 565.0	22.265
min 570.0	22.462	min 570.0	22.462
min 575.0	22.660	min 575.0	22.660
min 580.0	22.857	min 580.0	22.857
min 585.0	23.054	min 585.0	23.054
min 590.0	23.251	min 590.0	23.251
min 595.0	23.448	min 595.0	23.448
min 600.0	23.645	min 600.0	23.645
min 605.0	23.842	min 605.0	23.842
min 610.0	24.040	min 610.0	24.040
min 615.0	24.237	min 615.0	24.237
min 620.0	24.434	min 620.0	24.434
min 625.0	24.631	min 625.0	24.631
min 630.0	24.828	min 630.0	24.828
min 635.0	25.025	min 635.0	25.025
min 640.0	25.222	min 640.0	25.222
min 645.0	25.420	min 645.0	25.420
min 650.0	25.617	min 650.0	25.617
min 655.0	25.814	min 655.0	25.814
min 660.0	26.011	min 660.0	26.011
min 665.0	26.208	min 665.0	26.208
min 670.0	26.405	min 670.0	26.405
min 675.0	26.602	min 675.0	26.602
min 680.0	26.800	min 680.0	26.800
min 685.0	26.997	min 685.0	26.997
min 690.0	27.194	min 690.0	27.194
min 695.0	27.391	min 695.0	27.391
min 700.0	27.588	min 700.0	27.588
min 705.0	27.785	min 705.0	27.785
min 710.0	27.982	min 710.0	27.982
min 715.0	28.180	min 715.0	28.180
min 720.0	28.377	min 720.0	28.377
min 725.0	28.574	min 725.0	28.574
min 730.0	28.771	min 730.0	28.771
min 735.0	28.968	min 735.0	28.968
min 740.0	29.165	min 740.0	29.165
min 745.0	29.362	min 745.0	29.362
min 750.0	29.560	min 750.0	29.560
min 755.0	29.757	min 755.0	29.757
min 760.0	29.954	min 760.0	29.954
min 765.0	30.151	min 765.0	30.151
min 770.0	30.348	min 770.0	30.348
min 775.0	30.545	min 775.0	30.545
min 780.0	30.742	min 780.0	30.742
min 785.0	30.940	min 785.0	30.940
min 790.0	31.137	min 790.0	31.137
min 795.0	31.334	min 795.0	31.334
min 800.0	31.531	min 800.0	31.531
min 805.0	31.728	min 805.0	31.728
min 810.0	31.925	min 810.0	31.925
min 815.0	32.122	min 815.0	32.122
min 820.0	32.320	min 820.0	32.320
min 825.0	32.517	min 825.0	32.517
min 830.0	32.714	min 830.0	32.714
min 835.0	32.911	min 835.0	32.911
min 840.0	33.108	min 840.0	33.108
min 845.0	33.305	min 845.0	33.305
min 850.0	33.502	min 850.0	33.502
min 855.0	33.700	min 855.0	33.700
min 860.0	33.897	min 860.0	33.897
min 865.0	34.094	min 865.0	34.094
min 870.0	34.291	min 870.0	34.291
min 875.0	34.488	min 875.0	34.488
min 880.0	34.685	min 880.0	34.685
min 885.0	34.882	min 885.0	34.882
min 890.0	35.080	min 890.0	35.080
min 895.0	35.277	min 895.0	35.277
min 900.0	35.474	min 900.0	35.474
min 905.0	35.671	min 905.0	35.671
min 910.0	35.868	min 910.0	35.868
min 915.0	36.065	min 915.0	36.065
min 920.0	36.262	min 920.0	36.262
min 925.0	36.460	min 925.0	36.460
min 930.0	36.657	min 930.0	36.657
min 935.0	36.854	min 935.0	36.854
min 940.0	37.051	min 940.0	37.051
min 945.0	37.248	min 945.0	37.248
min 950.0	37.445	min 950.0	37.445
min 955.0	37.642	min 955.0	37.642
min 960.0	37.840	min 960.0	37.840
min 965.0	38.037	min 965.0	38.037
min 970.0	38.234	min 970.0	38.234
min 975.0	38.431	min 975.0	38.431
min 980.0	38.628	min 980.0	38.628
min 985.0	38.825	min 985.0	38.825
min 990.0	39.022	min 990.0	39.022
min 995.0	39.220	min 995.0	39.220
min 1000.0	39.417	min 1000.0	39.417

CLINDER REMOVAL

Remove the cylinder head (Section 6).

Remove the two cylinder head base mounting bolts.

Remove the cam shin guide.





Remove the four cylinder mounting bolts.

NOTE

- Loosen the bolts in crisscross pattern in two or more steps.

Remove the cylinder.

Remove the dowel pins and cylinder gasket.




CYLINDER/PISTON

Clean any gasket material from the cylinder surface.

NOTE

- Gasket material will come off easier if it soaked in solvent.



CYLINDER INSPECTION


Inspect the cylinder bore for wear or damage.

Measure the cylinder I.D.

SERVICE LIMIT: 92.12 mm (3.627 in)

NOTE

- Check for out of round on the X and Y axis at three locations.




Calculate the taper and out of round.

SERVICE LIMIT: OUT OF ROUND: 0.05 mm (0.002 in)
TAPER: 0.05 mm (0.002 in)

Inspect the top of the cylinder for warpage.

SERVICE LIMIT: 0.10 mm (0.004 in)




PISTON REMOVAL

Place clean shop towels in the crankcase to keep the piston pin clips, or other parts from falling into the crankcase.

Remove the piston pin clips with pliers.

Press the piston pin out of the piston.




CYLINDER/PISTON CYLINDER/PISTON

Remove the piston rings.
Inspect the piston for damaged and the ring grooves for wear.

CAUTION


- *Piston rings are easily broken; take care not to damage them during removal.*



PISTON/PISTON RING INSPECTION

Measure the piston ring-to-groove clearance.

SERVICE LIMIT: TOP 0.10 mm (0.004 in)
2nd 0.10 mm (0.004 in)




Calculate the taper and out of round.

Insert each piston ring into the cylinder, above 20 mm (0.750 in) in from the bottom.

To ensure that it's square in the bore, use a piston to push it in.

Measure the ring end gap.

SERVICE LIMIT: TOP 0.50 mm (0.020 in)
2nd 0.65 mm (0.026 in)



Measure the piston diameter 10 mm from the bottom.

SERVICE LIMIT: 91.85 mm (3.616 in)

Calculate the piston-to-cylinder clearance by subtracting the piston O.D. from the cylinder I.D. (page 7-4)


SERVICE LIMIT: 0.10 mm (0.004 in)



CYLINDER/PISTON

Measure the piston pin hole I.D.

SERVICE LIMIT: 24.08 mm (0.948 in)



Measure the piston pin O.D.

SERVICE LIMIT: 23.95 mm (0.943 in)


Calculate the piston-to-piston pin clearance.

SERVICE LIMIT: 0.08 mm (0.003 in)



Measure the connecting rod small end I.D.

SERVICE LIMIT: 22.041 mm (0.8678 in)




PISTON RING INSTALLATION

Clean the piston ring grooves thoroughly.

Check for cleanliness by holding a ring in the grooves while turning the piston.

CAUTION

- Do not use a wire brush to clean ring lands, or cut lands deeper with a cleaning tool.



CYLINDER/PISTON

Install the piston rings with the marks facing up.

CAUTION



- Avoid piston and piston ring damage during installation.

Stagger the compression (1st and 2nd) and oil rings (side rails) 180 degrees apart as shown.

NOTE

- Install the oil ring spacer first, then install the side rails.

After installation, rings should be free to rotate in the grooves.



CYLINDER/PISTON

PISTON INSTALLATION

Apply molybdenum disulfide grease to the piston O.D.

Install the piston and piston pin. Position the piston "IN" mark on the intake valve side.

Install new piston pin clips and apply engine oil to the piston.

NOTE

- Do not align the piston pin clip end gap with the piston cut-out.
- Place a shop towel around the piston skirt and in the crankcase to prevent the piston pin clips from falling into the crankcase.

CYLINDER INSTALLATION

Apply a liquid sealant to the crankcase mating area to prevent oil leaks.

Install a new cylinder base gasket and dowel pins.

Place the piston at bottom dead center.

Coat the cylinder bore, piston and piston rings with fresh engine oil.





Carefully lower the cylinder over the piston by compressing the piston ring, one at a time.

CAUTION

- *Do not force the cylinder over a ring; you may damage the piston and piston ring.*

Apply engine oil to the cylinder bolts, washer and tighten the cylinder bolts in crisscross pattern in two or more steps.

TORQUE: 40–44 N·m (4.0–4.4 kg·m, 29–32 ft·lb)




CYLINDER/PISTON

Tighten the cylinder base bolts.
Install the cam chain guide.
Install the cylinder head (page 6-16).


NOTE

- Push the cam chain guide in until it bottoms in the crankcase guide hole.

(1) CYLINDER BASE BOLT (2) CAM CHAIN GUIDE



**CLUTCH/OIL PUMP/KICK STARTER
EMBRAYAGE/POMPE A HUILE/KICKSTARTER
KUPPLUNG/ÖLPUMPE/KICKSTARTER**



8. CLUTCH/OIL PUMP/KICK STARTER

SERVICE INFORMATION	8-1	OIL PUMP	8-7
TROUBLESHOOTING	8-2	KICK STARTER	8-13
RIGHT CRANKCASE COVER REMOVAL	8-3	CLUTCH INSTALLATION	8-17
CLUTCH REMOVAL	8-5	RIGHT CRANKCASE COVER INSTALLATION	8-20

SERVICE INFORMATION

GENERAL

- This section covers removal and installation of the clutch, oil pump, kick starter, and right crankcase cover. All these operations can be accomplished with the engine installed.
- When the existing clutch discs are replaced, coat new discs with engine oil prior to assembly.
- For shift linkage replacement, refer to section 10.

SPECIFICATIONS

ITEM		STANDARD	SERVICE LIMIT
Clutch	Lever free play (at lever end)	10–20 mm (3/8–3/4 in)	—
	Spring free length	44.3 mm (1.744 in)	42.7 mm (1.68 in)
	Spring preload/length	25±1.3 kg/28.5 mm (4.9±2.9 lb/1.12 in)	—
	Disk thickness	(A) 1.35–1.45 mm (0.053–0.057 in)	1.1 mm (0.04 in)
		(B) 2.92–3.08 mm (0.115–0.121 in)	2.6 mm (0.10 in)
	Plate warpage	—	0.3 mm (0.01 in)
	Clutch outer I.D.	27.000–27.021 mm (1.0630–1.0638 in)	27.05 mm (1.065 in)
	Outer guide O.D.	26.959–26.980 mm (1.0614–1.0622 in)	26.91 mm (1.059 in)
Oil pump	Mainshaft-to-clutch outer guide clearance	0.010–0.068 mm (0.0004–0.0027 in)	0.12 mm (0.005 in)
	Inner rotor-to-outer rotor clearance	0.15 mm (0.006 in) max	0.20 mm (0.008 in)
	Outer rotor-to-body clearance	0.15–0.22 mm (0.006–0.009 in)	0.25 mm (0.010 in)
	Rotor-to-cover clearance	0.04–0.09 mm (0.002–0.004 in)	0.12 mm (0.005 in)
Kick starter	Starter idler gear I.D.	20.000–20.021 mm (0.7874–0.7882 in)	20.11 mm (0.792 in)
	Idler gear bushing	O.D. 19.959–19.980 mm (0.7858–0.7866 in)	19.90 mm (0.783 in)
		I.D. 16.000–16.018 mm (0.6299–0.6306 in)	16.03 mm (0.631 in)
	Kick starter gear I.D.	22.000–22.033 mm (0.8661–0.8674 in)	22.12 mm (0.871 in)
	Kick starter spindle O.D.	21.959–21.980 mm (0.8645–0.8654 in)	21.90 mm (0.862 in)

TORQUE VALUES

Clutch lock nut	70–80 N·m (7.0–8.0 kg-m, 51–58 ft-lb)
Right crankcase cover bolt	10–14 N·m (1.0–1.4 kg-m, 7–10 ft-lb)
Kick starter stopper plate bolt	22–28 N·m (2.2–2.8 kg-m, 16–20 ft-lb)

TOOLS

COMMON

Driver	07749–0010000
Attachment, 24x26 mm	07746–0010700
Pilot, 20 mm	07746–0040500
Clutch center holder	07724–0050000
Driver pin, 2.5 mm	07744–0010100

TROUBLESHOOTING

Faulty clutch operation can usually be corrected by adjusting the clutch lever free play.

Clutch slips when accelerating

- No free play
- Discs worn
- Springs weak

Clutch will not disengage

- Too much free play
- Plates warped

Motorcycle creeps with clutch disengaged

- Too much free play
- Plates warped

Excessive lever pressure

- Clutch cable kinked, damaged or dirty
- Lifter mechanism damaged

Clutch operation feels rough

- Outer drum slots rough
- Dirty clutch cable

Low oil pressure

- Faulty oil pump
- Oil pump drive gear broken


RIGHT CRANKCASE COVER REMOVAL

REMOVAL

Drain oil from the engine and oil tank (page 2-2).


Remove the kick starter pedal.

Remove the cable holder attaching bolt and disconnect the decompressor cable at the kick starter lever.




Remove the lower oil bolt, sealing washers and oil pipe bracket bolt.


Disconnect the oil pipe from the right crankcase cover.



Remove the bolts holding the right crankcase cover, and remove the cover.




Remove the dowel pins and gasket.



CLUTCH/OIL PUMP/KICK STARTER

DISASSEMBLY/ASSEMBLY


Remove the snap ring, cam, return spring and camshaft.



Remove the snap ring and oil seal.


Install a new oil seal.

Install the snap ring.



Check the oil seal and needle bearing for wear, excessive play or damage and replace if necessary.

Remove the oil seal and needle bearing from the right crankcase cover.



Drive a new needle bearing with the special tools.

Install a new oil seal.


TOOLS:

Driver
Attachment, 24 x 26 mm
Pilot, 20 mm

07749-0010000

07746-0010700

07746-0040500



CLUTCH REMOVAL

Remove the four clutch bolts and springs.

NOTE

- Loosen the bolts in a crisscross pattern in 2–3 steps.

Remove the clutch pressure plate.

Remove the clutch push rod tip and release bearing on the clutch pressure plate.

Remove the clutch discs and plates.

Remove the judder spring and seat.

Remove the push rod.

Straighten the tubs of the lock washer.





Hold the clutch center with the clutch center holder.

Remove the lock nut, lock washer and washer.

Remove the clutch center holder and clutch center.


TOOL:

Clutch center holder 07724-0050000




CLUTCH/OIL PUMP/KICK STARTER

Remove the thrust washer and clutch outer.



Remove the clutch outer guide from the mainshaft.



SPRING INSPECTION


Measure the free length of each spring.

SERVICE LIMIT: 42.7 mm (1.68 in)

Replace if shorter than the service limit.

NOTE

- Clutch springs should be replaced as a set if one or more is beyond the service limit.




CLUTCH DISC INSPECTION

Replace the discs if they show signs of scoring or discoloration. Measure the disc thickness.

SERVICE LIMIT: (A) 1.1 mm (0.04 in)
(B) 2.6 mm (0.10 in)

NOTE

- Clutch discs and plates should be replaced as a set if any one is beyond the service limit.




CLUTCH/OIL PUMP/KICK STARTER

CLUTCH PLATE INSPECTION

Check for plate warpage on a surface plate, using a feeler gauge.

SERVICE LIMIT: 0.3 mm (0.01 in)




CLUTCH OUTER AND OUTER GUIDE INSPECTION

Check the slots in the outer drum for nicks, cuts or indentations made by the friction discs.

Measure the I.D. of the clutch outer and the O.D. of the outer guide.

SERVICE LIMIT


CLUTCH OUTER I.D.	27.05 mm (1.065 in)
OUTER GUIDE O.D.	26.91 mm (1.059 in)




OIL PUMP

REMOVAL

Remove the clutch (page 8-5).
Remove the oil pump driven gear.




Remove the collar and O-ring.
Remove the bolts attaching the oil pump and the oil pump from the right crankcase.




CLUTCH/OIL PUMP/KICK STARTER

Remove the orifice and O-ring from the right crankcase.
Check that the oil orifice in the crankcase is clean by blowing through with compressed air.




DISASSEMBLY

Remove the oil pump body screws and dowel pins.




Remove the oil pump A body from the housing



OIL PUMP INSPECTION

Measure the tip clearance between the inner and outer A rotors.


SERVICE LIMIT: 0.20 mm (0.008 in)



CLUTCH/OIL PUMP/KICK STARTER


Measure the clearance between the outer rotor A and the pump A body.

SERVICE LIMIT: 0.25 mm (0.010 in)




Measure the end clearance of pump A.

SERVICE LIMIT: 0.12 mm (0.005 in)




Remove the lock pin and washer from the oil pump shaft, then separate the housing from the oil pump B.



Measure the tip clearance between the inner and outer B rotors.

SERVICE LIMIT: 0.20 mm (0.008 in)



CLUTCH/OIL PUMP/KICK STARTER

Measure the clearance between the outer rotor B and the pump B body.

SERVICE LIMIT: 0.25 mm (0.010 in)

Remove the oil pump shaft and press out the lock pin from the shaft.

SERVICE LIMIT: 0.12 mm (0.005 in)


Measure the end clearance of pump B.

SERVICE LIMIT: 0.12 mm (0.005 in)

Remove the spring pin and the cotter pin from the housing.
Remove the oil leak stopper and plug.



TOOL:

Driver pin, 2.5 mm 07744-0010100




(1) OIL PUMP SHAFT

(2) LOCK PIN



(1) SPRING PIN


(2) COTTER PIN




CLUTCH/OIL PUMP/KICK STARTER

Inspect the O-ring and the oil leak stopper for damage.

Clean as necessary. Also check the condition of the plug.
Discard the old cotter pin and spring pin.




ASSEMBLY



Install the oil leak stopper into the housing, and align the hole in the oil leak stopper with the hole in the housing.

Install a new cotter pin.

Install the sealing plug with a new spring pin.




CLUTCH/OIL PUMP/KICK STARTER


Assemble oil pump B and the housing, then slip the dowel pins into places.

Install the washer on the pump shaft and press the lock pin.

Install outer rotor A into the pump A body, then assemble onto the housing.




Tighten the two oil pump screws.



INSTALLATION

Install the orifice and a new O-ring onto the right crankcase.




Install the oil pump onto the right crankcase.

Install the collar and a new O-ring.


Coat new O-rings with engine oil and install them on the oil pipe.

Install the oil pipe.




CLUTCH/OIL PUMP/KICK STARTER

Tighten the oil pipe with bolt and nut.
Install the oil pump bolts and tighten them.




Install the oil pump driven gear over the oil pump shaft.
Install the clutch (page 8-17).




KICK STARTER

REMOVAL

Remove the clutch (page 8-5).
Remove the starter idler gear and its flanged bushing.



Remove the thrust washer, kick starter cam, spring and spring seat from the spindle.



CLUTCH/OIL PUMP/KICK STARTER

Remove the kick starter return spring from the right crankcase hole and remove the kick starter spindle assembly from the right crankcase.

DISASSEMBLY

Remove the collar, return spring, spring seat, ratchet spring and ratchet from the spindle.

Remove the snap rings, washers and pinion gear from the spindle.





INSPECTION

Measure the I.D. of the kick starter idler gear.

SERVICE LIMIT: 20.11 mm (0.792 in)

Measure the I.D. and O.D. of the idler gear bushing.

**SERVICE LIMIT: I.D. 16.03 mm (0.631 in)
O.D. 19.90 mm (0.783 in)**




CLUTCH/OIL PUMP/KICK STARTER

Measure the I.D. of the kick starter gear.


SERVICE LIMIT: 22.12 mm (0.871 in)

Measure the O.D. of the kick starter spindle.


SERVICE LIMIT: 21.90 mm (0.862 in)



ASSEMBLY



Align the punch marks on the ratchet and the spindle and install the ratchet over the spindle.




CLUTCH/OIL PUMP/KICK STARTER

Install the ratchet spring and spring seat.


Install the return spring and insert its end into the hole in the spindle.

Install the collar aligning its groove with the spring end inserted into the hole in the spindle.




INSTALLATION


Hook the return spring to the right crankcase hole.



Turn the kick starter spindle counterclockwise until punch mark facing up.
Align the ratchet pawl with the stopper plate and install the spindle assembly.




Install the spring seat and cam spring.
Align the punch marks on the starter cam and the spindle and install the starter cam.




CLUTCH/OIL PUMP/KICK STARTER


Install the thrust washer.



Install the starter idler gear bushing with its flange facing in.




Install the starter idler gear with its higher boss facing out.
Install the clutch (page 8-17).




CLUTCH INSTALLATION

Apply molybdenum disulfide grease to the clutch outer guide.
Install the clutch outer guide onto the mainshaft.




CLUTCH/OIL PUMP/KICK STARTER

Install the clutch outer over the outer guide, and the thrust washer.



Install the clutch center.
Install the washer with the OUTSIDE mark facing out.
Install the lock washer with the hole aligned with the stopper pin of the clutch center.




Install the clutch lock nut.
Install the clutch center holder to the clutch center.
Tighten the clutch lock nut to the specified torque.

TORQUE: 70–80 N·m (7.0–8.0 kg·m, 51–58 ft·lb)


Remove the holder.

TOOL:

Clutch center holder 07724–0050000



Install the push rod into the mainshaft.




CLUTCH/OIL PUMP/KICK STARTER


Coat the discs and plates with clean engine oil.
Install the judder spring seat and judder spring.
Install the disc A.

NOTE


- Note the direction of the judder spring.



Install the plates and discs B as shown.




Install the clutch push rod tip into the mainshaft.




CLUTCH/OIL PUMP/KICK STARTER

Install the bearing onto the clutch pressure plate.
Install the clutch pressure plate, bolts and spring.
Tighten the bolts in crisscross pattern in 2–3 steps.




RIGHT CRANKCASE COVER INSTALLATION

Clean the oil filter screen (page 2-4).
Install the dowel pins and new gasket.




Install the right crankcase cover while pushing the cam follower lever down.
Check the operation of the decompression and clutch levers after installing the cover.



Tighten the right crankcase cover bolts.

TORQUE: 10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb)




CLUTCH/OIL PUMP/KICK STARTER

Make sure that the oil pipe and oil pipe bolts are clean and the sealing washers are in good condition.

Tighten the oil bolt with two sealing washers.

Tighten the oil pipe bracket bolt.




Connect the decompressor cable to the cam follower lever.


Install the cable holder and tighten the bolt.

Install the kick starter pedal.

Fill the oil tank with the recommended oil (page 2-1). Adjust the kick starter decompressor (page 3-8).



**ALTERNATOR
ALTERNATEUR
LICHTMASCHINE**



9. ALTERNATOR

SERVICE INFORMATION	9-1	FLYWHEEL INSTALLATION	9-4
LEFT CRANKCASE COVER REMOVAL	9-2	LEFT CRANKCASE COVER INSTALLATION	9-4
FLYWHEEL REMOVAL	9-3		

SERVICE INFORMATION

GENERAL

- This section pertains to removal and installation of the alternator. These operations can be accomplished with the engine in the frame after removing the left crankcase cover.
- For alternator inspection, refer to section 17.
- For starter clutch and starter driven gear removal, refer to section 18.

TORQUE VALUES

Flywheel bolt 115–135 N·m (11.5–13.5 kg-m, 84–98 ft-lb)

TOOLS


COMMON

Flywheel holder 07725-0040000
Rotor puller 07733-0020001

ALTERNATOR

LEFT CRANKCASE COVER REMOVAL

Remove the left side cover.
Disconnect the alternator couplers and wire.
Drain the oil from the engine.
Remove the cable holder attaching bolt and disconnect the clutch cable from the lifter arm.




INFORMATIONS D'ENTRETIEN

GÉNÉRALITÉS

- Cette section couvre le démontage et le montage de l'alternateur.
- Les opérations doivent être effectuées dans l'ordre indiqué.
- Pour le montage de l'alternateur, se reporter à l'annexe 81.
- Pour le montage de l'embrayage de démarrage, de l'embrayage et de la pompe à huile, se reporter à l'annexe 82.

Remove the drive sprocket cover.
Remove the starter gear cover and gears (18-2).




OUTILS

OUTILS CHENAIRES


Outil de montage de volant
Extracteur de roue

07775-0040000
07733-0720001

Disconnect the neutral switch wire from the switch.
Remove the left crankcase cover bolts and cover.



Remove the dowel pins and gasket.




ALTERNATOR

CLUTCH LIFTER ARM DISASSEMBLY


Remove the clutch lifter piece.

Remove the clutch lifter arm and spring.



ALTERNATOR STATOR REMOVAL

Remove the three bolts attaching the alternator stator to the left crankcase and the stator.



FLYWHEEL REMOVAL


Remove the starter drive gear.

Hold the flywheel with the flywheel holder.

Remove the flywheel bolt.

TOOL:


Flywheel holder 07725-0040000



Remove the flywheel using the rotor puller.

TOOL:

Rotor puller 07733-0020001



ALTERNATOR

FLYWHEEL INSTALLATION


Install the flywheel by aligning the woodruff key on the crankshaft with the flywheel keyway.

Hold the flywheel with the flywheel holder and tighten the flywheel bolt.

TORQUE: 115–135 N·m (11.5–13.5 kg·m, 84–98 ft·lb)

TOOL:

Flywheel holder 07725-0040000




LEFT CRANKCASE COVER INSTALLATION

CLUTCH LIFTER ARM INSTALLATION

Install the spring onto the lifter arm.

Insert the lifter arm and hook the spring to the left crankcase cover.

Turn the lifter arm and install the lifter piece, aligning the groove on the lifter arm with the bottom of the lifter piece.




ALTERNATOR STATOR INSTALLATION

Install the stator onto the left crankcase cover and apply locking agent to the stator mounting bolt threads.

Tighten the three bolt.


Route the stator wire and install the wire grommet into the groove in the cover as shown.



Install the two dowel pins and a new gasket.

Make sure the clutch lifter rod is in place.

Install the starter driver gear (page 18-4).



ALTERNATOR

Install the left crankcase cover and connect the neutral switch wire.

Tighten the left crankcase cover bolts.

TORQUE: 110-135 N·m (81-100 ft·lb)
TOOL:
Flywheel holder 97725-00000

Install the starter gears (page 18-4) and starter gear cover.

Connect the clutch cable and tighten the cable holder bolts.



Install the drive sprocket cover.

Connect the alternator couplers and wire.


Fill the oil tank with the recommended oil (page 2-1).

Adjust the clutch (page 3-8).

Install the left side cover.



**SHIFT LINKAGE/TRANSMISSION
TRINGLERIE DE CHANGEMENT DE
VITESSES/BOITE DE VITESSES
SCHALTMECHANISMUS/GETRIEBE**



10

10. SHIFT LINKAGE/TRANSMISSION

SERVICE INFORMATION	10-1	TRANSMISSION REMOVAL	10-5
TROUBLESHOOTING	10-2	TRANSMISSION ASSEMBLY	10-8
CRANKCASE SEPARATION	10-3	CRANKCASE ASSEMBLY	10-10

SERVICE INFORMATION

GENERAL

- The crankcase must be separated to service the transmission and shift linkage.
- The gearshift stopper arm, plate and primary drive gear can be serviced with the engine install in the frame.
- Remove the following parts before separating the crankcase.

CYLINDER HEAD	Section 6
CYLINDER/PISTON	Section 7
CLUTCH/OIL PUMP/KICK STARTER	Section 8
ALTERNATOR	Section 9
STARTER DRIVEN GEAR	Section 18

SPECIFICATIONS

ITEM			STANDARD	SERVICE LIMIT	
Transmission	Gear I.D.	M4	28.020–28.041 mm (1.1031–1.1040 in)	28.10 mm (1.106 in)	
		M5	28.000–28.021 mm (1.1024–1.1032 in)	28.08 mm (1.106 in)	
		C1	25.020–25.041 mm (0.9850–0.9859 in)	25.10 mm (0.988 in)	
		C3	25.020–25.041 mm (0.9850–0.9859 in)	25.10 mm (0.988 in)	
		C2	28.020–28.041 mm (0.1031–1.1040 in)	28.10 mm (1.106 in)	
	Gear bushing	M5	O.D.	27.949–27.980 mm (1.1004–1.1016 in)	27.90 mm (1.098 in)
			M4	I.D.	25.020–25.041 mm (0.9850–0.9859 in)
		O.D.		27.979–28.000 mm (1.1015–1.1024 in)	27.93 mm (1.100 in)
		C1	I.D.	20.020–20.041 mm (0.7882–0.7890 in)	20.10 mm (0.791 in)
			O.D.	24.984–25.005 mm (0.9836–0.9844 in)	24.93 mm (0.981 in)
		C2	I.D.	25.020–25.041 mm (0.9850–0.9859 in)	25.10 mm (0.988 in)
			O.D.	27.979–28.000 mm (1.1015–1.1024 in)	27.93 mm (1.100 in)
	Gear-to-bushing clearance	M5	0.020–0.072 mm (0.0008–0.0028 in)	0.10 mm (0.004 in)	
		M4	0.020–0.062 mm (0.008–0.0024 in)	0.10 mm (0.004 in)	
		C1	0.015–0.057 mm (0.0006–0.0022 in)	0.10 mm (0.004 in)	
		C2	0.020–0.062 mm (0.0008–0.0024 in)	0.10 mm (0.004 in)	
	Mainshaft O.D.	M4	24.959–24.980 mm (0.9826–0.9835 in)	24.91 mm (0.981 in)	
	Countershaft O.D.	Starter idler	15.966–15.984 mm (0.6286–0.6293 in)	15.93 mm (0.627 in)	
		C1	19.980–19.993 mm (0.7866–0.7871 in)	19.94 mm (0.785 in)	
		C2	24.972–24.993 mm (0.9831–0.9840 in)	24.92 mm (0.981 in)	
		C3	24.959–24.980 mm (0.9826–0.9835 in)	24.92 mm (0.981 in)	
	Shaft-to-gear clearance	C3	0.040–0.082 mm (0.0016–0.0032 in)	0.15 mm (0.006 in)	
	Shaft-to-bushing clearance	M4	0.027–0.068 mm (0.0011–0.0027 in)	0.10 mm (0.004 in)	
		C1	0.027–0.061 mm (0.0011–0.0024 in)	0.10 mm (0.004 in)	
		C2	0.027–0.069 mm (0.0011–0.0027 in)	0.10 mm (0.004 in)	
Shift fork, shift fork shaft	Shift fork I.D.		14.000–14.018 mm (0.5512–0.5519 in)	14.05 mm (0.553 in)	
	Shift fork claw thickness		4.93–5.00 mm (0.194–0.197 in)	4.5 mm (0.18 in)	
	Shift fork shaft O.D.		13.966–13.984 mm (0.5498–0.5506 in)	13.90 mm (0.547 in)	

CRANKCASE SEPARATION

Remove the engine from the frame (Section 5).
Refer to Service Information (page 10-1) for removal of necessary parts before disassembling the crankcase.




Remove the pulse generator by removing the bolts.
Temporarily install the clutch outer guide and clutch outer onto the mainshaft.
Install the gear holder between the primary drive and driven gears.
Remove the drive gear lock nut, and washer.
Remove the gear holder.

TOOL:

Gear holder 07724-0010100


Remove the oil pump drive gear, pulse generator rotor and primary drive gear.

Remove the cam chain, tensioner slipper and drive sprocket.




SHIFT LINKAGE/TRANSMISSION


Remove the stopper arm bolt and arm.
Remove the stopper plate bolt and plate.



Remove the right crankcase bolts.




Remove the left crankcase bolts.



Place the left crankcase side down and separate the right crankcase from the left crankcase while tapping them at several locations with a soft hammer.


CAUTION

- Do not pry between the left and right crankcases.




SHIFT LINKAGE/TRANSMISSION

Remove the gasket and dowel pins.




TRANSMISSION REMOVAL


Pull the gearshift plate and remove the gearshift spindle.



Bend down the lock washer tabs and remove the bolt and lock washer from the center shift fork.




Remove the shift fork shaft, then remove the shift forks and shift drum.



SHIFT LINKAGE/TRANSMISSION

Remove the mainshaft and countershaft as an assembly.
Disassemble the mainshaft and countershaft.

(1) COUNTERSHAFT (2) MAINSHAFT



INSPECTION

Check each gear dog for excessive or abnormal wear.
Inspect the I.D. of each gear.

SERVICE LIMIT

M4	28.10 mm (1.106 in)
M5	28.08 mm (1.106 in)
C1	25.10 mm (0.988 in)
C3	25.10 mm (0.988 in)
C2	28.10 mm (1.106 in)

Measure the I.D. and O.D. of each gear bushing.

SERVICE LIMIT:

M5 O.D.	27.90 mm (1.098 in)
M4 O.D.	27.93 mm (1.100 in)
M4 I.D.	25.10 mm (0.988 in)
C1 O.D.	24.93 mm (0.981 in)
C1 I.D.	20.10 mm (0.791 in)
C2 O.D.	27.93 mm (1.100 in)
C2 I.D.	25.10 mm (0.988 in)

Calculate the clearance between the gear and bushing.

SERVICE LIMIT: 0.10 mm (0.004 in)

Measure the mainshaft and countershaft O.D.



SERVICE LIMIT:

A (M4):	24.91 mm (0.981 in)
B (Starter idler):	15.93 mm (0.627 in)
C (C1):	19.94 mm (0.785 in)
D (C3):	24.92 mm (0.981 in)
E (C2):	24.92 mm (0.981 in)

Calculate the clearance between the shaft and gear or bushing.

SERVICE LIMIT:

M4	0.10 mm (0.004 in)
C1	0.10 mm (0.004 in)
C2	0.10 mm (0.004 in)
C3	0.15 mm (0.006 in)



SHIFT LINKAGE/TRANSMISSION

Measure the I.D. of the shift fork.

SERVICE LIMIT: 14.05 mm (0.553 in)

Measure the thickness of the shift fork shaft.

SERVICE LIMIT: 4.5 mm (0.18 in)

Measure the O.D. of the shift fork shaft.

SERVICE LIMIT: 13.90 mm (0.547 in)

SERVICE LIMIT

M4	28.10 mm (1.106 in)
M5	28.08 mm (1.105 in)
C1	28.10 mm (1.106 in)
C2	28.10 mm (1.106 in)

Measure the I.D. and O.D. of each gear housing.

Inspect the shift drum grooves and replace the drum if they are damaged or show excessive wear.

M4 O.D.	27.50 mm (1.083 in)
M4 I.D.	23.10 mm (0.910 in)
C1 O.D.	24.50 mm (0.965 in)
C1 I.D.	20.10 mm (0.791 in)
C2 O.D.	27.50 mm (1.083 in)
C2 I.D.	23.10 mm (0.910 in)

SERVICE LIMIT: 0.10 mm (0.004 in)




Measure the main shaft and countershaft O.D.

Inspect the shift shaft and springs for wear or damage.

A (M4)	24.50 mm (0.965 in)
B (Main shaft)	23.10 mm (0.910 in)
C (C1)	24.50 mm (0.965 in)
D (C2)	27.50 mm (1.083 in)

SERVICE LIMIT

M4	0.10 mm (0.004 in)
C1	0.10 mm (0.004 in)
C2	0.10 mm (0.004 in)




TRANSMISSION ASSEMBLY


Check the gears for freedom of movement or rotation on the shaft.

Check that the snap rings are seated in the grooves.

SERVICE LIMIT: 0.5 mm (0.019 in)




Align the hole in the M5 gear bushing with the hole in the mainshaft when installing.




SHIFT LINKAGE/TRANSMISSION


Install the mainshaft and countershaft into the left crankcase together.



Install the gearshift drum.
Install the shift forks as shown.




Insert the shift fork shaft into the shift forks and align the center shift fork set bolt holes.



Install a new lock washer and shift fork set bolt.
Tighten the set bolt and bend up the lock washer tabs against the bolt head.


TORQUE: 13–17 N·m (1.3–1.7 kg·m, 9–12 ft·lb)



SHIFT LINKAGE/TRANSMISSION


Assemble the shift spindle.

Align the return spring with the pin bolt and install the shift spindle while pulling the shift plate.



CRANKCASE ASSEMBLY


Install the three dowel pins and a new gasket.



Assemble the right and left crankcases being careful to align the dowel pins and shafts.

CAUTION


- *Don't force the crankcase halves together; if there is excessive force required, something is wrong. Remove the right crankcase and check for misaligned parts.*



Install and tighten the left crankcase bolts in a crisscross pattern in 2–3 steps.

TORQUE: 10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb)

(1) LEFT CRANKCASE




SHIFT LINKAGE/TRANSMISSION

Install and tighten the right crankcase bolts in a crisscross pattern in 2–3 steps.

TORQUE: 10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb)

(1) RIGHT CRANKCASE




Align the hole in the stopper plate with the dowel pin on the gearshift drum and install the stopper plate. Apply locking agent to the threads of the stopper plate bolt and tighten the bolt.

TORQUE: 10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb)

Install the stopper arm, spring and bolt. Tighten the arm bolt.

TORQUE: 22–28 N·m (2.2–2.8 kg·m, 16–20 ft·lb)


Install the gearshift pedal and check the transmission for smooth shifting.



Install the cam chain drive sprocket.

NOTE

- The cam chain drive sprocket will only go on one position because of extra-wide aligning spline.




Install the cam chain.

Install the cam chain tensioner slipper with the washer, collar and bolt.

TORQUE: 10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb)

Apply thread lock agent to the tensioner mounting bolt threads.




SHIFT LINKAGE/TRANSMISSION


Install the primary drive gear with the OUT mark facing out.

NOTE

- The primary drive gear, pulse generator rotor, and oil pump drive gear will only go on in one position because of the extra-wide aligning spline.



Install the pulse generator rotor and oil pump drive gear.



Install the lock washer with the OUTSIDE mark facing out. Temporarily install the outer guide and clutch outer onto the mainshaft.

Install the gear holder between the primary drive gear and the driven gear.

TOOL:

Gear holder 07724-0010100

Install the drive gear lock nut and tighten it to the specified torque.

TORQUE: 70–80 N·m (7.0–8.0 kg·m, 51–58 ft·lb)

Remove the gear holder.



Install the pulse generator.

Check the air gap.


AIR GAP: 0.8 mm (0.03 in)

Install the following:

- oil pump (page 8-12).
- kick starter assembly (page 8-16).
- oil filler screen (page 2-4).
- clutch assembly (page 8-17).
- oil pump driven gear.
- starter driven gear (page 18-4).
- flywheel (page 18-4).



CRANKSHAFT/BALANCER
VILEBREQUIN/EQUILIBREUR
KURBELWELLE/BALANCER



11. CRANKSHAFT/BALANCER

SERVICE INFORMATION	11-1	CRANKSHAFT/BALANCER REMOVAL	11-2
TROUBLESHOOTING	11-1	BALANCER/CRANKSHAFT INSTALLATION	11-5

SERVICE INFORMATION

GENERAL

- The crankcase must be separated to repair the crankshaft, connecting rod, transmission and balancer. To separate the crankcase, refer to section 10.
- If the crankshaft is removed from the left crankcase, replace the left crankshaft bearing.

SPECIFICATIONS

ITEM		STANDARD	SERVICE LIMIT
Crankshaft	Connecting rod big end side clearance	0.050–0.650 mm (0.0020–0.0256 in)	0.80 mm (0.031 in)
	Connecting rod big end radial clearance	0.006–0.018 mm (0.0002–0.0007 in)	0.05 mm (0.002 in)
	Crankshaft runout	—	0.05 mm (0.002 in)

11

TOOLS

SPECIAL

Bearing puller	07931–MK20100
Universal bearing puller	07631–0010000
Attachment	07960–1870100
Crankshaft puller	07935–KF00001
Threaded adapter	07931–KF00200
Puller shaft	07931–ME40000
Assembly collar	07931–KF00100
Attachment	07946–6790200

COMMON

Driver	07749–0010000
Attachment, 72 x 75 mm	07746–0010600
Pilot, 35 mm	07746–0040800
Pilot, 40 mm	07746–0040900
Attachment, 35 mm I.D.	07746–0030400


TROUBLESHOOTING

Excessive noise

- Crankshaft
 - Worn connection rod bearings
 - Bent connecting rod
 - Worn crankshaft bearings
- Balancer
 - Improper installation

CRANKSHAFT/BALANCER REMOVAL

Separate the crankcase (page 10-3).
Remove the balancer.
Remove the transmission (page 10-5).



Remove the crankshaft from the left crankcase with a press or crankshaft puller.


CAUTION

- Be careful not to damage the crankcase gasket surface.
- Set up the tool plate with the special tool parallel to the left crankcase surface.

TOOL:

Crankshaft puller

07935-KF00001



Remove the left crankshaft bearing with a bearing puller if it is removed with the crankshaft. Discard the bearing.

CAUTION

- Always replace the left bearing with a new one if it is removed with the crankshaft.

TOOLS:

Bearing puller


07931-MK20100

Universal bearing puller


07631-0010000

Attachment

07960-1870100



Remove the snap ring and washer.
Remove the sub balancer gear.



CRANKSHAFT/BALANCER


CRANKSHAFT INSPECTION

Measure the crankshaft runout.

Support the crankshaft at points A and B, and then measure the points C and D.


SERVICE LIMIT: 0.05 mm (0.002 in)

If runout exceeds the service limit, replace the crankshaft.




Measure the connecting rod big end side clearance with a feeler gauge.

SERVICE LIMIT: 0.80 mm (0.031 in)




Measure the radial clearance at the connecting rod big end, at two points in the directions indicated by the arrows.

SERVICE LIMIT: 0.05 mm (0.002 in)



Spin the crankshaft bearing by hand and check for play.


The bearing must be replaced if it is noisy or has excessive play.



CRANKSHAFT/BALANCER

BALANCER INSPECTION


Inspect the balancer gear springs for wear or damage.



CRANKSHAFT BEARING REPLACEMENT


Drive out the right crankshaft bearing.

(1) RIGHT CRANKCASE BEARING



Install the bearing plate onto the left crankcase.

(1) BEARING PLATE



Drive in a new bearings onto the crankcase.

TOOLS:

RIGHT CRANKCASE:

Driver 07749-0010000

Shaft bearing; Attachment, 72 x 75 mm 07746-0010600

Pilot, 35 mm 07746-0040800

LEFT CRANKCASE:


Driver 07749-0010000

Attachment 07946-6790200

Pilot, 40 mm 07746-0040900

(1) DRIVER

(3) LEFT CRANKCASE




CRANKSHAFT/BALANCER

BALANCER/CRANKSHAFT

INSTALLATION


Install the spring and sub-balancer gear onto the balancer gear, aligning the punch marks as shown.



Install the washer onto the sub-balancer gear.
Install the snap ring.

NOTE

- Seat the snap ring in the groove of the gear with the sharp edge facing towards outside.




Clean the crankcase mating surfaces before assembling and check for wear or damage.

NOTE

- If there is minor roughness or irregularities on the crankcase mating surfaces, dress them with an oil stone.
- After cleaning, lubricate the crankshaft bearings and other contacting surfaces with clean engine oil.

Install the threaded adaptor into the thread end of the crankshaft.


Position the crankshaft into the left crankcase.



Draw the crankshaft into the left crankcase with the crankshaft assembly tool noting the connecting rod location.
Remove the tool and the threaded adaptor.


TOOLS:

Threaded adaptor	07931-KF00200
Puller shaft	07931-ME40000
Assembly collar	07931-KF00100
Attachment, 35 mm I.D.	07746-0030400



Downloaded from www.Manualslib.com manuals search engine

FRONT WHEEL/SUSPENSION/STEERING
ROUE AV/SUSPENSION AV/DIRECTION
VORDERRAD/AUFHÄNGUNG/LENKUNG



12

12. FRONT WHEEL/SUSPENSION/STEERING

SERVICE INFORMATION	12-1	FRONT WHEEL	12-6
TROUBLESHOOTING	12-2	FRONT FORKS	12-11
HANDLEBARS	12-3	STEERING STEM	12-18

SERVICE INFORMATION

GENERAL

- A work stand or box is required to support the motorcycle.
- The front wheel uses a tubeless tire. For tubeless tire repairs, refer to the TUBELESS TIRE MANUAL.

SPECIFICATIONS


ITEMS		STANDARD	SERVICE LIMIT
Front axle runout		_____	0.2 mm (0.01 in)
Front wheel rim runout	Radial	_____	2.0 mm (0.08 in)
	Axial	_____	2.0 mm (0.08 in)
Front fork spring free length		436.8 mm (17.2 in)	428 mm (16.9 in)
Front fork tube runout		_____	0.2 mm (0.01 in)
Front fork oil level		283 mm (9.6 in)	_____

TORQUE VALUES

Steering bearing adjustment nut	Initial torque: 30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb) Final torque: 14–16 N·m (1.4–1.6 kg-m, 10–12 ft-lb)
Steering stem nut	80–120 N·m (8.0–12.0 kg-m, 58–87 ft-lb)
Front fork upper pinch bolt	9–13 N·m (0.9–1.3 kg-m, 7–9 ft-lb)
Front fork lower pinch bolt	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Handlebar pinch bolt	18–25 N·m (1.8–2.5 kg-m, 13–18 ft-lb)
Front axle	55–65 N·m (5.5–6.5 kg-m, 40–47 ft-lb)
Front axle holder nut	18–25 N·m (1.8–2.5 kg-m, 13–18 ft-lb)
Fork cap	15–30 N·m (1.5–3.0 kg-m, 11–22 ft-lb)
Front fork socket bolt	15–25 N·m (1.5–2.5 kg-m, 11–18 ft-lb)
Brake caliper bracket bolt	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Brake disc mount bolt	37–43 N·m (3.7–4.3 kg-m, 27–31 ft-lb)

TOOLS

SPECIAL

Ball race remover	07953-3330000
Ball race remover attachment	07953-KM10100
Steering stem driver	07946-MB00000
Fork seal driver	07747-0010100
Fork seal driver attachment	07947-KA20200
Attachment	07946-3290000
Attachment	07945-3330300  For ball race

COMMON

Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 15 mm	07746-0040300
Lock nut wrench, 30 x 32 mm	07716-0020400
Bearing remover shaft	07746-0050100
Bearing remover head, 15 mm	07746-0050400

TROUBLESHOOTING

Hard steering

- Steering stem nut too tight
- Faulty steering stem bearings
- Insufficient air in front tire

Steers to one side or does not track straight

- Bent front forks
- Bent front axle, wheel installed incorrectly

Front wheel wobbling

- Distorted rim
- Worn front wheel bearings
- Loose or broken spokes
- Faulty tire
- Axle not tightened properly

Soft suspension

- Weak fork springs
- Insufficient fluid in front forks
- Incorrect fork air pressure

Hard suspension

- Incorrect fluid weight in front forks
- Incorrect fork air pressure
- Fork tube bent

Front suspension noise


- Slider binding
- Insufficient fluid in forks
- Loose front fork fasteners

HANDLEBARS


RIGHT HANDLEBAR REMOVAL

Disconnect the front brake switch wires from the switch.
Remove the front brake master cylinder by removing the holder bolts.

(1) FRONT BRAKE SWITCH WIRES




Remove the right handlebar switch housing screws.




Disconnect the throttle cables and remove the right handlebar switch.

(1) THROTTLE CABLES




Hold the handle weight with pliers and shop towel, and remove the handle weight attaching screw and the weight.

(1) HANDLE WEIGHT




FRONT WHEEL/SUSPENSION/STEERING

Remove the throttle grip. Remove the handlebar retainer ring. Loosen the handlebar pinch bolt and remove the right handlebar from the fork tube.



LEFT HANDLEBAR REMOVAL


Disconnect the clutch switch wires from the switch. Remove the clutch lever bracket from the left handlebar by removing the holder bolts.



Remove the left handlebar switch housing screws.



Disconnect the choke cable from the choke lever. Remove the retainer ring, loosen the left handlebar pinch bolt and remove the left handlebar from the fork tube.



RIGHT HANDLEBAR INSTALLATION

Install the right handlebar onto the fork tube and on the top bridge, aligning the pin on the bottom of the handlebar with the slit of the top bridge.

Put the pin of the handlebar to the rear surface of the slit and tighten the handlebar pinch bolt.

TORQUE: 18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)

Install the handlebar retainer ring.

Install the handle weight and attaching screw to the handlebar. Hold the weight with pliers and shop towel, and tighten the attaching screw.

Connect the throttle cables and apply grease to the throttle cable ends.

Install the right handlebar switch housing, aligning the locating pin of the housing with the hole in the handlebar.

Tighten the forward screw first, then tighten the rear screw.



Place the front brake master cylinder on the handlebar and install the master cylinder holder with the UP mark facing up. Align the punch mark on the handlebar with the end of the holder, and tighten the upper bolt first then tighten the lower bolt.

Connect the front brake switch wires.

LEFT HANDLEBAR INSTALLATION


Install the left handlebar onto the fork tube in the same manner as right handlebar.

Connect the choke cable to the choke lever and apply grease to the choke cable end.




FRONT WHEEL/SUSPENSION/STEERING

Install the left handlebar switch housing, aligning the locating pin of the housing with the hole in the handlebar. Tighten the forward screw first, then tighten the rear screw.




Install the clutch lever on the handlebar and install the master cylinder holder with the UP mark facing up. Align the punch mark on the handlebar with the end of the holder, and tighten the upper bolt first then tighten the lower bolt. Connect the clutch switch wires.



FRONT WHEEL

REMOVAL

Remove the speedometer cable set screw and the speedometer cable.




Loosen the axle holder nut and loosen the axle.

Raise the front wheel, pull out the axle and remove the front wheel.

NOTE

- Do not operate the front brake lever after removing the front wheel. To do so will cause difficulty in refitting the brake disc between the brake pads.




FRONT WHEEL/SUSPENSION/STEERING

INSPECTION AXLE

Set the axle in V blocks and measure the runout.
The actual runout is 1/2 of the total indicator reading.


SERVICE LIMIT: 0.2 mm (0.01 in)



WHEEL BEARING

Check the wheel bearing play by placing the wheel on a truing stand and spinning the wheel by hand.


Replace the bearings with new ones if they are noisy or have excessive play.



WHEEL

Check the rim runout by placing the wheel on a truing stand. Then spin the wheel by hand, and read the runout using a dial indicator gauge.

SERVICE LIMIT: 2.0 mm (0.08 in)



WHEEL BALANCE


CAUTION

- Wheel balance directly affects the stability, handling and overall safety of the motorcycle. Always check balance when the tire has been removed from the rim.

NOTE

- For optimum balance, the tire balance mark (a paint dot on the side wall) must be located next to the valve stem. Remount the tire if necessary.

(1) TIRE BALANCE MARK



FRONT WHEEL/SUSPENSION/STEERING


Mount the wheel, tire and brake disc assembly in an inspection stand.

Spin the wheel, allow it to stop, and mark the lowest (heaviest) part of the wheel with chalk.

Do this two or three times to verify the heaviest area. If the wheel is balanced, it will not stop consistently in the same position.

To balance the wheel, install wheel weight on the highest side of the rim, the side opposite the chalk marks. Add just enough weight so the wheel will no longer stop in the same position when it's spun.


Do not add more than 60 grams (rear wheel 60 grams).



DISASSEMBLY

Remove the right and left dust seals and speedometer gear retainer.

Remove the brake disc mount bolts and disc.




Remove the wheel bearings and distance collar from the hub.

NOTE

- Never reinstall old bearings; once the bearings have been removed, they must be replaced with new ones.

TOOLS:

Bearing remover head, 15 mm 07746-0050400
Bearing remover shaft 07746-0050100




ASSEMBLY

WARNING

- Do not get grease on the brake disc or stopping power will be reduced.

NOTE

- The front wheel uses a tubeless tire.
For tubeless tire repairs, refer to the Tubeless Tire Manual.




FRONT WHEEL/SUSPENSION/STEERING

Drive in the left bearing.

TOOLS:


Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 15 mm	07746-0040300



Install the distance collar and drive in the right bearing.

TOOLS:

Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 15 mm	07746-0040300



Install the speedometer gear retainer into the wheel hub, aligning the tangs with the slots.


Lubricate the inside of the dust seal and install it.

Install the brake disc onto the wheel hub.

Apply thread lock agent to the disc mount bolt threads.


Tighten the brake disc mount bolts.

TORQUE: 37-43 N·m (3.7-4.3 kg·m, 27-31 ft·lb)



Apply grease to the inside of the dust seal.

Install the right dust seal and side collar.



FRONT WHEEL/SUSPENSION/STEERING

Pack the speedometer gearbox with the grease and install the plain washers and drive gear.

TOOLS:

Driver

Attachment: 42 x 40 mm

Photo: 12 mm

Install the speedometer gearbox in the wheel hub, aligning the tangs with the slots.

Clean the brake disc with a high quality degreasing agent.

INSTALLATION

Fit the caliper over the disc, taking care not to damage the brake pads.

Position the tang on the speedometer gearbox against the lug on the left fork leg.

Insert the axle through the wheel hub.





Install the axle holder with the arrow pointing forward.
Install the holder nuts and tighten the nuts lightly.

Tighten the axle to the specified torque.

TORQUE: 55–65 N·m (5.5–6.5 kg·m, 40–47 ft·lb)

Tighten the axle holder nuts; the forward nut first, then the rear nut.


TORQUE: 18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)



FRONT WHEEL/SUSPENSION/STEERING

Connect the speedometer cable and secure it with the set screw.


With the front brake applied, pump the front forks up and down several times to seat the axle and check front brake operation.




FRONT FORKS

REMOVAL

Remove the caliper bracket mounting bolts.
Remove the front wheel (page 12-6).




Remove the brake hose clamp.
Remove the front fender.



Remove the retainer rings and loosen the pinch bolts.
Remove the right and left handlebars from the fork tubes.


NOTE

- After removing the right handlebar, place it so that the master cylinder is level.




FRONT WHEEL/SUSPENSION/STEERING

Loosen the front fork lower pinch bolt.



Loosen the front fork upper pinch bolt and the headlight stay pinch bolts.
Remove the turn signal stay mount bolt and nut.
Remove the front fork, while rotating the fork tube by hand.



DISASSEMBLY


Hold the fork tube in a vise, with soft jaws or a shop towel and remove the fork cap.

CAUTION

- Be careful not to damage the fork tube's sliding surface.


WARNING

- The cap is also under spring pressure. Use care when removing and wear eye and face protection.



Remove the spacer, washer and fork spring.

Pour out the fork fluid by pumping the fork up and down several times.




FRONT WHEEL/SUSPENSION/STEERING


Hold the fork slider in a vise with soft jaws or a shop towel.
Remove the socket bolt with a hex wrench.

NOTE


- Temporarily install the spring, spacer and fork cap if difficulty is encountered in removing the bolt.



Remove the dust seal and snap ring.



Pull the fork tube out until resistance from the slider bushing is felt. Then move it in and out, tapping the bushing lightly until the fork tube separates from the slider. The slider bushing will be forced out by the fork tube bushing.




Remove the oil seal, back-up ring and slider bushing.

NOTE

- Don't remove the fork tube bushing if it does not require replacement.

Remove the oil lock piece and stopper ring from the piston.
Remove the piston from the fork tube and the rebound spring from the piston.



FRONT WHEEL/SUSPENSION/STEERING


INSPECTION

FORK SPRING FREE LENGTH

Measure the fork spring free length.

SERVICE LIMIT: 428 mm (16.9 in)


Replace the spring if it is shorter than the service limit.



FORK TUBE/FORK SLIDER/PISTON

Check the fork tube, fork slider and piston for score marks, scratches, or excessive or abnormal wear.
Replace any components which are worn or damaged.


Check the fork piston ring for wear or damage.
Check the rebound spring for fatigue or damage.



BUSHING/BACK-UP RING


Visually inspect the slider and fork tube bushings.
Replace the bushings if there is excessive scoring or scratching, or if the teflon is worn so that the copper surface appears on more than 3/4 of the entire surface.

Check the back-up ring; replace it if there is any distortion at the points shown.



Set the fork tube on V-blocks and measure the runout.
Take 1/2 of the total indicator reading to determine the actual runout.

SERVICE LIMIT: 0.20 mm (0.008 in)




FRONT WHEEL/SUSPENSION/STEERING

ASSEMBLY


Clean all parts with non-flammable or high flash point solvent.

VERSCHLEISSSTÄRKE: 430 mm
Die Feder ist ein einseitig wirkendes Feder-System. Die Feder ist ein einseitig wirkendes Feder-System. Die Feder ist ein einseitig wirkendes Feder-System.

Time: 10 min
Check the rebound spring for a wide bounce and check the rebound spring for a wide bounce and check the rebound spring for a wide bounce.



Insert the rebound spring and piston into the fork tube.
Install the stopper ring and place the oil lock piece on the end of the piston.
Insert the fork tube into the slider.



FRONT WHEEL/SUSPENSION/STEERING

Apply a locking agent to the socket bolt threads and torque the bolt.

NOTE

- Temporarily install the fork springs, seat washer, spacer and fork tube cap to tighten the socket bolt.

TORQUE: 15–25 N·m (1.5–2.5 kg·m, 11–18 ft·lb)

Place the slider bushing over the fork tube and rest it on the slider. Put the back-up ring and an old bushing or equivalent tool on top.

Drive the bushing into place with the seal driver and remove the old bushing or equivalent tool.

Coat a new oil seal with ATF and install it with the seal markings facing up. Drive the seal in with the seal driver.

TOOLS:

Fork seal driver
Attachment

07747–0010100
07947–KA20200

NOTE

- Wrap the fork tube groove and top edge with vinyl tape to prevent damage to the oil seal lip, during installation.

Install the snap ring into the groove in the slider.
Install the dust seal.


Pour in the specified amount of ATF.

SPECIFIED FLUID: ATF


CAPACITY: 283 cc (9.6 ozs)

NOTE


- Do not overfill or the suspension will be stiff.



(1) FORK SEAL DRIVER



(2) ATTACHMENT




(3) DUST SEAL

(4) SNAP RING


(5) OIL SEAL

(6) BACK UP RING




FRONT WHEEL/SUSPENSION/STEERING

Wipe oil off the spring thoroughly using a clean cloth.
Install the fork spring with the taper ends facing down.
Install the seat washer and spacer in the fork tube.



Install the O-ring on the fork cap.
Install the fork cap onto the fork tube and tighten the cap to the specified torque.


TORQUE: 15–30 N·m (1.5–3.0 kg·m, 11–22 ft·lb)



INSTALLATION

Slip the tube through the steering stem, turn signal stay, headlight stay and fork top bridge.

Align the lower groove of the fork tube with the top surface the fork top bridge.




Tighten the front fork upper and lower pinch bolts.

TORQUE:

Upper: 9–13 N·m (0.9–1.3 kg·m, 7–9 ft·lb)

Lower: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)




FRONT WHEEL/SUSPENSION/STEERING

Align upper end of the headlight stay with the groove on the fork tube.

Tighten the headlight stay pinch bolts.

Install the turn signal stay as shown and tighten the nut.

Install the handlebars (page 12-5).




Install the front fender and route the speedometer cable through the clamps correctly.

Install the brake hose clamp and clamp the brake hose.

Install the brake caliper onto the left fork slider and tighten the caliper mounting bolts.

TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)

Install the front wheel (page 12-10).



STEERING STEM

REMOVAL


Remove the headlight (page 19-2).

Disconnect all couplers and connectors in the headlight case.

Remove the headlight case mounting bolts and remove the headlight case.


Remove the right and left turn signal stays.

Disconnect the speedometer cable.




Remove the fuse holder cover mount screws and cover.

Remove the fuse holder mount screws and holder.




FRONT WHEEL/SUSPENSION/STEERING

Remove the instrument cluster mount bolts and remove the instrument cluster.




Remove the right and left handlebars (page 12-5).
Remove the front wheel (page 12-6) and front fender (page 12-11).
Remove the horns and horn bracket by removing the front fork lower pinch bolts.



Remove the steering stem nut.
Remove the front forks (page 12-11).
Remove the front fork top bridge.

TOOL:

Lock nut wrench, 30 x 32 mm 07716-0020400




Remove the steering head bearing adjustment nut, upper bearing inner race, steel balls and steering stem.

NOTE

- Be careful not to drop and lose any of the steel balls.

TOOL:

Steering stem socket 07916-3710100



FRONT WHEEL/SUSPENSION/STEERING


BEARING REPLACEMENT

Check the steel balls and bearing races for wear or damage.

NOTE

- Replace the steel balls and bearing races as a set.


Remove the lower bearing inner race, dust seal and washer.



Remove the lower bearing outer race with special tools.

TOOLS:


Ball race remover	07953-3330000
Ball race remover attachment	07953-KM10100



Remove the upper bearing outer race with a special tool.

TOOL:


Ball race remover	07953-3330000
-------------------	---------------



Drive a new upper bearing outer race into the steering head.

TOOLS:

Driver	07749-0010000
Attachment	07946-3290000




FRONT WHEEL/SUSPENSION/STEERING

Drive a new lower bearing outer race into the steering head.

TOOLS:


Driver 07749-0010000
Attachment 07945-3330300



Install the washer and dust seal and press a new lower bearing inner race over the stem with a special tool.


TOOL:

Steering stem driver 07946-MB00000



INSTALLATION

Pack the bearing cavities with bearing grease.
Install the 19 steel balls onto the lower bearing outer race.
Insert the steering stem into the steering head pipe.
Install the 18 steel balls onto the upper bearing outer race.
Install the upper bearing inner race and steering head bearing adjustment nut.




Tighten the steering stem head bearing adjustment nut to the initial torque.

TORQUE: 30-40 N·m (3.0-4.0 kg·m, 22-29 ft·lb)

TOOL:

Steering stem socket 07916-3710100



FRONT WHEEL/SUSPENSION/STEERING

Turn the steering stem lock-to-lock 5 times to seat the bearing. Loosen the adjustment nut, then tighten it to the final torque.

TORQUE: 14–16 N·m (1.4–1.6 kg·m, 10–12 ft·lb)

Then, back it out 1/8 turn. Make sure that there is no vertical movement and the stem rotates freely.

Install the fork top bridge and steering stem nut. Temporarily install the front forks with headlight stays (page 12-17).

Tighten the steering stem nut.

TORQUE: 80–120 N·m (8.0–12.0 kg·m, 58–87 ft·lb)

TOOL:

Lock nut wrench, 30 x 32 mm 07716–0020400

Install the horn bracket.

Tighten the upper and lower front fork pinch bolts (page 12-17).

Install the front fender, brake caliper (page 12-18) and front wheel (page 12-10).

Check the steering head bearing preload (page 12-23).

Route the fuse holder wire harness and install the instrument cluster and fuse holder.

Install the right and left turn signal stays (page 12-18).

Install the headlight case.

Connect the color coded wires and the coupler.

For wire harness routing, see pages 1-11 to 12.

Align the index mark on the headlight case with the lower slit in the headlight stay.

NOTE

- When installing the headlight stay, align the upper end of the headlight stay with the groove on the fork tube.

Connect the speedometer cable and install the horns.

Install the right and left handlebars (page 12-3).

Install the fuse holder cover.

Install the headlight and adjust the headlight aim.

(1) STEERING STEM

(1) HEADLIGHT STAY

(2) LOCK NUT WRENCH

(1) GROOVE

(2) SLITS

(3) HEADLIGHT STAY

(4) INDEX MARK

(1) HANDLEBARS

(2) FUSE HOLDER COVER

FRONT WHEEL/SUSPENSION/STEERING

STEERING HEAD BEARING PRELOAD

Install the front forks (page 12-11).

Install the front wheel (page 12-6).

Raise the front wheel off the ground and place a stand under the engine.

Position the steering stem straight ahead position.

Hook a spring balancer to the fork tube and measure the steering head bearing preload.


NOTE

- Make sure there is no cable and wire harness interference.


The preload should be within 1.1–1.7 kg (2.4–3.7 lbs) for right and left turns.

If the readings do not fall within the limits, lower the front wheel on the ground and adjust the bearing adjustment nut.

After making sure the bearing preload, install the removed parts in the reverse order of removal.



REAR WHEEL/BRAKE/SUSPENSION
ROUE AR/FREIN AR/SUSPENSION AR
HINTERRAD/BREMSE/AUFHÄNGUNG



13. REAR WHEEL/BRAKE/SUSPENSION

SERVICE INFORMATION	13-1	BRAKE PEDAL	13-10
TROUBLESHOOTING	13-2	REAR SHOCK ABSORBERS	13-11
REAR WHEEL	13-3	SWING ARM	13-13
REAR BRAKE	13-8		

SERVICE INFORMATION

GENERAL

- A work stand or box is required to support the motorcycle.
- The rear wheel uses a tubeless tire. For tubeless tire repairs, refer to the TUBELESS TIRE MANUAL.

SPECIFICATIONS

ITEM	STANDARD	SERVICE LIMIT
Rear shock absorber spring free length	224.2 mm (8.83 in)	219.5 mm (8.64 in)
Rear wheel rim runout	Radial	2.0 mm (0.08 in)
	Axial	2.0 mm (0.08 in)
Rear axle runout		0.2 mm (0.01 in)
Rear brake drum I.D.	140 mm (5.5 in)	141 mm (5.6 in)
Rear brake lining thickness	5.0 mm (0.19 in)	2.0 mm (0.08 in)

TORQUE VALUES

Swing arm pivot bolt	80–100 N·m (8.0–10.0 kg-m, 58–72 ft-lb)
Rear axle nut	80–100 N·m (8.0–10.0 kg-m, 58–72 ft-lb)
Rear shock absorber (upper)	40–50 N·m (4.0–5.0 kg-m, 22–29 ft-lb)
(lower)	40–50 N·m (4.0–5.0 kg-m, 22–29 ft-lb)
Final driven sprocket nut	60–70 N·m (6.0–7.0 kg-m, 43–51 ft-lb)
Chain slider mounting screw	5–7 N·m (0.5–0.7 kg-m, 4–5 ft-lb)
Damper rod lock nut	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Footpeg bracket mount bolt	18–25 N·m (1.8–2.5 kg-m, 13–18 ft-lb)
Rear brake arm bolt	8–12 N·m (0.8–1.2 kg-m, 6–9 ft-lb)

TOOLS

SPECIAL

Bearing remover set	07936–3710001
Remover spindle assembly	07936–3710600
Remover handle	07936–3710100
Remover weight	07741–0010201

COMMON

Driver	07749–001000
Attachment, 32 x 35 mm	07746–0010100
Attachment, 42 x 47 mm	07746–0010300
Pilot, 17 mm	07746–0040400
Pilot, 20 mm	07746–0040500
Bearing remover head, 17 mm	07746–0050500
Bearing remover shaft	07746–0050100
Shock absorber compressor	07959–3290001

13

- Tire pressure incorrect
- Faulty tire
- Bent rim
- Loose wheel bearing
- Swingarm bushing worn

- Weak spring
- Shock absorbers improperly adjusted

- Shock absorbers improperly adjusted
- Bent shock absorber damper rod

- Loose fasteners
- Worn shocks

REAR WHEEL/BRAKE/SUSPENSION

REAR WHEEL

REMOVAL

Raise the rear wheel off the ground by placing a jack or block under the engine.

Loosen the drive chain adjuster lock nuts and adjusting bolts on both sides.



Loosen the axle nut.

Disconnect the brake rod from the brake arm by removing the brake adjusting nut.

Remove the brake torque link attaching bolt and nut, and disconnect the brake torque link from the brake panel.

Push the wheel forward and remove the drive chain from the driven sprocket.

Remove the axle nut and axle, and remove the rear wheel.




INSPECTION

AXLE

Set the axle on V blocks and measure the runout. The actual runout is 1/2 of the total indicator reading.


SERVICE LIMIT: 0.2 mm (0.01 in)



REAR WHEEL RIM RUNOUT

Check the rim runout by placing the wheel on a truing stand. Turn the wheel by hand and measure the runout using a dial indicator.


SERVICE LIMIT: 2.0 mm (0.08 in)



REAR WHEEL/BRAKE/SUSPENSION


WHEEL BEARING PLAY

Check the wheel bearing play by placing the wheel in a truing stand and spinning the wheel by hand.
Replace the bearings with new ones if they are noisy or have excessive play.



Remove the brake panel from the rear wheel (page 13-8).
Remove the driven flange from the wheel hub.

(1) DRIVEN FLANGE




Replace the damper rubbers if they are damaged or deteriorated.

Remove the O-ring.

(1) DAMPER RUBBER


(2) O-RING



Do not separate the driven sprocket and driven flange, unless replacement of the driven sprocket or flange is necessary.
Check the condition of the final driven sprocket teeth (page 3-10).

(1) DRIVEN FLANGE

(2) DRIVEN SPROCKET




REAR WHEEL/BRAKE/SUSPENSION


Drive out the wheel bearings with the special tools.

TOOLS:

Bearing remover head, 17 mm 07746-0050500
Bearing remover shaft 07746-0050100



Remove the dust seal from the driven flange.
Remove the snap ring and drive the driven flange bearing out of the flange.




ASSEMBLY

WARNING

- Do not get grease on the brake drum or stopping power will be reduced.

NOTE

- The rear wheel uses a tubeless tire. For tubeless tire repairs, refer to the Tubeless Tire Manual.




REAR WHEEL/BRAKE/SUSPENSION

Drive in a new left bearing.

TOOLS:


Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 17 mm	07746-0040400



Install the distance collar and drive a new right bearing in.

TOOLS:


Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 17 mm	07746-0040400




Place a new flange bearing with the plain sealed end facing out onto the flange hub.
Drive the driven flange bearing in the flange squarely.

TOOLS:

Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 17 mm	07746-0040400




Install the snap ring, and the spacer from the right side.



REAR WHEEL/BRAKE/SUSPENSION

Install the O-ring onto the left wheel hub.
Install the damper rubbers and the driven flange into the hub.

(1) O-RING



(2) DRIVEN FLANGE

If the driven sprocket was removed from the flange, tighten the driven sprocket nuts.


TORQUE: 60–70 N·m (6.0–7.0 kg-m, 43–51 ft-lb)

Apply grease to the inside of the dust seal.

Install the dust seal and collar in the wheel hub left side.

Install the brake panel onto the right wheel hub.

(1) LEFT COLLAR




INSTALLATION

Position the rear wheel into the swing arm.
Install the drive chain on the driven sprocket.
Install the right collar onto the brake panel and the drive chain adjusters onto the swing arm.
Insert the axle from the left side.
Install the axle nut and tighten it lightly.

(1) BRAKE PANEL

(2) RIGHT SIDE COLLAR




Connect the brake rod to the brake arm.
Install the brake torque link to the brake panel.
Tighten the nut and install the cotter pin.
Adjust the drive chain slack (page 3-9).
Tighten the axle nut to the specified torque.

TORQUE: 80–100 N·m (8.0–10.0 kg-m, 58–72 ft-lb)

Adjust the rear brake (page 3-12).

(1) AXLE NUT

(2) BRAKE TORQUE LINK



(3) COTTER PIN

REAR BRAKE

BRAKE PANEL REMOVAL

Remove the front wheel (page 13-3).
Remove the brake panel from the wheel hub.

INSPECTION

REAR BRAKE DRUM I.D.

Measure the rear brake drum I.D.

SERVICE LIMIT: 141 mm (5.6 in)

BRAKE LINING

Measure the rear brake lining thickness.





SERVICE LIMIT: 2.0 mm (0.08 in)

REAR BRAKE SHOE REPLACEMENT

Remove the brake arm, wear indicator plate and the brake shoes.

Remove the special washer and brake cam from the brake panel.

Check the brake cam seals for wear or damage and replace if necessary.



REAR WHEEL/BRAKE/SUSPENSION

Install the special washer by aligning its groove with the tab on the brake panel.

Apply grease to the anchor pins and brake cam.

WARNING

- *Contaminated brake linings reduce stopping power. Keep grease off the brake linings. Wipe any excess grease off the cam.*

Install the following

- brake cam.
- brake shoes and springs.

Align the wear indicator tab with the cut-out in the brake cam and install the indicator over the cam.

Install the brake arm aligning the punch mark with the cam punch mark.





Tighten the brake arm bolt.

TORQUE: 8–12 N·m (0.8–1.2 kg·m, 6–9 ft·lb)

BRAKE PANEL INSTALLATION

Install the brake panel.


Install the rear wheel (page 13-7).




BRAKE PEDAL

REMOVAL


Disconnect the brake rod from the brake arm.




Remove the right foot peg bracket bolts.



Unhook the rear brake switch spring from the actuating arm.
Remove the right foot peg bracket.




Unhook the rear return spring and remove the cotter pin,
joint pin and brake rod.
Remove the rear brake pedal from the actuating arm.
Remove the actuating arm from the right foot peg.



REAR WHEEL/BRAKE/SUSPENSION

INSTALLATION


The installation sequence is essentially the reverse order of removal.



Hook the rear brake switch spring to the actuating arm. Install the right foot peg bracket to the frame and tighten the mount bolts.

TORQUE: 18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)


Install the muffler-to-foot peg bracket bolt and nut. Install the rear brake pedal. Adjust the rear brake.



REAR SHOCK ABSORBERS

REMOVAL

Loosen the foot peg bracket mount bolts. Remove the shock absorber lower mount bolt and upper mount nut. Remove the shock absorber.



REAR WHEEL/BRAKE/SUSPENSION

DISASSEMBLY



Set the shock in the compressor and compress the spring by turning the compressor handle.

TOOL:

Shock absorber compressor

07959-3290001

Place the upper joint in a vise and pull the damper rod out. Separate the upper joint by rotating the damper rod lock nut in the direction as shown and remove the compressor. Remove the spring, spring guide and spring adjuster.




SHOCK ABSORBER SPRING INSPECTION

Measure the spring free length.

Replace the spring if it is shorter than the service limit.


SERVICE LIMIT: 219.5 mm (8.64 in)



ASSEMBLY

Place the spring adjuster, spring guide and spring onto the shock damper.

Set the shock in the compressor and compress the spring.




REAR WHEEL/BRAKE/SUSPENSION

Apply a locking agent to the rod threads and install the lock nut and upper joint.

Tighten the damper rod lock nut to the specified torque.

TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)

Remove the shock compressor.



INSTALLATION

Install the shock absorber, lower mount bolt, upper nut and washer.

Tighten the nut and bolt.


TORQUE:

Upper: 40–50 N·m (4.0–5.0 kg·m, 29–36 ft·lb)

Lower: 40–50 N·m (4.0–5.0 kg·m, 29–36 ft·lb)

Tighten the foot peg bracket mount bolts (page 13-11).

Turn the each spring adjuster to the same position and check the operation of the rear suspension (page 3-15).



SWING ARM

REMOVAL


Raise the rear wheel off the ground with a jack or block under the engine.

Remove the following parts:

- rear wheel (page 13-3).
- rear shock absorber lower mount bolts from the swing arm.
- drive chain cover.



Remove the swing arm pivot nut and bolt, and remove the swing arm from the frame.



PIVOT BUSHING REPLACEMENT

Remove the chain slider, dust covers and collar.
Remove the pivot bushings with the bearing remover set.

TOOLS:

Bearing remover set	07936-3710001
– Remover spindle assembly	07936-3710600
– Remover handle	07936-3710100
– Remover weight	07741-0010201

Check that the collar and bushings for abnormal wear.
Replace the chain slider if excessively worn.
Apply grease to the inside of the bushings and dust seal lips.

Drive the bushings into the swing arm.
Install the collar.


TOOLS:

Driver	07749-0010000
Attachment, 32 x 35 mm	07746-0010100
Pilot, 20 mm	07746-0040500

Install the chain slider and dust covers.
Tighten the chain slider mount screws.

TORQUE: 5–7 N·m (0.5–0.7 kg·m, 4–5 ft·lb)


(1) BEARING REMOVER SET




(1) DUST COVER/DUST SEAL

(2) BUSHING

(3) COLLAR




(1) DRIVER



(2) ATTACHMENT, 32 x 35 mm
PILOT, 20 mm

(1) DRIVE CHAIN SLIDER



(2) SCREWS

(3) DUST COVER

REAR WHEEL/BRAKE/SUSPENSION

INSTALLATION

Install the swing arm onto the frame and tighten the pivot nut.




TORQUE: 80–100 N·m (8.0–10.0 kg·m, 58–72 ft·lb)

Check the swing arm for smooth operation.

Install the following parts:

- shock absorber (page 13-13).
- rear wheel (page 13-7).
- chain cover.

After installation, grease the swing arm pivot bushing through the grease fitting on the swing arm.




HYDRAULIC BRAKE **FREIN HYDRAULIQUES** **HYDRAULISCHE BREMSEM**

INSTALLATION

Die Schwingen an den Rahmen montieren und die Lagerbohrungen
 Invert the swing arm and tighten the pivot bolts
 TORQUE: 80-100 N·m (8.0-10.0 kg-m, 58-72 ft·lb)

Install the following parts:
 - shock absorber (page 13-13)
 - rear wheel (page 13-7)



14. HYDRAULIC BRAKE

SERVICE INFORMATION	14-1	BRAKE PAD/DISC	14-5
TROUBLESHOOTING	14-2	FRONT BRAKE MASTER CYLINDER	14-7
BRAKE FLUID REPLACEMENT/ AIR BLEEDING	14-3	FRONT BRAKE CALIPER	14-10

SERVICE INFORMATION

GENERAL

- Use DOT 3 or 4 brake fluid.
- The front wheel can be removed without disconnecting the hydraulic system.
- Once the hydraulic systems have been opened, or if the brakes feel spongy, the system must be bled.
- Do not allow foreign material to enter the system when filling the reservoirs.
- Brake fluid will damage painted, plastic, and rubber parts, whenever handling brake fluid, protect the painted, plastic, and rubber parts by covering them with a rug. If fluid does get on these parts, wipe it off with a clean cloth.
- Always check brake operation before riding the motorcycle.

SPECIFICATIONS

ITEM	STANDARD	SERVICE LIMIT
Front disc thickness	5 mm (0.19 in)	4 mm (0.16 in)
Front disc runout	—	0.3 mm (0.01 in)
Front master cylinder I.D.	12.700–12.743 mm (0.4999–0.5017 in)	12.75 mm (0.512 in)
Front master piston O.D.	12.657–12.684 mm (0.4983–0.4994 in)	12.64 mm (0.498 in)
Front caliper piston O.D.	30.148–30.198 mm (1.1869–1.1889 in)	30.14 mm (1.187 in)
Front caliper cylinder I.D.	30.230–30.280 mm (1.1902–1.1921 in)	30.29 mm (1.193 in)

TORQUE VALUES

Hose bolt	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Caliper bleed valve	4–7 N·m (0.4–0.7 kg-m, 3–5 ft-lb)
Pin retainer	8–13 N·m (0.8–1.3 kg-m, 6–9 ft-lb)
Front brake disc	37–43 N·m (3.7–4.3 kg-m, 27–31 ft-lb)
Front caliper bracket	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Front caliper mount bolt	20–25 N·m (2.0–2.5 kg-m, 14–18 ft-lb)
Front caliper pivot bolt	25–30 N·m (2.5–3.0 kg-m, 18–22 ft-lb)

TOOL

SPECIAL

Snapping pliers	07914–3230001
-----------------	---------------

TROUBLESHOOTING

Brake lever soft or spongy

- Air bubbles in hydraulic system
- Low fluid level
- Hydraulic system leaking

Brake lever too hard

- Sticking piston(s)
- Clogged hydraulic system
- Pads glazed or worn excessively

Brakes drag

- Hydraulic system sticking
- Clogged master cylinder
- Sticking piston(s)

Brakes grab or pull to one side

- Pads contaminated
- Disc or wheel misaligned

Brakes chatter or squeal

- Pads contaminated
- Excessive disc runout
- Caliper installed incorrectly
- Disc or wheel misaligned

VERBODEN	TOEGestaan	TOEGestaan
Disc runout	0.00 - 0.01 mm	0.00 - 0.01 mm
Disc thickness	12.50 - 12.54 mm	12.50 - 12.54 mm
Disc runout	0.00 - 0.01 mm	0.00 - 0.01 mm
Disc thickness	12.50 - 12.54 mm	12.50 - 12.54 mm
Disc runout	0.00 - 0.01 mm	0.00 - 0.01 mm
Disc thickness	12.50 - 12.54 mm	12.50 - 12.54 mm
Disc runout	0.00 - 0.01 mm	0.00 - 0.01 mm
Disc thickness	12.50 - 12.54 mm	12.50 - 12.54 mm

COUPLES DE SERRAGE

Les couples de serrage indiqués sont des valeurs minimales. Les couples de serrage réels doivent être supérieurs ou égaux à ces valeurs.

UNITÉ

1 Nm = 0.737 lb-ft

BRAKE FLUID REPLACEMENT/ AIR BLEEDING

Check the fluid level with the master cylinder parallel to the ground.

CAUTION

- Do not remove the cover until the handlebar has been turned so that the reservoir is level.
- Do not mix different types of fluid; they are not compatible with each other.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

BRAKE FLUID DRAINING

Connect a bleed hose to the bleed valve.

Loosen the caliper bleed valve and pump the brake lever. Stop operating the lever when fluid stops flowing out of the bleed valve.

WARNING

- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake cleaning agent.

BRAKE FLUID FILLING

Connect the commercially available brake bleeder to the bleed valve.

Pump the brake bleeder and loosen the bleed valve. Add fluid when the fluid level in the master cylinder reservoir is low.

NOTE





- Check the fluid level often while bleeding the brakes to prevent air from being pumped into the system.
- Use only DOT 3 or 4 brake fluid from a sealed container.
- When using a brake bleeding tool, follow the manufacturer's operation instructions.

Repeat the above procedures until air bubbles do not appear in the plastic hose.

NOTE

- If air is entering the bleeder from around the bleed valve threads, seal the threads with teflon tape.

Close the bleed valve and operate the brake lever. If it feels spongy, bleed the system by performing the AIR BLEEDING procedure (page 14-4).



HYDRAULIC BRAKE

If a brake bleeder is not available, perform the following procedure:

Pump up the system pressure with the lever until there are no air bubbles in the fluid flowing out of the reservoir small hole and lever resistance is felt.

AIR BLEEDING

- 1) Squeeze the brake lever, then open the bleed valve 1/2 turn and close the valve.

NOTE

- Do not release the brake lever until the bleed valve has been closed.
- 2) Release the brake lever slowly and wait several seconds after it reaches the end of its travel.

Repeat steps 1 and 2 until bubbles cease to appear in the fluid at the end of the hose.

Tighten the bleed valve.

TORQUE: 4–7 N·m (0.4–0.7 kg·m, 3–5 ft·lb)




Fill the fluid reservoir to near full.

CAUTION

- Do not mix different types of fluid since they are not compatible.

WARNING

- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.



HYDRAULIC BRAKE

BRAKE PAD/DISC

PAD REPLACEMENT

NOTE





- Always replace the brake pads in pairs to assure even disc pressure.

Remove the pad pin retainer bolt.

Press the caliper against the disc to push the pistons all the way into the caliper.


Remove the caliper mount bolt and caliper pivot bolt.
Lift the caliper up and remove the caliper from the bracket.

Pull the two retainer pad pins and remove the pads from the caliper.




HYDRAULIC BRAKE

Position the pad spring in the caliper as shown.
Push the caliper pistons in all the way.




Install the new pads in the caliper.
Install the pad pins, one pad pin first, then install the other pin by pushing the pads against the caliper to depress the pad spring.




Place the pad pin retainer over the pad pins.
Push the retainer down to secure the pins.
Install the retainer bolt and tighten the bolt to the specified torque.

TORQUE: 8–13 N·m (0.8–1.3 kg·m, 6–9 ft·lb)



Apply silicone grease to the caliper pivot bolt and boot.

Make sure that the retainer clip is in position on the caliper bracket (page 14-12).



HYDRAULIC BRAKE

Install the caliper to the bracket so the disc is positioned between the pads, being careful not to damage the pads. Tighten the caliper mount bolt and caliper pivot bolt.

TORQUE:

CALIPER MOUNT BOLT:

20–25 N·m (2.0–2.5 kg·m, 14–18 ft·lb)

CALIPER PIVOT BOLT:

25–30 N·m (2.5–3.0 kg·m, 18–22 ft·lb)

BRAKE DISC INSPECTION DISC THICKNESS

Measure the thickness of the disc.

SERVICE LIMIT: 4.0 mm (0.16 in)

DISC WARPAGE

Remove the brake disc (page 12-8).

Set the brake disc on a surface plate and set up a dial indicator.

Measure the brake disc warpage.

SERVICE LIMIT: 0.3 mm (0.01 in)





FRONT BRAKE MASTER CYLINDER

DISASSEMBLY

Drain brake fluid from the hydraulic system (page 14-3).

Remove the brake lever and rear view mirror from the master cylinder.

Disconnect the brake hose from the master cylinder by removing the oil bolt.



HYDRAULIC BRAKE

CAUTION

- Do not remove the cover until the handlebar has been turned so that the reservoir is level.
- Do not mix different types of fluid; they are not compatible with each other.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.


NOTE

- When removing the brake hose bolt, cover the end of the hose to prevent contamination and secure the hose to prevent spilling fluid.

Remove the master cylinder from the handlebar by removing the holder.

Remove the boot from the piston.

Remove the circlip from the master cylinder body.




(1) SNAP RING PLIERS
07914-3230001



Remove the master piston, cups and spring.

Clean the master cylinder with brake fluid.




INSPECTION

MASTER CYLINDER I.D.

Check the master cylinder for scores, scratches or nicks.

Measure the master cylinder I.D.

SERVICE LIMIT: 12.75 mm (0.512 in)



HYDRAULIC BRAKE

MASTER PISTON O.D.

Measure the master piston O.D.

SERVICE LIMIT: 12.64 mm (0.498 in)

Check the primary and secondary cups for damage before assembly.

ASSEMBLY

CAUTION

- Handle the master cylinder piston, cylinder and spring as a set.
- Do not remove the cover until the handlebar has been turned so that the reservoir is level.
- Do not mix different types of fluid; they are not compatible with each other.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

Assemble the master cylinder. Coat all parts with clean brake fluid before assembly. Install the spring and valve together.

Dip the piston cup in brake fluid before assembly.

CAUTION

- When installing the cups, do not allow the lips to turn inside out. Be certain the circlip is seated firmly in the groove.

Install the clip and boot.

Place the master cylinder on the handlebar and install the holder with "up mark" on the holder up.

Align the punch mark on the handlebar with the end of the holder.

Tighten the top bolt first, then the bottom bolt.





Install the brake lever and rear view mirror.

Install the oil hose with the bolt and its two sealing washers.

Tighten the hose bolt.

TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)

Fill the reservoir to the upper level mark and bleed the brake system according to page 14-3.



FRONT BRAKE CALIPER

DISASSEMBLY

Place a container under the caliper and remove the oil hose.
Remove the caliper pivot bolt and caliper mount bolt.
Remove the front caliper.

CAUTION

- Do not remove the cover until the handlebar has been turned so that the reservoir is level.
- Do not mix different types of fluid; they are not compatible with each other.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

Remove the caliper pads (page 14-5).

Remove the collar, boot and pad spring.

CAUTION

Remove the piston. If necessary, apply compressed air to the caliper fluid inlet to get the piston out.
Place a shop rag under the caliper to cushion the pistons when they are expelled. Use the air in short spurt.

WARNING

- Do not bring the nozzle too close to the inlet.





Remove the piston seal by first pushing it into the cylinder as shown.

CAUTION

- Be careful not to damage the piston sliding surfaces when removing the seals.

Examine the piston and cylinder for scoring or scratches and replace if necessary.

Clean the caliper grooves with brake fluid.



HYDRAULIC BRAKE

INSPECTION

CALIPER PISTON O.D.

Check the piston and the cylinder for scoring or scratches.

Measure the O.D. of the pistons.

SERVICE LIMIT: 30.14 mm (1.187 in)

CALIPER CYLINDER I.D.

Measure the I.D. of the caliper bores.

SERVICE LIMIT: 30.29 mm (1.193 in)

Replace the caliper if necessary.

ASSEMBLY

WARNING

- A contaminated brake disc or pad reduces stopping power. Do not allow grease on the brake pads.

CAUTION

- Do not remove the cover until the handlebar has been turned so that the reservoir is level.
- Do not mix different types of fluid; they are not compatible with each other.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

Assemble the caliper in the reverse order of disassembly. The piston seals must be replaced with new one whenever removed. Lubricate the pistons and seals with a medium grade of Hi-Temperature silicone grease or brake fluid before assembly.

Be certain the piston seals are seated in the caliper groove. Place the pistons in the caliper with opening facing out.

Install the collar and its boots.

NOTE

- Fit the boot in the collar's groove properly.

Install the pad spring and the caliper pivot bolt.
Install the pads in the caliper and install the caliper.

Tighten the mount bolt.

TORQUE: 20–25 N·m (2.0–2.5 kg·m, 14–18 ft·lb)



Tighten the caliper pivot bolt.

TORQUE: 25–30 N·m (2.5–3.0 kg·m, 18–22 ft·lb)

Install the brake hose with the bolt.

TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)

Fill the brake fluid reservoir and bleed the front brake system (page 14-4).



CALIPER BRACKET DISASSEMBLY

Remove the speedometer cable clamp.

Remove the caliper mount bolts and remove the caliper.

Remove the two caliper bracket mount bolts and remove the caliper bracket.

Remove the boot and the pad spring from the caliper bracket, making sure that they are in good condition.



CALIPER BRACKET ASSEMBLY/INSTALLATION

Install the boot and the pad spring.

Attach the caliper bracket to the front fork.

TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)

Install the front caliper (page 14-11).




15. REAR FENDER/EXHAUST SYSTEM

REAR FENDER

Remove the mounting bolts. Slide the seat back and lift it off.
Remove the rear wheel (page 13-3).
Remove and separate rear fenders A and B.
Install in the reverse order of removal.

NOTE

- Before installing the seat, check that the rear fender is set on the frame cross member properly.




EXHAUST PIPE


WARNING

- Do not service the exhaust pipe or muffler while they are hot.

Remove the nuts attaching the pipe to the cylinder head.




Remove the exhaust pipe lower mount bolt and loosen the foot peg bracket bolts.




Remove the muffler mounting bolt and remove the exhaust pipe assembly.

Loosen the exhaust pipe and muffler clamp.
Separate the muffler from the exhaust pipe.
Install in the reverse order of removal.




NOTE


- After installing, make sure that there are no gas leaks.



IGNITION SYSTEM SYSTEME D'ALLUMAGE ZÜNDNLAKE



- (11) Bl: Black
- (12) G: Green
- (13) W: White
- (14) Y: Yellow
- (15) R: Red



- (1) UNITE CDI
- (2) ALTERNATEUR
- (3) CONTACTEUR DE RELAIS DE DEMARREUR
- (4) GENERATEUR D'IMPULSIONS
- (5) BOBINE D'ALLUMAGE
- (6) CONTACTEUR DE DEMARREUR
- (7) BATTERIE
- (8) CONTACTEUR D'ARRET DE MOTEUR
- (9) CONTACTEUR D'ALLUMAGE
- (10) FUSIBLE 10A

- (11) BR: Noir
- (12) G: Vert
- (13) W: Blanc
- (14) Y: Jaune
- (15) R: Rouge

- (1) CDI-EINHEIT
- (2) LICHTMASCHINE
- (3) STARTERMAGNETSCHALTER
- (4) IMPULSGEBER
- (5) ZÜNDSPULE
- (6) STARTERSCHALTER
- (7) BATTERIE
- (8) MOTORABSCHALTER
- (9) ZÜNDSCHALTER
- (10) SICHERUNG 10A

- (11) Bl: Schwarz
- (12) G: Grün
- (13) W: Weiß
- (14) Y: Gelb
- (15) R: Rot

16. IGNITION SYSTEM

SERVICE INFORMATION	16-1	ALTERNATOR EXCITER COIL	16-4
TROUBLESHOOTING	16-1	PULSE GENERATOR	16-4
IGNITION COIL	16-2	IGNITION TIMING	16-5
CDI UNIT	16-3		

SERVICE INFORMATION

GENERAL

- Ignition timing cannot be adjusted since the CDI (Capacitive Discharge Ignition) unit is non-adjustable. If ignition timing is incorrect, check the CDI unit, pulse generator and alternator and replace the faulty parts.
- For spark plug gap inspection and adjustment procedure, see page 3-7.
- For alternator removal and installation, see section 9.

SPECIFICATIONS

Spark plug:	Standard	DPR8EA-9 (NGK) or X24EPR-U9 (ND)
	For cold climate (Below 5°C)	*DPR7EA-9 (NGK) or *X22EPR-U9 (ND)
	For extended high speed driving	DPR9EA-9 (NGK) or X27EPR-U9(ND)

*: Except G-I, H types

Plug gap: 0.8–0.9 mm (0.031–0.035 in)

Ignition timing:

Initial $8^{\circ} \pm 2^{\circ}$ BTDC at $1,200 \pm 100 \text{ min}^{-1}$ (rpm)

Full advance $29^{\circ} \pm 2^{\circ}$ BTDC at $5,000 \text{ min}^{-1}$ (rpm)

Headlight 12V 60W/55W

Taillight 12V 21W/5W

Alternator 170 W/5,000 min^{-1} (rpm)

TROUBLESHOOTING

No spark at plug

- Engine stop switch "OFF"
- Poorly connected, broken or shorted wired
 - Between alternator and ignition coil
 - Between CDI unit and engine stop switch
 - Between CDI unit and ignition switch
 - Between ignition coil and plug
 - Between pulse generator and CDI unit
- Faulty ignition coil
- Faulty CDI unit
- Alternator faulty
- Faulty pulse generator
- Faulty ignition or engine stop switch

Engine starts but runs poorly

- Ignition primary circuit
 - Faulty ignition coil
 - Loose or bare wire
 - Faulty pulse generator
- Secondary circuit
 - Alternator faulty
 - CDI unit faulty
 - Faulty pulse generator

16

IGNITION SYSTEM

IGNITION COIL

REMOVAL

Remove the seat and fuel tank.

Disconnect the ignition coil primary wire and remove the ignition coil.




INSPECTION

CONTINUITY TEST


Measure the primary coil resistance.

RESISTANCE: 0.18 ± 0.02 ohm




Measure the secondary coil resistance.

RESISTANCE: 5.18 ± 1.25 Kohm



Remove the spark plug cap from the wire and measure the secondary coil resistance.

RESISTANCE: 4.1 ± 0.4 Kohm



IGNITION SYSTEM

PERFORMANCE TEST

Check the ignition coil performance with the ignition coil tester (07508-0070100).

NOTE

- Follow the ignition coil tester manufacturer's instructions.

If sparks fail to jump across the electrodes in the tester inspection window, replace the ignition coil with a new one.



INSTALLATION

Install the ignition coil and connect the black/yellow wire connector to the black terminal of the coil and the green wire connector to the green terminal.

Install the spark plug cap.

CDI UNIT

Disconnect the CDI unit coupler and remove the CDI unit.




INSPECTION

CONTINUITY TEST

Replace the CDI unit if the readings are not within the limits shown in the table.

NOTE

- The CDI unit is fully transistorized. For accurate testing, it is necessary to use a specified electrical tester. Use of an improper tester may give false readings.
- Use Sanwa Electric Tester (07308-0020000), Kowa Tester (TH-5H-1) or Kowa Digital Multitester (07411-0020000).



Set the tester on the R x k Ω

Unit: k Ω

(-)	(+)	SW	EXT	PC	E	IGN	ST
SW			∞	∞	∞	∞	∞
EXT	0.1 ~ 20			∞	∞	∞	∞
PC	30 ~ 300	10 ~ 200			1 ~ 100	∞	∞
E	1 ~ 50	0.1 ~ 20	1 ~ 100			∞	∞
IGN	∞	∞	∞	∞	∞		∞
ST				∞		∞	

IGNITION SYSTEM

PERFORMANCE TEST

Inspect the CDI unit with CDI tester.

NOTE

- Follow the CDI tester manufacturer's instructions.

TOOL:

Inspection adapter (AI) 07508—0012300

Connect the special adapter to the CDI unit and CDI tester.

TESTER SWITCH POSITION	CDI UNIT GOOD	CDI UNIT FAULTY
1. OFF	No spark	—
2. P	—	—
3. EXT	—	Sparks jump
4. ON1	Sparks jump	No spark
5. ON2	—	—

Replace the CDI unit with a new one if necessary.

ALTERNATOR EXCITER COIL

NOTE

- It is not necessary to remove the stator coil to make this test.

Remove the seat and left side cover.

Disconnect the exciter coil wire.

The exciter coil is in good condition if there is continuity between the black/red wire terminal and ground.

RESISTANCE: 100–250 ohm

PULSE GENERATOR

INSPECTION

Remove the seat and fuel tank.

Disconnect the pulse generator wire coupler.

Measure the resistance between green/white and blue/yellow.

RESISTANCE: 470–570 ohm

REMOVAL

Remove the right crankcase cover (page 8-3).





Disconnect the pulse generator coupler.

Remove the two bolts attaching the pulse generator and the generator.

INSTALLATION

Install the pulse generator.

Install the wire grommet in the groove of the right crankcase securely.




IGNITION SYSTEM

Turn the crankshaft clockwise and align the pulse generator rotor tooth with the pulse generator pickup and measure the air gap with a feeler gauge.

AIR GAP: 0.8 mm (0.03 in)

Install the right crankcase cover (page 8-19).



IGNITION TIMING


Remove the timing hole cap.
Connect a tachometer and a timing light.

Start the engine and allow it to idle.


IDLE SPEED: 1,200 ± 100 min⁻¹ (rpm)

The timing is normal if the F mark aligns with the index notch.

Start the engine and let it run at 2,000–2,200 min⁻¹ (rpm).
The F mark should move to the right.



The index notch should be between the advance marks at 6,000 min⁻¹ (rpm).



PULSE GENERATOR

INSPECTION

Remove the timing hole cap.
Disconnect the pulse generator pickup and measure the air gap with a feeler gauge.


RESISTANCE: 470–570 Ω

REMOVAL


Remove the timing hole cap.
Disconnect the pulse generator pickup and measure the air gap with a feeler gauge.

INSTALLATION


Install the pulse generator.
Connect the pulse generator pickup and measure the air gap with a feeler gauge.



BATTERY/CHARGING SYSTEM BATTERIE/CIRCUIT DE CHARGE BATTERIE/LADESYSTEM



- (10) B: Black
- (11) R: Red
- (12) W: White
- (13) G: Green
- (14) Y: Yellow



- (1) CONTACTEUR D'ALLUMAGE
- (2) REGULATEUR/RECTIFICATEUR
- (3) BATTERIE
- (4) FUSIBLE PRINCIPAL
- (5) ALTERNATEUR
- (6) PHARE
- (7) FEU ARRIERE
- (8) ECLAIRAGE DES INSTRUMENTS
- (9) TEMOIN DE FAISCEAU DE PHARE
- (10) B: Noir
- (11) R: Rouge
- (12) W: Blanc
- (13) G: Vert
- (14) Y: Jaune

- (1) ZÜNDSCHALTER
- (2) REGLER/GLEICHRICHTER
- (3) BATTERIE
- (4) HAUPTSICHERUNG
- (5) LICHTMASCHINE
- (6) SCHEINWERFER
- (7) SCHLUSS-/BREMSLICHT
- (8) INSTRUMENTENBELEUCHTUNG
- (9) FERNLICHT-KONTROLLAMPE
- (10) B: Schwarz
- (11) R: Rot
- (12) W: Weiß
- (13) G: Grün
- (14) Y: Gelb

17. BATTERY/CHARGING SYSTEM

SERVICE INFORMATION	17-1	BATTERY CHARGING SYSTEM	17-3
TROUBLESHOOTING	17-1	ALTERNATOR	17-5
BATTERY	17-2	VOLTAGE REGULATOR/RECTIFIER	17-5

TROUBLESHOOTING

GENERAL

- The battery electrolyte level should be checked regularly. Fill with distilled water as necessary.
- Quick charge the battery only in an emergency. Slow-charging is preferred.
- Remove the battery from the motorcycle for charging. If the battery must be charged on the motorcycle, disconnect the battery cables.

WARNING

• Do not smoke or have flames near a charging battery. The hydrogen gas produced by a battery is highly flammable and can explode.

- For Alternator removal and installation, refer to Section 9.
- All charging system components can be tested on the motorcycle.

SPECIFICATIONS

Battery	Capacity		12V, 12 ampere-hours	
	Specific gravity at 20°C (68°F)	Fully charged	1.280	
		Normal charged	1.260	
		Need charging	1.200	
	Charging rate		1.2 amperes max.	
Alternator capacity		12V, 170W/5,000 min ⁻¹ (rpm)		
Regulator/rectifier	Type		Transistorized, non-adjustable	
	Regulated voltage		14–15V	
Charging current	Charging start rpm		1,000–1,200 min ⁻¹ (rpm)	
	At idle		(+) 8A/Above 14V	
	At 3,000 min ⁻¹ (rpm)		(+) 12.5A/14–15V	
	At 8,000 min ⁻¹ (rpm)		(+) 13.5A/14–15V	
				Light OFF

17

TROUBLESHOOTING

No power — key turned on

- Dead battery
 - Low fluid level
 - Low specific gravity
 - Charging system failure
- Disconnected battery cable
- Main fuse burned out
- Faulty ignition switch

Low power — key turned on

- Weak battery
 - Low fluid level
 - Low specific gravity
 - Charging system failure
- Loose battery connection

Low power — engine running

- Battery undercharged
 - Low fluid level
 - One or more dead cells
- Charging system failure

Intermittent power

- Loose battery connection
- Loose charging system connection
- Loose starting system connection
- Loose connection or short circuit in ignition system
- Loose connection or short circuit in lighting system

Charging system failure

- Loose, broken, or shorted wire or connection
- Faulty voltage regulator/rectifier
- Faulty alternator

BATTERY CHARGING SYSTEM

BATTERY

REMOVAL

Remove the seat.


Remove the bolt and open the battery holder.

Disconnect the negative terminal, then positive terminal at the battery.

Remove the battery.

CAUTION

- Make sure the positive cable is not forced against any metal parts, otherwise a short may occur.



SPECIFIC GRAVITY TEST

Test each cell by drawing electrolyte into a hydrometer.

SPECIFIC GRAVITY (20°C/68°F)


1.280	Fully charged
1.260 or below	Undercharged

NOTE


- The battery must be recharged if the specific gravity is below 1.20.
- The specific gravity varies with the temperature as shown.
- Replace the battery if sulfation is evident.
- The battery must be replaced if there is sediment on the bottom of the cell.

WARNING

- The battery electrolyte contains sulfuric acid. Avoid contact with skin, eyes, or clothing. Antidote: Flush with water and call a doctor if electrolyte gets in your eyes.



(1) BATTERY TEMPERATURE VS SPECIFIC GRAVITY



When the specific gravity reading is low, the battery must be recharged. Slow-charge the battery; do not quick charge it.

Remove the battery cell caps.


Charge until specific gravity reaches 1.260–1.280.

CHARGING RATE: 1.2 amper maximum

The reading should remain stable for at least one hour after charging.

Check electrolyte level periodically.

After charging, wash the battery with water.



BATTERY CHARGING SYSTEM

WARNING

- Before charging a battery, remove the cap from each cell.
- Keep fire and sparks away from a charging battery.
- Turn power ON/OFF at the charger, not at the battery terminals.
- Discontinue charging if the electrolyte temperature exceeds 45°C (117°F).


CAUTION

- Quick-charging should only be done in an emergency; slow-charging is preferred.

After installing the battery, coat the terminals with clean grease.

CAUTION

- Route the breather tube as shown on the battery caution label.



BATTERY CHARGING SYSTEM



LEAKAGE INSPECTION

Inspect the battery voltage leakage before charging system inspection.

Turn the ignition switch OFF. Remove the ground cable from the battery. Connect the voltmeter between the ground cable and battery (-) terminal.

The voltmeter should indicate 0V with the ignition switch off.

(1) GROUND CABLE



BATTERY CHARGING SYSTEM

CHARGING SYSTEM INSPECTION

NOTE

- Use a fully charged 12V battery (electrolyte specific gravity above 1.260) to test the charging output. Use of a low battery will result in false readings.

Start the engine and warm it up to operating temperature.

Remove the main fuse; connect an ammeter to the positive (+) and negative (-) terminals of the fuse holder as shown.

NOTE

- Use an ammeter which can measure the rate of flow of current in both directions.
- Do not hook up an ammeter between the battery positive (+) terminal and the positive (+) cable of the battery. Failure to do so can lead to a broken ammeter.

Connect a voltmeter between the positive and negative terminals of the battery.

Start the engine and take the readings on the meters:

- Gradually raise the engine speed from the idle to find the speed at which the output is $\pm 0A/14-15V$.

CHARGING START: 1,000–1,200 min^{-1} (rpm)

If the ammeter shows discharging even when the engine speed is raised, the probabilities are:

- Short circuit (excessive current draw)
- Overcharged battery
- Faulty alternator
- Loose or poor contact between alternator and regulator/rectifier.

If the ammeter shows charging even when the engine speed is lowered, this is an indication of:

- Faulty voltage regulator/rectifier
- Discharged battery

If the output voltage is outside of 14–15V when the engine speed is increased, the likelihood is:

- Faulty voltage regulator/rectifier

ALTERNATOR OUTPUT TEST


NOTE

- Use a fully charged 12V battery (electrolyte specific gravity above 1.260) to test the charging output. Use of a low battery will result in false readings.

Warm up the engine.

Connect an ammeter and voltmeter in the same manner as the charging system inspection.

Disconnect the black wire from the regulator/rectifier coupler. Start the engine and check the charging output at the speeds shown in the chart.



CHARGING OUTPUT SPECIFICATIONS (Light off)

ENGINE RPM	AMPERAGE	VOLTAGE
1,200 min^{-1} (rpm)	(+) 8A	ABOVE 12V
3,000 min^{-1} (rpm)	(+) 12.5A	14–15V
8,000 min^{-1} (rpm)	(+) 13.5A	14–15V

BATTERY CHARGING SYSTEM

ALTERNATOR

STATOR COIL INSPECTION

Remove the left side cover.

Disconnect the alternator-to-regulator/rectifier coupler.

Check for continuity between the leads, and between the leads and ground.

Replace the stator if there is no continuity between the leads, or if there is continuity between the leads and ground.

VOLTAGE REGULATOR/RECTIFIER

Remove the seat and fuel tank.

Disconnect the regulator/rectifier couplers.

Check for continuity between the leads with an ohmmeter.

NOTE

- The test results shown are for a positive ground ohmmeter and the opposite results will be obtained when a negative ground ohmmeter is used.

NORMAL DIRECTION: CONTINUITY


	+ probe	- probe
I	YELLOW	GREEN
II	RED/WHITE	YELLOW

REVERSE DIRECTION: NO CONTINUITY


	+ probe	- probe
I	GREEN	YELLOW
II	YELLOW	RED/WHITE

Remove the regulator/rectifier mounting bolts and the regulator/rectifier.



Replace the regulator/rectifier if necessary.





(1) STATOR COIL WIRE COUPLER



(1) REGULATOR/RECTIFIER COUPLERS



ELECTRICAL STARTER SYSTEM **CIRCUIT DE DEMARREUR ELECTRIQUE** **ELECTRISCHER STARTER**



- (1) DEMARREUR
- (2) RELAIS DE DEMARREUR
- (3) DIODE
- (4) CONTACTEUR NEUTRE
- (5) CONTACTEUR D'EMBRAYAGE
- (6) TEMOIN DE POINT MORT
- (7) CONTACTEUR D'ALLUMAGE
- (8) BOBINE DE RELAIS
- (9) CONTACTEUR DE DEMARREUR
- (10) FUSIBLE
- (11) BATTERIE
- (12) G: Vert
- (13) R: Rouge
- (14) Lg Vert clair

- (1) STARTERMOTOR
- (2) STARTERRELAIS
- (3) DIODE
- (4) LEERLAUFSSCHALTER
- (5) KUPPLUNGSSCHALTER
- (6) LEERLAUF-KONTROLLAMPE
- (7) ZÜNDSCHALTER
- (8) RELAISSPULE
- (9) STARTERSCHALTER
- (10) SICHERUNG 30A
- (11) BATTERIE
- (12) G: Grün
- (13) R: Rot
- (14) Lg: Hellgrün

18. ELECTRICAL STARTER SYSTEM

SERVICE INFORMATION	18-1	STARTER MOTOR	18-5
TROUBLESHOOTING	18-1	STARTER RELAY SWITCH	18-7
STARTER IDLE GEARS	18-2	CLUTCH SWITCH DIODE	18-7
STARTER CLUTCH/DRIVEN GEAR	18-2		

SERVICE INFORMATION

GENERAL

- The starter motor can be removed with the engine in the frame.

SPECIFICATIONS

ITEM		STANDARD	SERVICE LIMIT
Starter motor	Brush spring tension	800 g (28.2 oz)	680 g (23.9 oz)
	Brush length	12 mm (0.47 in)	5.5 mm (0.22 in)

TORQUE

Starter clutch torx bolt 28–32 N·m (2.8–3.2 kg·m, 20–23 ft·lb)

TOOL

SPECIAL

Torx bit (40) 07703–0010100

TROUBLESHOOTING

Starter motor will not turn

- Dead battery
- Faulty ignition switch
- Faulty starter switch
- Faulty neutral switch
- Faulty starter relay switch
- Loose or disconnected wires
- Faulty clutch switch

Starter motor turns: but engine does not turn

- Faulty starter drive pinion
- Faulty starter idle gear

Starter motor and engine turn, but engine does not start

- Faulty ignition system
- Engine problem
- Faulty engine stop switch

Starter motor turns engine slowly


- Low battery
- Excessive resistance in circuit
- Binding in starter motor

ELECTRICAL STARTER SYSTEM


STARTER IDLE GEARS

REMOVAL

Remove the starter gear cover.




Remove the gasket and dowel pins.
Remove the washers, starter reduction and idle gears.
Then remove the needle bearings from the gear shafts.



Remove the left crankcase cover (page 9-2).
Remove the washer and starter drive gear.


INSPECTION

Inspect the starter gears needle bearings for wear or damage.
Check the starter gears for excessive wear or damage.
Replace if necessary.



STARTER CLUTCH/DRIVEN GEAR

Remove the flywheel with the flywheel holder (page 9-3).
Remove the washer and starter driven gear.




ELECTRICAL STARTER SYSTEM

Remove the six torx bolts attaching the starter clutch to the flywheel and remove the starter clutch and clutch outer.

TOOL:


Torx bit (T40) 07703-0010100

**INSPECTION/ASSEMBLY**

Inspect the starter clutch for smooth operation and the rollers for excessive wear or damage.

Install the starter clutch onto the clutch outer.

(1) CLUTCH OUTER (2) STARTER CLUTCH




Install the starter clutch and clutch outer onto the flywheel. Apply a locking agent to the six torx bolt threads and tighten the bolts using the torx bit.

TORQUE: 28–32 N·m (2.8–3.2 kg·m, 20–23 ft·lb)


TOOL:

Torx bit (T40) 07703-0010100



Install the starter driven gear onto the starter outer. The starter driven gear should turn counterclockwise freely and should not turn clockwise.

(1) STARTER DRIVEN GEAR



ELECTRICAL STARTER SYSTEM

INSTALLATION

Install the inner washer and needle bearing onto the crankshaft.

Install the starter driven gear and outer washer.

Install the flywheel (page 9-4).

Assemble the needle bearings, drive gear and inner and outer washer onto the gear shaft.

Install them onto the left crankcase.





Install the left crankcase cover (page 9-4).

Assemble the needle bearing, starter idle gear and inner washer onto the gear shaft.

Install them onto the left crankcase cover.


Assemble the inner washer, needle bearing onto the gear shaft and install them to the left crankcase cover.

Install the starter reduction gear onto the gear shaft.



ELECTRICAL STARTER SYSTEM

Install the outer washers onto the gear shafts.
Install the gasket and dowel pins.
Install the starter gear cover and bolts.
Tighten the bolts.



STARTER MOTOR


REMOVAL/DISASSEMBLY

Remove the clutch cable holder bolt.


WARNING

- **With the ignition switch off, remove the negative cable at the battery before servicing the starter motor.**

Remove the bolt, oil hose bolt, sealing washers and disconnect the oil hose from the right crankcase cover.




Disconnect the starter cable at the motor.
Remove the starter motor mounting bolts and mount base.
Remove the starter motor.



NOTE

- Record the location and number of the thrust washers and insulator washer.



ELECTRICAL STARTER SYSTEM


BRUSH INSPECTION

Remove the starter motor case screws.
Inspect the brushes and measure the brush length.
Measure brush spring tension with a spring scale.

SERVICE LIMITS:

Brush length: 5.5 mm (0.22 in)
Brush spring tension: 680 g (23.9 oz)

(1) BRUSH




COMMUTATOR INSPECTION

Remove the starter motor case.
Inspect the commutator bars for discoloration.
Bars discolored in pairs indicate grounded armature coils.


NOTE

- Do not use emery or sand paper on the commutator.

(1) ARMATURE COIL



Check for continuity between pairs of commutator bars. Also, make a resistance check between individual commutator bars and the armature shaft.
There should be no continuity.




- (1) CONTINUITY BETWEEN COMMUTATOR BAR PAIRS: NORMAL
- (2) NO CONTINUITY BETWEEN COMMUTATOR BARS AND ARMATURE SHAFT: NORMAL

ELECTRICAL STARTER SYSTEM


ASSEMBLY/INSTALLATION

Assemble the starter motor. Align the case notch with the brush holder pin.



Install the rear cover aligning its slot with the brush holder pin.


Install the starter motor in the reverse order of removal.



STARTER RELAY SWITCH

Connect an ohmmeter and 12V battery to the starter relay switch as shown.

The switch is normal if there is continuity with the battery connected and there is no continuity without the battery connected.




CLUTCH SWITCH DIODE

Remove the seat.
Remove the clutch diode from the wire harness.

INSPECTION

Check for continuity with an ohmmeter.

NORMAL DIRECTION: CONTINUITY
REVERSE DIRECTION: NO CONTINUITY



19. LIGHT/SWITCHES/INSTRUMENT

SERVICE INFORMATION	19-1	HANDLEBAR SWITCHES	19-7
TROUBLESHOOTING	19-1	BRAKE LIGHT SWITCHES	19-8
BULB REPLACEMENT	19-3	CLUTCH SWITCH	19-9
INSTRUMENTS	19-4	BRAKE AND TAILLIGHT SENSOR	19-9
IGNITION SWITCH	19-5		

SERVICE INFORMATION

GENERAL

- Some wires have different colored bands around them near the connector. These are connected to other wires which correspond with the band color.
- All plastic plugs have locking tabs that must be released before disconnecting, and must be aligned when reconnecting.
- Isolate an electrical failure, check the continuity of the electrical path through the part. A continuity check can usually be made without removing the part from the motorcycle — by simply disconnecting the wires and connecting a continuity tester or voltmeter to the terminals or connections.

SPECIFICATIONS

Headlight	12V 60/55W
Brake and taillight	21/5W
Turn signal light	21W
Speedometer light	3.4W x 2
Tachometer light	3W x 2
Neutral indicator	3W
Turn signal indicator	3W
High beam indicator	3W

TROUBLESHOOTING

No lights come on when ignition switch is turned ON:

- Bulb at fault or burned out
- Faulty switch
- Wiring to that component has open circuit
- Fuse blown
- Wiring loose, broken, or at fault
- Battery dead or disconnected


All lights come on, but dimly, when ignition switch is turned ON:

- Battery voltage low
- Wiring or switch has excessive resistance

Headlight beam does not shift when HI-LO switch is operated:

- Beam filament burned out
- Faulty dimmer switch


BRAKE AND TAILLIGHT WARNING SYSTEM



BULB REPLACEMENT


HEADLIGHT

Remove the headlight mounting screws.
Disconnect the wire coupler and remove the headlight.



Remove the retaining screws, horizontal adjusting screw and sealed beam unit from the rim.
Assemble the headlight in the reverse order of disassembly.
After installation, adjust the headlight aim.


(1) RETAINER SCREW



(2) HORIZONTAL ADJUSTING SCREW


INSTRUMENTS

Remove the headlight case bolts.
Disconnect the speedometer cable and instrument cover screws.



Replace the instrument bulb sockets.
Replace any burnt out bulbs.
After installing a new bulb, check for continuity.
If the bulb does not light, inspect the wiring for an open or short circuit.
Remove the instrument, if necessary.


(1) INSTRUMENT BULB SOCKET



TAIL/BRAKE LIGHT

Remove the seat.
Remove the tool box cover and tool kit.
Remove the tail/brake light socket and bulb.
Disconnect the connectors, if necessary.


(1) TAIL/BRAKE LIGHT SOCKET



TURN SIGNAL

Remove the turn signal mounting screw and bulb socket.
Replace any burnt out bulb.

(1) MOUNTING SCREW




INSTRUMENTS

REMOVAL


Remove the headlight (page 19-2).
Disconnect the instrument wire couplers and speedometer cable.
Remove the fuse holder and instrument mounting bolts.
Remove the instruments.

(1) INSTRUMENT MOUNTING BOLTS




Remove the instrument cover screws.

(1) INSTRUMENT COVER SCREWS



ASSEMBLY/INSTALLATION

Assemble and install the instruments in the reverse order of disassembly and removal.



IGNITION SWITCH

INSPECTION

Remove the headlight (page 19-2).

Disconnect the ignition switch coupler and check continuity of terminals on the ignition switch coupler in each switch position.

SWITCH POSITION


LOCK: No continuity

OFF: No continuity

ON: R to BI, Br/W to Br – Continuity

PARK: Y/B to R – Continuity

Color Position	Y/BI	R	BI	Br/W	Br	BI/W	G
ON		○	○	○	○		
OFF						○	○
P	○	○				○	○
LOCK						○	○



HANDLEBAR SWITCHES

The handlebar switch must be replaced as an assembly.
Remove the headlight and disconnect the handlebar switch couplers.

Continuity should exist between the color coded wires in each chart.

ENGINE STOP SWITCH

Color	Bl/W	G
Position		
OFF	○	○
RUN		

STARTER SWITCH

Color	Bl/Br	Y/R
Position		
FREE		
PUSH	○	○

LIGHTING SWITCH



Color	Br/Bu	Br/W	Bu/W	Bl/R
Position				
OFF				
P	○	○		
HL	○	○	○	○

TURN SIGNAL SWITCH

Color	W	R	L
Position			
R	○	○	
N			
L	○		○

HORN SWITCH

Color	W/G	Lg
Position		
FREE		
PUSH	○	○



PASSING SWITCH

Color Position	W/G	Bu
FREE		
PUSH	○	○

DIMMER SWITCH

Color Position	Bu/W	W	Bu
Lo	○	○	
(N)	○	○	○
Hi	○		○



BRAKELIGHT SWITCHES

FRONT

Disconnect the front brake light switch wires from the switch.
Check the front brake light switch for continuity with the front brake applied.
Replace the switches if necessary.

REAR

Check the rear brake light switch for continuity with the rear brake applied.




CLUTCH SWITCH

Check continuity of the clutch lever switch with the clutch released and applied.
Replace the switch if necessary.

CLUTCH APPLIED: CONTINUITY

CLUTCH RELEASED: NO CONTINUITY



BRAKE AND TAILLIGHT SENSOR

INSPECTION

Refer to the troubleshooting (page 19-2) for brake and tail-light warning system inspection.


Disconnect the coupler from the sensor.

Connect a voltmeter between the Black/Brown wire terminal and the Green wire terminal.

There should be battery voltage when the ignition switch on.

If there is battery voltage, replace the sensor with a new one.

(1) BRAKE AND TAILLIGHT SENSOR




BRAKELIGHT SWITCHES

FRONT

Check the front brake light switch operation. The front brake light switch is located in the front brake master cylinder. The front brake light switch is a normally closed switch. When the front brake is applied, the switch opens and the front brake light turns on. Replace the switch if necessary.

REAR


Check the rear brake light switch operation. The rear brake light switch is located in the rear brake master cylinder. The rear brake light switch is a normally closed switch. When the rear brake is applied, the switch opens and the rear brake light turns on. Replace the switch if necessary.



20. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START	20-1	POOR PERFORMANCE AT HIGH SPEED	20-4
ENGINE LACKS POWER	20-2	POOR HANDLING	20-4
POOR PERFORMANCE AT LOW AND IDLE SPEEDS	20-3		

ENGINE DOES NOT START OR IS HARD TO START



ENGINE LACKS POWER

Probable Cause:

1. Raise wheels off ground and spin by hand

WHEEL SPINS FREELY

WHEEL DOES NOT SPIN FREELY

- (1) Brake dragging
- (2) Worn or damaged wheel bearing
- (3) Wheel bearing needs lubrication
- (4) Drive chain too tight
- (5) Rear axle nut excessively tightened

2. Check tire pressure with tire gauge

PRESSURE NORMAL

PRESSURE TOO LOW

- (1) Punctured tire
- (2) Faulty tire valve

3. Check clutch slipping

CLUTCH ENGAGED PROPERLY

CLUTCH SLIPS

- (1) Clutch slipping
- (2) Worn clutch disc/plate
- (3) Warped clutch disc/plate

4. Lightly accelerate engine

ENGINE SPEED INCREASE

ENGINE SPEED DOES NOT INCREASE SUFFICIENTLY

- (1) Carburetor choke closed
- (2) Clogged air cleaner
- (3) Restricted fuel flow
- (4) Clogged fuel tank breather hole
- (5) Clogged muffler

5. Check ignition timing

CORRECT

INCORRECT

- (1) Faulty CDI unit
- (2) Faulty pulse generator

6. Check valve clearance

CORRECT

INCORRECT

- (1) Improper valve adjustment
- (2) Worn valve seat

7. Test cylinder compression using compression gauge

NORMAL

TOOL LOW

- (1) Worn or damaged valve seat
- (2) Worn cylinder or piston rings
- (3) Damaged cylinder head gasket
- (4) Improper valve timing
- (5) Improperly adjusted decompression mechanism
- (6) Seized valve
- (7) Warped or clacked cylinder head mating surfaces

8. Check carburetor for clogging

NOT CLOGGED

CLOGGED

- (1) Carburetor not serviced frequently enough

9. Remove spark plug

NOT FOULED OR DISCOLORED

FOULED OR DISCOLORED

- (1) Plug not replaced frequently enough
- (2) Use of plug with improper heat range

TROUBLESHOOTING

10. Remove oil level gauge and check oil level.

OIL LEVEL INCORRECT

- (1) Oil level too high
(2) Oil level too low

CORRECT

11. Accelerate or run at high speed

ENGINE KNOCKS

- (1) Worn piston and cylinder
(2) Fuel/air mixture too lean
(3) Use of improper grade of fuel
(4) Excessive carbon build-up in combustion chamber
(5) Ignition timing too advanced (Faulty CDI unit)

ENGINE DOES NOT KNOCK

12. Check if engine overheats

OVERHEATED

- (1) Excessive carbon build-up in combustion chamber
(2) Improper quality fuel
(3) Clutch slipping
(4) Fuel air mixture too lean

NORMAL

13. Remove cylinder head cover and inspect lubrication

VALVE TRAIN NOT LUBRICATED PROPERLY

- (1) Clogged oil passage
(2) Clogged oil control orifice
(3) Contaminated oil

VALVE TRAIN LUBRICATED PROPERLY

POOR PERFORMANCE AT LOW AND IDLE SPEEDS

1. Check ignition timing and valve clearance

INCORRECT

Probable Cause:

- (1) Improper valve clearance
(2) Improper ignition timing (Faulty CDI unit)

CORRECT

2. Check carburetor pilot screw adjustment

INCORRECT

- (1) Fuel-air mixture too lean (To correct, screw out)
(2) Fuel-air mixture too rich (To correct, screw in)

CORRECT

3. Check if air is leaking past manifold

LEAKING

- (1) Deteriorated insulator O-ring
(2) Loose carburetor

NOT LEAKING


4. Try spark test

WEAK OR INTERMITTENT SPARK

- (1) Faulty, carbon or wet fouled spark plug
(2) Faulty CDI unit
(3) Alternator faulty
(4) Faulty ignition coil
(5) Faulty pulse generator
(6) Poorly connected, broken or shorted wire

GOOD SPARK

POOR PERFORMANCE AT HIGH SPEED



POOR HANDLING

Check tire pressure

